

# HC(S)08 / RS08 Assembler Manual

Freescale™ and the Freescale logo are trademarks of Freescale Semiconductor, Inc. CodeWarrior is a trademark or registered trademark of Freescale Semiconductor, Inc. in the United States and/or other countries. All other product or service names are the property of their respective owners.

Copyright © 2006 by Freescale Semiconductor, Inc. All rights reserved.

Information in this document is provided solely to enable system and software implementers to use Freescale Semiconductor products. There are no express or implied copyright licenses granted hereunder to design or fabricate any integrated circuits or integrated circuits based on the information in this document.

Freescale Semiconductor reserves the right to make changes without further notice to any products herein. Freescale Semiconductor makes no warranty, representation or guarantee regarding the suitability of its products for any particular purpose, nor does Freescale Semiconductor assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation consequential or incidental damages. “Typical” parameters that may be provided in Freescale Semiconductor data sheets and/or specifications can and do vary in different applications and actual performance may vary over time. All operating parameters, including “Typicals”, must be validated for each customer application by customer's technical experts. Freescale Semiconductor does not convey any license under its patent rights nor the rights of others. Freescale Semiconductor products are not designed, intended, or authorized for use as components in systems intended for surgical implant into the body, or other applications intended to support or sustain life, or for any other application in which the failure of the Freescale Semiconductor product could create a situation where personal injury or death may occur. Should Buyer purchase or use Freescale Semiconductor products for any such unintended or unauthorized application, Buyer shall indemnify and hold Freescale Semiconductor and its officers, employees, subsidiaries, affiliates, and distributors harmless against all claims, costs, damages, and expenses, and reasonable attorney fees arising out of, directly or indirectly, any claim of personal injury or death associated with such unintended or unauthorized use, even if such claim alleges that Freescale Semiconductor was negligent regarding the design or manufacture of the part.

## How to Contact Us

<b>Corporate Headquarters</b>	Freescale Semiconductor, Inc. 7700 West Parmer Lane Austin, TX 78729 U.S.A.
<b>World Wide Web</b>	<a href="http://www.freescale.com/codewarrior">http://www.freescale.com/codewarrior</a>
<b>Technical Support</b>	<a href="http://www.freescale.com/support">http://www.freescale.com/support</a>

# Table of Contents

---

## I Using the HC(S)08/RS08 Assembler

Highlights . . . . .	15
Structure of this document . . . . .	15
<b>1 Working with the Assembler</b>	<b>17</b>
Programming Overview . . . . .	17
Project directory . . . . .	18
External Editor . . . . .	18
Using CodeWarrior to manage an assembly language project . . . . .	18
The Wizard . . . . .	19
Analysis of groups and files in the project window . . . . .	29
CodeWarrior groups . . . . .	29
Creating a Target . . . . .	30
Generating Listing Files . . . . .	38
Renaming files. . . . .	39
Creating a new group . . . . .	41
Renaming groups in the project window. . . . .	42
Writing your assembly source files. . . . .	43
Analyzing the project files . . . . .	44
Assembling your source files . . . . .	47
Assembling with CodeWarrior . . . . .	47
Assembling with the Assembler . . . . .	51
Linking the application. . . . .	67
Linking with CodeWarrior . . . . .	67
Linking with the Linker. . . . .	71
Directly generating an ABS file . . . . .	80
Using CodeWarrior to generate an ABS file. . . . .	81
<b>2 Assembler Graphical User Interface</b>	<b>89</b>
Starting the Assembler . . . . .	89

---

Assembler Main Window . . . . .	90
Window title . . . . .	91
Content area. . . . .	91
Toolbar . . . . .	92
Status bar . . . . .	93
Assembler menu bar . . . . .	93
File menu. . . . .	93
Assembler menu . . . . .	95
View menu. . . . .	95
Editor Setting dialog box . . . . .	96
Global Editor (shared by all tools and projects) . . . . .	96
Local Editor (shared by all tools) . . . . .	97
Editor started with the command line . . . . .	98
Editor started with DDE . . . . .	99
CodeWarrior with COM . . . . .	100
Modifiers. . . . .	101
Save Configuration dialog box . . . . .	102
Environment Configuration dialog box. . . . .	103
Option Settings dialog box . . . . .	105
Message settings dialog box . . . . .	106
Changing the class associated with a message . . . . .	108
About... dialog box . . . . .	110
Specifying the input file . . . . .	110
Use the command line in the toolbar to assemble. . . . .	110
Assembling a new file. . . . .	110
Assembling a file which has already been assembled. . . . .	110
Use the File > Assemble... entry . . . . .	111
Use Drag and Drop . . . . .	111
Message/Error feedback . . . . .	111
Use information from the assembler window . . . . .	112
Use a user-defined editor. . . . .	112
Line number can be specified on the command line. . . . .	112
Line number cannot be specified on the command line . . . . .	112

---

<b>3 Environment</b>	<b>115</b>
Current directory . . . . .	116
Environment macros . . . . .	117
Global initialization file - mctools.ini (PC only) . . . . .	117
Local configuration file (usually project.ini) . . . . .	118
Line continuation . . . . .	120
Environment variables details . . . . .	121
ABSPATH: Absolute file path . . . . .	122
ASMOPTIONS: Default assembler options . . . . .	123
COPYRIGHT: Copyright entry in object file . . . . .	124
DEFAULTDIR: Default current directory . . . . .	125
ENVIRONMENT: Environment file specification . . . . .	126
ERRORFILE: Filename specification error . . . . .	127
GENPATH: Search path for input file . . . . .	130
INCLUDETIME: Creation time in the object file . . . . .	131
OBJPATH: Object file path . . . . .	132
SRECORD: S-Record type . . . . .	133
TEXTPATH: Text file path . . . . .	134
TMP: Temporary directory . . . . .	135
USERNAME: User Name in object file . . . . .	136
<b>4 Files</b>	<b>137</b>
Input files . . . . .	137
Source files . . . . .	137
Include files . . . . .	137
Output files . . . . .	137
Object files . . . . .	138
Absolute files . . . . .	138
S-Record Files . . . . .	138
Listing files . . . . .	139
Debug listing files . . . . .	139
Error listing file . . . . .	139
File Processing . . . . .	140

---

<b>5 Assembler Options</b>	<b>143</b>
Types of assembler options . . . . .	143
Assembler Option details . . . . .	145
Using special modifiers . . . . .	145
List of Assembler options . . . . .	149
Detailed listing of all assembler options . . . . .	151
-Ci: Switch case sensitivity on label names OFF . . . . .	152
-CMacAngBrack: Angle brackets for grouping Macro Arguments . . . . .	154
-CMacBrackets: Square brackets for macro arguments grouping . . . . .	155
-Compat: Compatibility modes . . . . .	156
-CS08/-C08/-CRS08: Derivative family . . . . .	159
-D: Define Label . . . . .	161
-Env: Set environment variable . . . . .	163
-F (-Fh, -F2o, -FA2o, -F2, -FA2): Output-file format . . . . .	164
-H: Short Help . . . . .	166
-I: Include file path . . . . .	167
-L: Generate a listing file . . . . .	168
-Lasmc: Configure listing file . . . . .	171
-Lasms: Configure the address size in the listing file . . . . .	173
-Lc: No Macro call in listing file . . . . .	175
-Ld: No macro definition in listing file . . . . .	178
-Le: No Macro expansion in listing file . . . . .	181
-Li: No included file in listing file . . . . .	184
-Lic: License information . . . . .	186
-LicA: License information about every feature in directory . . . . .	187
-LicBorrow: Borrow license feature . . . . .	188
-LicWait: Wait until floating license is available from floating License Server . . . . .	190
-Ll: Show label statistics . . . . .	191
-M (-Ms, -Mt): Memory model . . . . .	193
-MacroNest: Configure maximum macro nesting . . . . .	195
-MCUasm: Switch compatibility with MCUasm ON . . . . .	196
-N: Display notify box . . . . .	197
-NoBeep: No beep in case of an error . . . . .	198

---

## Table of Contents

---

-NoDebugInfo: No debug information for ELF/DWARF files . . . . .	199
-NoEnv: Do not use environment . . . . .	200
-ObjN: Object filename specification . . . . .	201
-Prod: Specify project file at startup . . . . .	203
-Struct: Support for structured types . . . . .	204
-V: Prints the Assembler version. . . . .	205
-View: Application standard occurrence. . . . .	206
-W1: No information messages. . . . .	208
-W2: No information and warning messages . . . . .	209
-WErrFile: Create "err.log" error file . . . . .	210
-Wmsg8x3: Cut filenames in Microsoft format to 8.3 . . . . .	211
-WmsgCE: RGB color for error messages . . . . .	212
-WmsgCF: RGB color for fatal messages. . . . .	213
-WmsgCI: RGB color for information messages . . . . .	214
-WmsgCU: RGB color for user messages. . . . .	215
-WmsgCW: RGB color for warning messages . . . . .	216
-WmsgFb (-WmsgFbv, -WmsgFbm): Set message file format for batch mode 217	
-WmsgFi (-WmsgFiv, -WmsgFim): Set message file format for interactive mode . . . . .	219
-WmsgFob: Message format for batch mode . . . . .	221
-WmsgFoi: Message format for interactive mode. . . . .	223
-WmsgFonf: Message format for no file information. . . . .	225
-WmsgFonp: Message format for no position information. . . . .	227
-WmsgNe: Number of error messages . . . . .	229
-WmsgNi: Number of Information messages . . . . .	230
-WmsgNu: Disable user messages . . . . .	231
-WmsgNw: Number of Warning messages. . . . .	233
-WmsgSd: Setting a message to disable . . . . .	234
-WmsgSe: Setting a message to Error. . . . .	235
-WmsgSi: Setting a message to Information. . . . .	236
-WmsgSw: Setting a Message to Warning . . . . .	237
-WOutFile: Create error listing file. . . . .	238
-WStdout: Write to standard output . . . . .	239

---

<b>6</b>	<b>Sections</b>	<b>241</b>
	Section attributes . . . . .	241
	Code sections . . . . .	241
	Constant sections . . . . .	241
	Data sections . . . . .	242
	Section types . . . . .	242
	Absolute sections . . . . .	242
	Relocatable sections . . . . .	244
	Relocatable vs. absolute sections . . . . .	247
	Modularity . . . . .	247
	Multiple developers . . . . .	247
	Early development . . . . .	248
	Enhanced portability . . . . .	248
	Tracking overlaps . . . . .	248
	Reusability . . . . .	248
<b>7</b>	<b>Assembler Syntax</b>	<b>249</b>
	Comment line . . . . .	249
	Source line . . . . .	249
	Label field . . . . .	250
	Operation field . . . . .	250
	Operand field: Addressing modes (HC08 / HCS08) . . . . .	265
	Operand Field: Addressing Modes (RS08) . . . . .	276
	Comment Field . . . . .	280
	Symbols . . . . .	280
	User-defined symbols . . . . .	280
	External symbols . . . . .	281
	Undefined symbols . . . . .	282
	Reserved symbols . . . . .	282
	Constants . . . . .	282
	Integer constants . . . . .	283
	String constants . . . . .	283
	Floating-Point constants . . . . .	283
	Operators . . . . .	283



---

Addition and subtraction operators (binary) . . . . .	284
Multiplication, division and modulo operators (binary) . . . . .	285
Sign operators (unary) . . . . .	285
Shift operators (binary) . . . . .	286
Bitwise operators (binary) . . . . .	287
Bitwise operators (unary) . . . . .	288
Logical operators (unary) . . . . .	288
Relational operators (binary) . . . . .	289
HIGH operator . . . . .	289
HIGH_6_13 Operator . . . . .	290
LOW operator . . . . .	290
MAP_ADDR_6 Operator . . . . .	291
PAGE operator . . . . .	292
Force operator (unary) . . . . .	292
Operator precedence . . . . .	293
Expression . . . . .	294
Absolute expression . . . . .	295
Simple relocatable expression . . . . .	296
Unary operation result . . . . .	296
Binary operations result . . . . .	297
Translation limits . . . . .	298

## **8 Assembler Directives 299**

Directive overview . . . . .	299
Section-Definition directives . . . . .	299
Constant-Definition directives . . . . .	299
Data-Allocation directives . . . . .	299
Symbol-Linkage directives . . . . .	300
Assembly-Control directives . . . . .	300
Listing-File Control directives . . . . .	301
Macro Control directives . . . . .	302
Conditional Assembly directives . . . . .	302
Detailed descriptions of all assembler directives . . . . .	303
ABSENTRY - Application entry point . . . . .	304
ALIGN - Align Location Counter . . . . .	306

## Table of Contents

---

BASE - Set number base . . . . .	307
CLIST - List conditional assembly . . . . .	309
DC - Define Constant . . . . .	311
DCB - Define Constant Block . . . . .	313
DS - Define Space . . . . .	314
ELSE - Conditional assembly . . . . .	316
END - End assembly . . . . .	318
ENDFOR - End of FOR block . . . . .	319
ENDIF - End conditional assembly . . . . .	320
ENDM - End macro definition . . . . .	321
EQU - Equate symbol value . . . . .	322
EVEN - Force word alignment . . . . .	323
FAIL - Generate Error message . . . . .	325
FOR - Repeat assembly block . . . . .	329
IF - Conditional assembly . . . . .	331
IFcc - Conditional assembly . . . . .	333
INCLUDE - Include text from another file . . . . .	335
LIST - Enable Listing . . . . .	336
LLEN - Set Line Length . . . . .	338
LONGEVEN - Forcing Long-Word alignment . . . . .	340
MACRO - Begin macro definition . . . . .	341
MEXIT - Terminate Macro Expansion . . . . .	342
MLIST - List macro expansions . . . . .	345
NOLIST - Disable Listing . . . . .	348
NOPAGE - Disable Paging . . . . .	350
OFFSET - Create absolute symbols . . . . .	351
ORG - Set Location Counter . . . . .	353
PAGE - Insert Page break . . . . .	355
PLEN - Set Page Length . . . . .	357
RAD50 - Rad50-encoded string constants . . . . .	358
SECTION - Declare Relocatable Section . . . . .	361
SET - Set Symbol Value . . . . .	363
SPC - Insert Blank Lines . . . . .	364
TABS - Set Tab Length . . . . .	365
TITLE - Provide Listing Title . . . . .	366

---

---

XDEF - External Symbol Definition . . . . .	367
XREF - External Symbol Reference . . . . .	368
XREFB - External Reference for Symbols located on the Direct Page . . .	369
<b>9 Macros</b>	<b>371</b>
Macro overview . . . . .	371
Defining a macro . . . . .	371
Calling macros . . . . .	372
Macro parameters . . . . .	372
Macro argument grouping . . . . .	373
Labels inside macros . . . . .	375
Macro expansion . . . . .	376
Nested macros . . . . .	376
<b>10 Assembler Listing File</b>	<b>377</b>
Page header . . . . .	377
Source listing . . . . .	378
Abs. . . . .	378
Rel. . . . .	379
Loc. . . . .	380
Obj. code . . . . .	381
Source line . . . . .	382
<b>11 Mixed C and Assembler Applications</b>	<b>383</b>
Memory models . . . . .	383
Parameter passing scheme . . . . .	384
Return Value . . . . .	384
Accessing assembly variables in an ANSI-C source file . . . . .	384
Accessing ANSI-C variables in an assembly source file . . . . .	385
Invoking an assembly function in an ANSI-C source file . . . . .	386
Example of a C file . . . . .	387
Support for structured types . . . . .	389
Structured type definition . . . . .	389
Types allowed for structured type fields . . . . .	390
Variable definition . . . . .	391

---

---

Variable declaration . . . . .	391
Accessing a structured variable . . . . .	392
Structured type: Limitations . . . . .	393
<b>12 Make Applications</b>	<b>395</b>
Assembly applications . . . . .	395
Directly generating an absolute file . . . . .	395
Mixed C and assembly applications . . . . .	395
Memory maps and segmentation . . . . .	396
<b>13 How to ...</b>	<b>397</b>
How to work with absolute sections . . . . .	397
Defining absolute sections in an assembly source file . . . . .	397
Linking an application containing absolute sections. . . . .	399
How to work with relocatable sections. . . . .	400
Defining relocatable sections in a source file . . . . .	400
Linking an application containing relocatable sections . . . . .	401
How to initialize the Vector table . . . . .	402
Initializing the Vector table in the linker PRM file . . . . .	403
Initializing the Vector Table in a source file using a relocatable section . . . . .	405
Initializing the Vector Table in a source file using an absolute section . . . . .	408
Splitting an application into different modules . . . . .	410
Example of an Assembly File (Test1.asm) . . . . .	410
Corresponding include file (Test1.inc). . . . .	410
Example of an assembly File (Test2.asm). . . . .	411
Using the direct addressing mode to access symbols . . . . .	412
Using the direct addressing mode to access external symbols . . . . .	413
Using the direct addressing mode to access exported symbols. . . . .	413
Defining symbols in the direct page . . . . .	413
Using the force operator . . . . .	414
Using SHORT sections . . . . .	414

---

## II Appendices

<b>A</b>	<b>Global Configuration File Entries</b>	<b>419</b>
	[Installation] Section . . . . .	420
	Path . . . . .	420
	Group . . . . .	420
	[Options] Section . . . . .	421
	DefaultDir . . . . .	421
	[XXX_Assembler] Section . . . . .	422
	SaveOnExit . . . . .	422
	SaveAppearance . . . . .	422
	SaveEditor . . . . .	423
	SaveOptions . . . . .	423
	RecentProject0, RecentProject1, . . . . .	423
	[Editor] Section . . . . .	425
	Editor_Name . . . . .	425
	Editor_Exe . . . . .	425
	Editor_Opts . . . . .	426
	Example . . . . .	427
<b>B</b>	<b>Local Configuration File Entries</b>	<b>429</b>
	[Editor] Section . . . . .	430
	Editor_Name . . . . .	430
	Editor_Exe . . . . .	430
	Editor_Opts . . . . .	431
	[XXX_Assembler] Section . . . . .	432
	RecentCommandLineX, X= integer . . . . .	432
	CurrentCommandLine . . . . .	432
	StatusBarEnabled . . . . .	433
	ToolbarEnabled . . . . .	433
	WindowPos . . . . .	434
	WindowFont . . . . .	434
	TipFilePos . . . . .	435
	ShowTipOfDay . . . . .	435

---

Options . . . . .	436
EditorType . . . . .	436
EditorCommandLine . . . . .	437
EditorDDEClientName . . . . .	437
EditorDDETopicName . . . . .	437
EditorDDEServiceName . . . . .	438
Example . . . . .	439
<b>C MASM Compatibility</b>	<b>441</b>
Comment Line . . . . .	441
Constants (Integers) . . . . .	441
Operators . . . . .	442
Directives . . . . .	442
<b>D MCUasm Compatibility</b>	<b>445</b>
Labels . . . . .	445
SET directive . . . . .	445
Obsolete directives . . . . .	446
<b>Index</b>	<b>447</b>

# Using the HC(S)08/RS08 Assembler

This document explains how to effectively use the HC(S)08/RS08 Macro Assembler.

## Highlights

The major features of the HC(S)08/RS08 Assembler are:

- Graphical User Interface
- On-line Help
- 32-bit Application
- Conforms to the Freescale Assembly Language Input Standard

## Structure of this document

This section has the following chapters:

- [“Working with the Assembler” on page 17](#): A tutorial using the CodeWarrior Development Studio to create and configure an assembly-code project. In addition, there is a description of using the Assembler and the Linker as standalone Build Tools.
- [“Assembler Graphical User Interface” on page 89](#): A description of the Macro Assembler’s Graphical User Interface (GUI)
- [“Environment” on page 115](#): A detailed description of the Environment variables used by the Macro Assembler
- [“Files” on page 137](#): A description of the input and output file the Assembler uses or generates.

- [“Assembler Options” on page 143](#): A detailed description of the full set of assembler options
- [“Sections” on page 241](#): A description of the attributes and types of sections
- [“Assembler Syntax” on page 249](#): A detailed description of the input syntax used in assembly input files.
- [“Assembler Directives” on page 299](#): A list of every directive that the Assembler supports
- [“Macros” on page 371](#): A description of how to use macros with the Assembler
- [“Assembler Listing File” on page 377](#): A description of the assembler output files
- [“Mixed C and Assembler Applications” on page 383](#): A description of the important issues to be considered when mixing both assembly and C source files in the same project
- [“Make Applications” on page 395](#): A description of special issues for the linker
- [“How to ...” on page 397](#): Examples of assembly source code, linker PRM, and assembler output listings.

In addition to the chapters in this section, there are the following chapters of Appendices

- [“Global Configuration File Entries” on page 419](#): Description of the sections and entries that can appear in the global configuration file - `mcutools.ini`
- [“Local Configuration File Entries” on page 429](#): Description of the sections and entries that can appear in the local configuration file - `project.ini`
- [“MASM Compatibility” on page 441](#): Description of extensions for compatibility with the MASM Assembler
- [“MCUasm Compatibility” on page 445](#): Description of extensions for compatibility with the MCUasm Assembler



# Working with the Assembler

---

This chapter is primarily a tutorial for creating and managing HC(S)08/RS08 assembly projects with the CodeWarrior Development Studio. In addition, there are directions to utilize the Assembler and Smart Linker Build Tools in the CodeWarrior Development Studio for assembling and linking assembly projects.

## Programming Overview

In general terms, an embedded systems developer programs small but powerful microprocessors to perform specific tasks. These software programs for controlling the hardware is often referred to as firmware. One such use for firmware might be controlling small stepping motors in an automobile seat.

The developer instructs what the hardware should do with one or more programming languages, which have evolved over time. The three principal languages in use to program embedded microprocessors are C and its variants, various forms of C++, and assembly languages which are specially tailored to families of microcontrollers. C and C++ have been fairly standardized through years of use, whereas assembly languages vary widely and are usually designed by semiconductor manufacturers for specific families or even subfamilies of their embedded microprocessors.

Assembly language instructions are considered as being at a lower level (closer to the hardware) than the essentially standardized C instructions. Programming in C may require some additional assembly instructions to be generated over and beyond what an experienced developer could do in straight assembly language to accomplish the same result. As a result, assembly language programs are usually faster to execute than C instructions, but require much more programming effort. In addition, each chip series usually has its own specialized assembly language which is only applicable for that family (or subfamily) of CPU derivatives.

Higher-level languages like C use compilers to translate the syntax used by the programmer to the machine-language of the microprocessor, whereas assembly language uses assemblers. It is also possible to mix assembly and C source code in a single project. See the [Mixed C and Assembler Applications](#) chapter.

This manual covers the Assembler dedicated to the Freescale 8-bit HC(S)08 series of microcontrollers. There is a companion manual for this series that covers the HC(S)08 Compiler.

The HC(S)08 Assembler can be used as a transparent, integral part of the CodeWarrior Development Studio. This is the recommended way to get your project up and running in minimal time. Alternatively, the Assembler can also be configured and used as a standalone macro assembler as a member of Build Tool Utilities such as a (Smart) Linker, Compiler, ROM Burner, Simulator or Debugger, etc.

The typical configuration of an Assembler is its association with a [Project directory on page 18](#) and an [External Editor on page 18](#). CodeWarrior uses the project directory for storing the files it creates and coordinates the various tools integrated into the

## Working with the Assembler

*Using CodeWarrior to manage an assembly language project*

---

CodeWarrior suite. The Assembler is but one of these tools that CodeWarrior coordinates for your projects. The tools used most frequently within CodeWarrior are its Editor, Compiler, Assembler, Linker, the Simulator/Debugger, and Processor Expert. Most of these “Build Tools” are located in the *prog* subfolder of the CodeWarrior installation. The others are directly integrated into the CodeWarrior Development Studio

The textual statements and instructions of the assembly-language syntax are written by editors. CodeWarrior has its own editor, although any external text editor can be used for writing assembly code programs. If you have a favorite editor, chances are that it can be configured so as to provide both error and positive feedback from either CodeWarrior or the standalone Assembler.

## Project directory

A project directory contains all of the environment files that you need to configure your development environment.

In the process of designing a project, you can either start from scratch by making your own Source code, configuration (\* .ini), and various layout files for your project for use with standalone project-building tools. This was how embedded microprocessor projects were developed in the recent past. On the other hand, you can have the CodeWarrior IDE coordinate and manage the entire project. This is recommended because it is easier and faster than employing standalone tools. However, you can still utilize any of the Build Tools in the CodeWarrior suite.

## External Editor

CodeWarrior reduces programming effort because its internal editor is configured with the Assembler to enable error feedback. You can use the *Configuration* dialog box of the standalone Assembler or other standalone Build Tools in CodeWarrior to configure or to select your choice of editors. Please refer to the [Editor Setting dialog box](#) section of this manual.

# Using CodeWarrior to manage an assembly language project

CodeWarrior has an integrated Wizard to easily configure and manage the creation of your project. The Wizard will get your project up and running in short order by following a short series of steps to create and coordinate the project and to generate the basic files that are located in the project directory.

This section will create a basic CodeWarrior project that uses assembly source code. A sample program is included for a project created using the Wizard. For example, the program included for an assembly project calculates the next number in a Fibonacci series. It is much easier to analyze any program if you already have some familiarity with solving the result in advance.

In case you did not know, a Fibonacci series is a mathematical infinite series that is very easy to visualize ([Listing 1.1 on page 19](#)):

**Listing 1.1 Fibonacci series**

---

```
0, 1, 1, 2, 3, 5, 8, 13, 21, 34, 55, 89, ... to infinity-->
```

---

It is simple to calculate the next number in this series. The first calculated result is actually the third number in the series because the first two numbers make up the starting point: 0 and 1. The next term in a Fibonacci series is the sum of the preceding two terms. The first sum is then:  $0 + 1 = 1$ . The second sum is  $1 + 1 = 2$ . The sixth sum is  $5 + 8 = 13$ . And so on to infinity.

Let's now rapidly create a project with CodeWarrior and analyze the assembly source and the Linker's parameter files to calculate a Fibonacci series for a particular 8-bit microprocessor in the Freescale HC(S)08 family - the *MC68HC908GP32*. Along the way, some CodeWarrior tips demonstrate how CodeWarrior could help manage your projects.

## The Wizard

Start the HC(S)08/RS08 Codewarrior IDE application. Its path is:

```
<CodeWarrior installation folder>\bin\IDE.exe)
```

After CodeWarrior opens, press the *Create New Project* button. If CodeWarrior is already running, select *New...* from the *File* menu (*File > New...*). See [Figure 1.1 on page 19](#).

**Figure 1.1 Startup dialog box**




## Working with the Assembler

Using CodeWarrior to manage an assembly language project

---

Press the *Create New Project* button. The *HC(S)08 New Project* dialog box appears, showing the *Project Parameters* panel of the *Wizard Map*. If CodeWarrior is already open, select *New...* from the *File* menu (*File > New...*). The *HC(S) New Project* dialog box appears ([Figure 1.2 on page 20](#)).

Figure 1.2 HC(S)08 New Project dialog box



Enter the *Project Parameters* of the *Wizard Map* for your project. For the programming language, check *Assembly* and uncheck both *C* and *C++*. Type the name for the project in the *Project name:* text box. In the event that you want another location for the project directory than the default in the *Location:* text box, press *Set...* and browse to the new location. There is no need to first prepare an empty folder, as CodeWarrior automatically creates its own folder - the *project directory*.

---

**NOTE** If you do not use the default *Location* for the project directory, you need not enter a name in the *Project name:* text box. Whatever you enter in the *File name:* text box will be entered into *Location* automatically.


---

CodeWarrior uses the default *\*.mcp* extension, so you do not have to explicitly append any extension to the filename.

Press the *Save* and *Next >* buttons to close the dialog boxes.

The *Device and Connection* dialog box of the *Wizard Map* appears ([Figure 1.3 on page 21](#)).

**Figure 1.3 Device and Connection dialog box**




Select the desired CPU derivative for the project. Expand *HC08* and *G Family*. In this case, the *MC68HC908GP32* derivative is selected. For *Connections*, select the default - *Full Chip Simulation*. Press *Next >*. The *Add Additional Files* dialog box appears ([Figure 1.4 on page 22](#)).

## Working with the Assembler

Using CodeWarrior to manage an assembly language project

---


Figure 1.4 Add Additional Files dialog box



If you wanted to add any existing files to your project, you could browse in the left panel - *Add existing files to the project* - for the files and press the *Add* button. The added files would then appear in the right panel - *Project Files*. No user files are to be added for this project, so you can either uncheck the *Copy files to project* check box or make sure that no files are selected and leave this check box checked.

Check the *Create main template file* check box. This enables template files including a `main.asm` file in the `Sources` subfolder to be created in the project directory (ABC, in this case) with some sample assembly-source code. Press *Next >*. The *Processor Expert* panel appears ([Figure 1.5 on page 23](#)).

**Figure 1.5 Processor Expert dialog box**



The default - *None* - is selected. For this simple demo project, you do not need the Rapid Application Development (RAD) tool - *Processor Expert* - in the CodeWarrior Development Studio. A basic demo assembly language project is being created. In practice, you would probably routinely use Processor Expert on account of its many advantages.


Press *Finish* >. The Wizard now creates the project ([Figure 1.6 on page 24](#)).

## Working with the Assembler

Using CodeWarrior to manage an assembly language project

---


Figure 1.6 The CodeWarrior project is being created...



Using the Wizard, an HC(S)08 project is set up in a matter of a minute or two. You can add additional components to your project afterwards. A number of files and folders are automatically generated in the root folder that was used in the project-naming process. This folder is referred to in this manual as the project directory. The major GUI component for your project is the project window. The CodeWarrior project window appears ([Figure 1.7 on page 25](#)).




**Figure 1.7 CodeWarrior project window**



If you expand the three “folder” icons, actually groups of files, by clicking in the CodeWarrior project window, you could view some of the files that CodeWarrior created. In general, any files in the project window with red check marks will remain checked until they are successfully assembled, compiled, or linked. At this final stage of the Wizard, you could safely close the project and you can reopen it later. A CodeWarrior project reopens in the same configuration it had when it was last saved ([Figure 1.8 on page 25](#)).

**Figure 1.8 Project window showing some of the files that the Wizard created**



You should examine the types and location of folders and files that CodeWarrior created in the actual project directory so that you know their location if you later configure the Assembler. If you work with standalone tools such as a Compiler, Linker, Simulator/

## Working with the Assembler


Using CodeWarrior to manage an assembly language project

---

Debugger, etc., you may need to specify the paths to these files. So it is helpful to know their typical locations and functions.

You could use the Windows Explorer ([Figure 1.9 on page 26](#)) to examine the actual folders and files that CodeWarrior created for your project and displays in the project window above. The name and location of the project directory are what you selected when creating the project using the Wizard.


**Figure 1.9 Project directory in Windows Explorer**



The project directory holds a total of six subfolders and 15 files at this point. The major file for any CodeWarrior project is its `<project_name>.mcp` file. This is the file you can use to reopen your project.

Return back to the CodeWarrior project window. Double-click on the main.asm file in the *Sources* group. The editor in CodeWarrior opens the main.asm file ([Figure 1.10 on page 27](#)).

**Figure 1.10** Sample main.asm file in the project



```
*****
;* This stationery serves as the framework for a user application. *
;* For a more comprehensive program that demonstrates the more *
;* advanced functionality of this processor, please see the *
;* demonstration applications, located in the examples *
;* subdirectory of the "Freescale CodeWarrior for HC08" program *
;* directory. *
*****

; export symbols
XDEF _Startup, main
; we use export 'Entry' as symbol. This allows us to
; reference 'Entry' either in the linker .prm file
; or from C/C++ later on

XREF __SEG_END_SSTACK ; symbol defined by the linker for

; Include derivative-specific definitions
INCLUDE 'derivative.inc'

; variable/data section
MY_ZEROPAGE: SECTION SHORT ; Insert here your data definition
Counter: DS.B 1
FiboRes: DS.B 1

; code section
MyCode: SECTION
main:
_Startup:
    LDHX #__SEG_END_SSTACK ; initialize the stack pointer
    TXS
    CLI ; enable interrupts

mainLoop:
    CLRA ; A contains counter

cntLoop:
    CBEQA #14,mainLoop ; larger values cause overflow.
    feed_watchdog
    STA Counter ; update global.
    BSR CalcFibo
    STA FiboRes ; store result
```


You can use this sample main.asm file as a base to rewrite your own assembly source program. Otherwise, you can import other assembly-code files into the project and delete the default main.asm file from the project. For this project, the main.asm file contains the sample Fibonacci program.

As a precaution, you can see if the project is configured correctly and if the source code is free of syntactical errors. It is not necessary that you do so, but you should make (build) the default project that CodeWarrior just created. Either press the *Make* button from the toolbar or select (*Project > Make*) from the *Project* menu. All of the red check marks will disappear after a successful building of the project ([Figure 1.11 on page 28](#)).

## Working with the Assembler


Using CodeWarrior to manage an assembly language project

Figure 1.11 Project window after a successful build



If you checked the project directory after the first successful build (make) of the project with the Windows Explorer, you would see that another subfolder and four additional files were created ([Figure 1.12 on page 28](#)).

Figure 1.12 main.o file generated...



The new subfolder - *ObjectCode* - holds an object file for every assembly source-code file that is assembled. In this case, the `main.asm.o` object-code file was generated.

## Analysis of groups and files in the project window

There are three default groups for this holding this project's files. It really does not matter in which group a file resides as long as that file is somewhere in the project window. A file does not even have to be in any group. The groups do not correspond to any physical folders in the project directory. They are simply present in the project window for conveniently grouping files anyway you choose. You can add, rename, or delete files or groups, or you can move files or groups anywhere in the project window.

### CodeWarrior groups

These groups and their usual functions are:

- Sources

This group contains the assembly source code files.

- Includes

This group holds include files. One include file is for the particular CPU derivative. In this case, the `MC68HC908GP32.inc` file is for the MC68HC908GP32 derivative.

- Project Settings

- Linker Files

This group holds the burner file, the Linker PRM file, and the Linker mapping file.

---

**NOTE** The default configuration of the project by the Wizard does not generate an assembler output listing file for every `*.asm` source file. However, you can afterwards select the *Generate a listing file* in the assembler options for the Assembler to generate a format-configurable listing file of the assembly source code (with the inclusion of include files, if desired). Assembler listing files (with the `*.lst` file extension) are located in the *bin* subfolder in the project directory when `*.asm` files are assembled with this option set.

---

**TIP** To set up your project for generating assembler output listing files, select: *Edit > <target\_name> Settings... > Target > Assembler for HC08 > Options > Output*. (The default `<target_name>` is `Standard`.) Check *Generate a listing file*. If you want to format the listing files differently than the default, check *Configure listing file* and make the desired options. You can also add these listing files to the project window for easier viewing instead of having to continually hunt for them. For example, you might add the listing files to the *Sources* group in order to have them near the assembly source files in the project window.

---

## Working with the Assembler

*Analysis of groups and files in the project window*


---

This initial building of your project shows whether it is created and configured correctly. Now you can utilize some of CodeWarrior's features for managing your project. One useful feature is the creation of additional build targets for your projects. You can use multiple targets to have additional subprojects, each with its own files and configuration. However, it is not at all necessary to use multiple build targets and renaming files and groups in CodeWarrior, so you might skip the following sections about some CodeWarrior project-management features and resume the Assembler part of this tutorial at ["Writing your assembly source files" on page 43](#).

## Creating a Target

The Wizard created one target which is named *Standard*. You can check this out for yourself by double-clicking on the *Targets* tab in the project window. The *Targets* panel appears ([Figure 1.13 on page 30](#)).

**Figure 1.13** Targets panel




Creating another build target is easy. Select *Project > Create Target...* (If *Create Target...* is grayed in the *Project* menu, click once on the project window and try again.) The *New Target* dialog box appears ([Figure 1.14 on page 31](#)).

**Figure 1.14** New Target dialog box



Enter the name for the new target and select either of the two options. The *Clone existing target:* option should be used if you plan on using any material from the existing (*Standard*) build target. You can later delete whatever you do not want. Press *OK*. Now there is another build target for your project ([Figure 1.15 on page 31](#)).

**Figure 1.15** Two build targets are now available



You can use the new target by clicking its icon so that the black arrow is attached to it and then select the *Files* tab. The project window now lists the files used for the new build target. In practice, a number of these files will be the same cloned files used by the other targets, but you can add or delete files as with any build target. You can also select which target is the default upon opening the project by selecting *Project > Set Default Target*.

This project just cloned the default *Standard* build target without changing the configuration. That does not do much at this point but to change the `<target_name>`. So let's create a subfolder in the *Sources* folder and include another `main.asm` file that you can use for your new build target. If you do not create another `main.asm` file in

## Working with the Assembler

### Analysis of groups and files in the project window

---


a separate folder, any changes to the original `main.asm` file would affect all build targets.

**NOTE** In practice, you would rename the files that are not common with files in other build targets to some unique filename for each build target. We will rename them later after you see what might occur when common filenames are used for files that differ among build targets.

---

One way to have a separate assembler-source file for each project is to remove the original `main.asm` file from the project (both build targets simultaneously) and then add the appropriate `main.asm` file back into each build target. In either build target, right-select the `main.asm` file and select *Remove* from the right-context menu ([Figure 1.16 on page 32](#)).

**Figure 1.16** Removing the original `main.asm` file simultaneously from all build targets




A *Freescale CodeWarrior* dialog box appears, asking if you want to remove this file from the project. Press *OK*. The `main.asm` file is now removed from all build targets. However, the `main.asm` still remains in the `Sources` folder in the project directory.

From Windows Explorer, create new subfolders, one for each build target, in the `Sources` folder. You may name them as you choose, but you should use a meaningful name, such as the same name as the appropriate build target. Then cut the `main.asm` file from the `Sources` folder and paste it into every build target's folder ([Figure 1.17 on page 33](#)).




**Figure 1.17** Project directory with a separate main.asm source file for each build target



Now the appropriate main.asm file is added to each build target. In the *Project* menu, select the *Sources* group for any of the build targets and then select *Add Files....* The *Select files to add...* dialog box appears ([Figure 1.18 on page 33](#)).

**Figure 1.18** Select files to add... dialog box




Select the appropriate folder for the build target, press *Open*, and select the main.asm file. Press *Open* again. The *Add Files* dialog box appears ([Figure 1.19 on page 34](#)).

## Working with the Assembler

Analysis of groups and files in the project window

---

Figure 1.19 Add Files dialog box



The figure above would be used for the *Alpha 0.1* build target. Deselect the original build target (*Standard*) and keep the new build target (*Alpha 0.1*) checked. Press *OK*. The `main.asm` file is now added to the *Alpha 0.1* build target. Repeat this procedure for adding the `main.asm` to the remaining build target.


Now you can modify a `main.asm` file for one build target without its adversely affecting the other build targets. You could repeat this procedure for any other files in the project that would be different for other build targets. However, you should not do this for those files that are common to all build targets.

---

**NOTE** The `main.asm` file was added to each build target, but only one of them is active. The inactive `main.asm` file will have n/a entries for the *Code* and *Data* columns in the project window ([Figure 1.20 on page 35](#)).


---

Figure 1.20 Project window showing active and inactive main.asm files



So far you have not yet used the editor for this project. For one of the build targets, say the *Alpha 0.1*, double click on the active `main.asm` file in the project window. This file opens. Adjust the mode of the `main.asm` file's window so as to have a comfortable view. One way is to choose the Docked-window option. Right-click on the title bar for the `main.asm` file and select *Docked* in the right-context menu ([Figure 1.21 on page 35](#)).

Figure 1.21 Docked-window option for the main.asm file




## Working with the Assembler

Analysis of groups and files in the project window

The docked-window view could be adjusted so as to appear as in [Figure 1.22 on page 36](#).


**Figure 1.22** Docked-window view for the main.asm file and project window



Now you can modify the main.asm file in a minor manner. Let's add a NOP instruction after the CLI instruction. Place the cursor at the end of the comment in the CLI

instruction line and press *Enter* on the keyboard. Type *NOP* and press *Enter* once more (Figure 1.23 on page 37).

**Figure 1.23** Modified main.asm file



```
KDEF _Startup, main
; we use export 'Entry' as symbol. This allows us to
; reference 'Entry' either in the linker .prm file
; or from C/C++ later on

XREF __SEG_END_SSTACK ; symbol defined by the linker for

; Include derivative-specific definitions
INCLUDE 'derivative.inc'

; variable/data section
MY_ZEROPAGE: SECTION SHORT ; Insert here your data definition
Counter: DS.B 1
FiboRes: DS.B 1

; code section
MyCode: SECTION
main:
_Startup:
    LDHX #__SEG_END_SSTACK ; initialize the stack pointer
    TXS
    CLI ; enable interrupts
    NOP

mainLoop:
    CLRA ; A contains counter
cntLoop:
    INCA
```

Line 34 Col 16

There are numerous ways to save any changes made by the editor to the main.asm file. Some of these are:

- Pressing the *Save* icon on the Toolbar
- Selecting *File > Save* or entering *Ctrl+S* with the keyboard.
- Selecting *Project > Check Syntax (Ctrl+;)*. This also checks the syntax for the main.asm file, as the name for the command suggests.
- Selecting *Project > Compile (Ctrl+F7)* or pressing the *Compile* icon on the Toolbar. This also checks the syntax, assembles the main.asm file, and produces a main.asm.o object-code file in the bin folder in the project directory, if successful.
- Selecting *Project > Bring Up To Date (Ctrl+U)*. If successful, this does everything that *Compile* does plus assembling multiple assembly-code files. In addition, each

## Working with the Assembler

Analysis of groups and files in the project window

---


file with a red check mark is processed. However, no executable output (\*.abs) file is generated.

- Selecting *Project > Make (F7)* or pressing *Make* on any of the two Toolbars. This effects all the functions that *Bring Up To Date* does in addition to generating an executable \*.asm file in the bin folder, if successful
- Selecting *Project > Debug (F5)* or pressing the *Debug* icon on any of the two Toolbars. This does everything that *Make* does in addition to starting the Simulator/Debugger Build Tool (hiwave.exe in the prog folder in the CodeWarrior installation folder), if successful.

## Generating Listing Files


It was mentioned previously that the assembler output listing files were not generated without making configuration changes for the build target. Generating a listing file is easy to set up using Assembler options. Select *Edit > <target\_name> Settings > Target > Assembler for HC08*. The *Assembler for HC08* preference panel opens ([Figure 1.24 on page 38](#)).

Figure 1.24 Assembler for HC08 preference panel



Press *Options*. The *HC08 Assembler Option Settings* dialog box opens ([Figure 1.25 on page 39](#)).

Figure 1.25 HC08 Assembler Option Settings dialog box



Check *Generate a listing file* and also *Do not print included files in listing file* (unless you actually want to view the sometimes lengthy include files). Press *OK* twice to close the dialog box and the preference panel. Then repeat this procedure for the remaining build targets. With these options set, the Assembler will generate a listing file in the `bin` folder for all `*.asm` files for each build target. The filename for this listing file is the same as the `*.asm` file, but with the `*.lst` file extension.

Using the same filename for the `main.asm` file for all build targets causes a problem for the assembler output listing file. To which `main.asm` file does the `main.lst` listing file correspond? You could eliminate this confusion by choosing a unique filename for the `main.asm` file for each build target. However, using the poor practice of using common filenames for files that differ in other build targets was done intentionally so that:

- You could see the confusion it causes with listing files.
- This allows you to employ another CodeWarrior functionality - renaming files.

## Renaming files

It is possible to change the name of a file in the project window, add it to the project, and remove the former file from the project window simultaneously.


## Working with the Assembler

### Analysis of groups and files in the project window

---

Double-click on the active `main.asm` file's icon in the project window. The editor opens that file. Select *File > Save as...*. The *Save As* dialog box appears ([Figure 1.26 on page 40](#)).

**Figure 1.26** Save As dialog box



Enter the new filename in the *Object name:* text box. Press *Save*. Close the open file by selecting *File > Close* or by pressing the *Close* button in the Title bar of the open file. Now:

- The new filename (e.g., `main_Standard.asm`) replaces the former filename in the project window for all build targets.
- A file with the new filename is created in the folder selected in the *Save As* dialog box `<project_name> \<all_source-files> \<build_target>`, or in this case: `ABC\Sources\Standard`.

However, the original file still exists in its folder with its original filename.

You can use this procedure for renaming other files in the project window:

- Open the file in the project window that you want to rename.
- Select *File > Save As...*
- Browse for the folder in which to store the new file.
- Enter a new filename. Press *Save*.

Renaming a filename in this manner simultaneously removes the older file from and imports the newer file into the project (window). Repeat this procedure for the other build targets. You can delete the two unneeded `main.asm` files from the two subfolders, if you choose, as they now longer are involved with the project. You could also delete the `main.lst` listing file and the `main.dbg` file from the `bin` folder if any of them is present.

If you build any of the two build projects from this point, a unique listing file is generated for each build target in the `bin` folder.



## Creating a new group


From the *Project* menu, select *Create Group...* The *Create Group* dialog box appears ([Figure 1.27 on page 41](#)).

Figure 1.27 Create Group dialog box



Enter a name for the new group in the *Enter name for new group:* text box. Press *OK*. The new group appears in the project window ([Figure 1.28 on page 41](#)).

Figure 1.28 Project window now has another group




There is only one reason for creating a group: placing one or more files in it. And “Oops!” The group name has an error. But you can rectify that later. Let’s place the two listing files located in the `bin` folder into the new group. (If there are not two listing files - one for each build target, build the build targets until there are two.) Select *Project > Add Files...*

## Working with the Assembler

Analysis of groups and files in the project window


---

Figure 1.29 New group - Select files to add... dialog box



Select the two listing files and press *Open*. The *Add Files* dialog box appears ([Figure 1.30 on page 42](#)).

Figure 1.30 New group - Add Files dialog box



Check all of the build targets - the default. Press *OK*. Now the listing files are conveniently grouped into the new group in the project window.

## Renaming groups in the project window

In addition to the ease in changing your *Target Name* or renaming files in the project window, you can also rename any of the groups in the project window.


Double-click on the misnamed group - *Bad Nam*. The *Rename Group* dialog box appears (Figure 1.31 on page 43).

Figure 1.31 Rename Group dialog box



Enter a new name for the group and press *OK*. The group name is now changed in the project window (Figure 1.32 on page 43).

Figure 1.32 Project window with the renamed group



## Writing your assembly source files

Once your project is configured, you can start writing your application's assembly source code and the Linker's PRM file.

**NOTE** You can write an assembly application using one or several assembly units. Each assembly unit performs one particular task. An assembly unit is comprised of an assembly source file and, perhaps, some additional include

## Working with the Assembler

### Analyzing the project files

---

files. Variables are exported from or imported to the different assembly units so that a variable defined in an assembly unit can be used in another assembly unit. You create the application by linking all of the assembly units.

---

The usual procedure for writing an assembly source-code file is to use the editor that is integrated into CodeWarrior. You can begin a new file by pressing the *New Text File* icon on the Toolbar to open a new file, write your assembly source code, and later save it with a \*.asm file extension using the *Save* icon on the Toolbar to name and store it wherever you want it placed - usually in the *Sources* folder.

After the assembly-code file is written, it is added to the project using the *Project* menu. If the source file is still open in the project window, select the *Sources* group icon in the project window, single click on the file that you are writing, and then select *Project > Add <filename> to Project*. The newly created file is added to the *Sources* group in the project. If you do not first select the destination group's icon (for example, *Sources*) in the project window, the file will probably be added to the bottom of the files and groups in the project window, which is OK. You can drag and drop the icon for any file wherever you want in the project window.

## Analyzing the project files

We will analyze the default main.asm file that was generated when the project was created with the *Wizard*. [Listing 1.2 on page 44](#) is the default but renamed main\_Standard.asm file that is located in the *Sources* folder created by the *Wizard*. This is the assembler source code for the Fibonacci program.

### Listing 1.2 main\_Standard.asm file

---

```
;*****
;* This stationery serves as the framework for a user application. *
;* For a more comprehensive program that demonstrates the more   *
;* advanced functionality of this processor, please see the       *
;* demonstration applications, located in the examples            *
;* subdirectory of the "Freescale CodeWarrior for HC08" program  *
;* directory.                                                     *
;*****

; export symbols
    XDEF _Startup, main
    ; we use export 'Entry' as symbol. This allows us to
    ; reference 'Entry' either in the linker .prm file
    ; or from C/C++ later on

    XREF __SEG_END_SSTACK    ; symbol defined by the linker
                           ; for the end of the stack

Include derivative-specific definitions

INCLUDE 'derivative.inc'
```

---

```
; variable/data section
MY_ZEROPAGE: SECTION SHORT           ; Insert here your data definition
Counter:    DS.B    1
FiboRes:    DS.B    1

; code section
MyCode:     SECTION
main:
_Startup:
    LDHX    #__SEG_END_SSTACK ; initialize the stack pointer
    TXS
    CLI                    ; enable interrupts
mainLoop:
    CLRA                    ; A contains counter
cntLoop:
    INCA
    CBEQA  #14,mainLoop    ; larger values cause overflow.
    feed_watchdog
    STA    Counter        ; update global.
    BSR    CalcFibo
    STA    FiboRes        ; store result
    LDA    Counter
    BRA    cntLoop        ; next round.
; Function to calculate fibonacci numbers. Argument is in A.
CalcFibo:
    DBNZA  fiboDo          ; fiboDo
    INCA
    RTS
fiboDo:
    PSHA                    ; the counter
    CLRX                    ; second last = 0
    LDA    #$01            ; last = 1
FiboLoop:
    PSHA
    ADD    1,SP
    PULX
    DBNZ  1,SP,FiboLoop
FiboDone:
    PULH                    ; release counter
    RTS                    ; result in A

;*****
spurious - Spurious Interrupt Service Routine.          *
;*              (unwanted interrupt)                  *
;*****
spurious:
    NOP                    ; placed here so that security value
    RTI                    ; does not change all the time.
```

## Working with the Assembler

Analyzing the project files

---

```
;*****  
;*                               Interrupt Vectors                               *  
;*****  
      ORG     $FFFA  
  
      DC.W   spurious           ;  
      DC.W   spurious           ; SWI  
      DC.W   _Startup           ; Reset
```

---

Since the RS08 memory map is different from the HC08 one (and so is the instruction set), [Listing 1.3 on page 46](#) shows a similar example for RS08.

---

**NOTE** In order to assemble files for the RS08 derivative the option `-Crs08` should be passed to the assembler. This can be done either directly (in the command line or in the assembler command bar) or by choosing the “Code generation” tab from the assembler options menu. Then select the “Derivative family” option and enable the RS08 Derivative Family radio button.

---

### Listing 1.3 Contents of Example File `test_rs08.asm`

---

```
      XDEF Entry ; Make the symbol entry visible for external module  
                ; This is necessary to allow the linker to find the  
                ; symbol and use it as the entry point for the  
                ; application.  
cstSec: SECTION ; Define a constant relocatable section  
var1: DC.B 5 ; Assign 5 to the symbol var1  
dataSec: SECTION ; Define a data relocatable section  
data: DS.B 1 ; Define one byte variable in RAM  
codeSec: SECTION ; Define a code relocatable section  
Entry:  
      LDA var1  
main:  
      INCA  
      STA data  
      BRA main
```

---

When writing your assembly source code, pay special attention to the following:

- Make sure that symbols outside of the current source file (in another source file or in the linker configuration file) that are referenced from the current source file are externally visible. Notice that we have inserted the assembly directive `"XDEF _Startup, main"` where appropriate in the example.

- In order to make debugging from the application easier, we strongly recommend that you define separate sections for code, constant data (defined with DC) and variables (defined with DS). This will mean that the symbols located in the variable or constant data sections can be displayed in the data window component.
- Make sure to initialize the stack pointer when using BSR or JSR instructions in your application. The stack can be initialized in the assembly source code and allocated to RAM memory in the Linker parameter file, if a \*.prm file is used.

---

**NOTE** The default assembly project using the Wizard with CodeWarrior initializes the stack pointer automatically with a symbol defined by the Linker for the end of the stack "`__SEG_END_SSTACK`".

---

---

**NOTE** For the RS08 derivative initializing the stack does not apply.

---

## Assembling your source files

Once an assembly source file is available, you can assemble it. You can either utilize CodeWarrior to assemble the \*.asm files or alternatively you can use the standalone assembler of the build tools in the prog folder in the CodeWarrior installation.

### Assembling with CodeWarrior

CodeWarrior simplifies the assembly of your assembly source code. You can assemble the source code files into object (\*.o) files without linking them by:

- selecting one or more \*.asm files in the project window and then select *Compile* from the *Project* menu (*Project > Compile*). Only \*.asm files that were selected will generate updated \*.o object files.
- selecting *Project > Bring Up To Date*. It is not necessary to select any assembly source files.

The object files are generated and placed into the ObjectCode subfolder in the project directory. The object file (and its path) that results from assembling the main.asm file in the default Code Warrior project is:

```
<project_name>\<project_name>_Data\<build-target_name>\  
ObjectCode\main.asm.o.
```

---

**NOTE** The build-target name can be changed to whatever you choose in the Target Settings preference panel. Select *Edit > <target> Settings... > Target > Target Settings* and enter the revised target name into the *Target Name:* text box. The default Target Name is *Standard*.

---

## Working with the Assembler

### Assembling your source files

---

Or, you can assemble all the \*.asm files and link the resulting object files to generate the executable <target\_name>.abs file by invoking either *Make* or *Debug* from the *Project* menu (*Project > Make* or *Project > Debug*). This results in the generation of the <target\_name>.abs file in the bin subfolder of the project directory.

Two other files generated by CodeWarrior after Linking (*Make*) or *Debug* are:

- <target\_name>.map

This Linker map file lists the names, load addresses, and lengths of all segments in your program. In addition, it lists the names and load addresses of any groups in the program, the start address, and messages about any errors the Linker encounters.

- <target\_name>.abs.s19

This is an S-Record File that can be used for programming a ROM memory.

---

**TIP** The remaining file in the default bin subfolder is the <target\_name>.dbg file that was generated back when the \*.asm file was successfully assembled. This debugging file was generated because a bullet was present in the debugging column in the project window. You can enter (or deselect by toggling) a debugging bullet by clicking at the intersection of the \*.asm file (or whatever other source-code file selected for debugging) and the debugging column in the project window. Whenever the debugger or simulator does not show the file in its *Source* window, check first to see if the debugging bullet is present or not in the project window. The bullet must be present for debugging purposes.

---

---

**TIP** The Wizard does not generate default assembler-output listing files. If you want such listing files generated, you have to select this option: *Edit > <target\_name> Settings > Target > Assembler for HC08 > Options*. Select the *Output* tab in the *HC08 Assembler Option Settings* dialog box. Check *Generate a listing file* and *Do not print included files in list file*. (You can uncheck *Do not print included files in list file* if you choose, but be advised that the include files are usually quite lengthy.) Now a \*.lst file will be generated in the bin subfolder of the project directory whenever a \*.asm file is assembled.

---

---

**TIP** You can add the \*.lst files to the project window for easier viewing. This way you do not have to continually hunt for them with your editor.

---

[Listing 1.4 on page 48](#) shows the main.lst file for this project. The comments are truncated on the far-right edge due to size constraints of the manual's page.

### Listing 1.4 main\_Standard.lst assembler output listing file

---

Freescale HC08-Assembler

---



(c) Copyright Freescale 1987-2005

Abs. Rel.	Loc	Obj. code	Source line
---- ----	-----	-----	-----
1	1		
;*****			
2	2		;* This stationery serves as the fram
3	3		;* For a more comprehensive program t
4	4		;* advanced functionality of this pro
5	5		;* demonstration applications, locate
6	6		;* subdirectory of the "Freescale Cod
7	7		;* directory.
8	8		;*****
9	9		
10	10		; export symbols
11	11		XDEF _Startup, main
12	12		; we use export 'Entry' a
13	13		; reference 'Entry' eithe
14	14		; or from C/C++ later on
15	15		
16	16		XREF __SEG_END_SSTACK ;
17	17		
18	18		; Include derivative-specific d
19	19		INCLUDE 'derivative.inc'
1238	20		
1239	21		; variable/data section
1240	22		MY_ZEROPAGE: SECTION SHORT ;
1241	23	000000	Counter: DS.B 1
1242	24	000001	FiboRes: DS.B 1
1243	25		
1244	26		
1245	27		; code section
1246	28		MyCode: SECTION
1247	29		main:
1248	30		_Startup:
1249	31	000000 45 xxxx	LDHX #__SEG_END_SSTACK
1250	32	000003 94	TXS
1251	33	000004 9A	CLI ;
1252	34		mainLoop:
1253	35	000005 4F	CLRA ;
1254	36	000006 4C	cntLoop: INCA
1255	37	000007 41 0E FB	CBEQA #14,mainLoop ;
1256	38		feed_watchdog
1257	13m	00000A C7 FFFF	+ STACOPCTL
1258	39	00000D B7 xx	STA Counter ;
1259	40	00000F AD 06	BSR CalcFibo
1260	41	000011 B7 xx	STA FiboRes ;

## Working with the Assembler

### Assembling your source files

---

```

1261 42 000013 B6 xx          LDA    Counter
1262 43 000015 20 EF          BRA    cntLoop          ;
1263 44
1264 45                      CalcFibo: ; Function to calculate f
1265 46 000017 4B 02          DBNZA  fiboDo          ;
1266 47 000019 4C             INCA
1267 48 00001A 81             RTS
1268 49                      fiboDo:
1269 50 00001B 87             PSHA                      ;
1270 51 00001C 5F             CLRX                      ;
1271 52 00001D A6 01          LDA    #$01              ;
1272 53 00001F 87             FiboLoop: PSHA            ;
1273 54 000020 9F             TXA
1274 55 000021 9EEB 01        ADD    1,SP
1275 56 000024 88             PULX
1276 57 000025 9E6B 01 F6    DBNZ  1,SP,FiboLoop
1277 58 000029 8A             FiboDone: PULH            ;
1278 59 00002A 81             RTS                      ;
1279 60
1280 61                      ;*****
1281 62                      ;* spurious - Spurious Interrupt Servi
1282 63                      ;*          (unwanted interrupt)

```

Freescale HC08-Assembler  
(c) Copyright Freescale 1987-2005

Abs.	Rel.	Loc	Obj. code	Source line
----	----	-----	-----	-----
1283	64			;*****
1284	65			spurious: ;
1285	66	00002B	9D	NOP ;
1286	67	00002C	80	RTI
1287	68			
1288	69			;*****
1289	70			;*          Interrupt Vectors
1290	71			;*****
1291	72			ORG    \$FFFA
1292	73			
1293	74	a00FFFA	xxxx	DC.W  spurious ;
1294	75	a00FFFC	xxxx	DC.W  spurious
1295	76	a00FFFE	xxxx	DC.W  _Startup ;

---

## Assembling with the Assembler


It is also possible to use the HC(S)08 Assembler as a standalone assembler. If you prefer not to use the assembler but do want to use the Linker, you can skip this section and proceed to [“Linking the application” on page 67](#).

This tutorial does not create another project from scratch with the Build Tools, but instead uses some files of a project already created by the CodeWarrior Wizard. CodeWarrior can create, configure, and manage a project much easier and quicker than using the Build Tools. However, the Build Tools could also create and configure another project from scratch.

A Build Tool such as the Assembler makes use of a project directory file for configuring and locating its input and generated files. The folder that is designated for this purpose is referred to by a Build Tool as the “current directory.”

Start the Assembler. You can do this by opening the `ahc08.exe` file in the `prog` folder in the HC08 CodeWarrior installation. The Assembler opens [\(Figure 1.33 on page 51\)](#).

Figure 1.33 HC08 Assembler opens...



Read any of the Tips if you choose to and then press *Close* to close the *Tip of the Day* dialog box.

## Configuring the Assembler

A Build Tool, such as the Assembler, requires information from configuration files. There are two types of configuration data:

- Global

This data is common to all Build Tools and projects. There may be common data for each Build Tool (Assembler, Compiler, Linker, ...) such as listing the most recent

## Working with the Assembler

### Assembling your source files

---

projects, etc. All tools may store some global data into the `mcutools.ini` file. The tool first searches for this file in the directory of the tool itself (path of the executable). If there is no `mcutools.ini` file in this directory, the tool looks for an `mcutools.ini` file located in the MS WINDOWS installation directory (e.g. `C:\WINDOWS`). See [Listing 1.5 on page 52](#).

#### Listing 1.5 Typical locations for a global configuration file

---

```
\CW installation directory\prog\mcutools.ini - #1 priority  
C:\WINDOWS\mcutools.ini - used if there is no mcutools.ini file above
```

---

If a tool is started in the default location `C:\Program Files\CW08 V5.x\prog` directory, the initialization file in the same directory as the tool is used:

```
C:\Program Files\CW08 V5.x\prog\mcutools.ini.
```

But if the tool is started outside the CodeWarrior installation directory, the initialization file in the Windows directory is used. For example, `C:\WINDOWS\mcutools.ini`.


For information about entries for the global configuration file, see [Global Configuration File Entries](#) in the Appendices.

- Local

This file could be used by any Build Tool for a particular project. For information about entries for the local configuration file, see [Local Configuration File Entries](#) in the Appendices.


After opening the Assembler, you would load the configuration file for your project if it already had one. However, you will create a new configuration file for the project in this tutorial and save it so that when the project is reopened, its previously saved configuration state will be used. From the *File* menu, select *New / Default Configuration*. The *HC08 Assembler Default Configuration* dialog box appears ([Figure 1.34 on page 53](#))

Figure 1.34 HC08 Assembler New / Default dialog box



Now let's save this configuration in a newly created folder that will become the project directory. From the *File* menu, select *Save Configuration As...*. A *Saving Configuration as...* dialog box appears. Navigate to the folder of your choice and Click on the *Create New Folder* icon in the Toolbar. Enter a name for the project directory ([Figure 1.35 on page 53](#)).

Figure 1.35 Loading configuration dialog box




Press *Open*. In this case, `Model T` becomes the project directory in the `Projects` folder. Press *Save* and the `project.ini` file is created in the `Model T` folder and becomes the local configuration file for this project. The current directory for the HC08 Assembler is changed to your project directory ([Figure 1.36 on page 54](#)).

## Working with the Assembler

### Assembling your source files


---

Figure 1.36 Assembler's current directory switches to your project directory...



If you were to examine the project directory with the Windows Explorer at this point, it would only contain the `project.ini` configuration file that the Assembler just created ([Figure 1.37 on page 54](#)).

Figure 1.37 Project directory in Windows Explorer



If you further examined the contents of the `project.ini` configuration file, you would see that it contains Assembler options in the `[AHC08_Assembler]` portion of the file. The `project.ini` file for this project only has an `[AHC08_Assembler]` section ([Listing 1.6 on page 54](#)).

Listing 1.6 Contents of the `project.ini` file

---

```
[AHC08_Assembler]
StatusBarEnabled=1
ToolbarEnabled=1
WindowPos=0,1,-1,-1,-1,-1,66,87,505,453
```


---

EditorType=4

The *AHC08\_Assembler* options are described in detail in [\[XXX Assembler\] Section](#) in the Appendices.

Next, you set the object-file format that you will use (HIWARE or ELF/DWARF). Select *Assembler > Options*. The Assembler displays the *HC08 Assembler Option Settings* dialog box ([Figure 1.38 on page 55](#)).

**Figure 1.38 .HC08 Assembler Option Settings dialog box**



In the *Output* panel, select the check boxes labeled *Generate a listing file* and *Object File Format*. For the *Object File Format*, select the *ELF/DWARF 2.0 Object File Format* in the pull-down menu. The listing file could be much shorter if the *Do not print included files in list file* check box is checked, so you may want to select that option also. Press *OK* to close the *HC08 Assembler Option Settings* dialog box.

---

**NOTE** Note: For the RS08 derivative the *HIWARE Object File Format* is not supported.

---

## Working with the Assembler

### Assembling your source files

---

Save the changes to the configuration by:

- selecting *File > Save Configuration (Ctrl + S)* or
- pressing the *Save* button on the toolbar.

After the changes to the configuration are saved, the project.ini file's contents are as follows ([Listing 1.7 on page 56](#)).

#### Listing 1.7 project.ini file after some assembly options were added

---

```
[AHC08_Assembler]
StatusBarEnabled=1
ToolbarEnabled=1
WindowPos=0,1,-1,-1,-1,-1,66,87,482,269
EditorType=4
Options=-F2 -L=%(TEXTSPATH)\%n.lst -Li
```

---

## Input Files

Now that the project's configuration is set, you can assemble an assembly-code file. However, the project does not contain any source-code files at this point. You could create assembly \*.asm and include \*.inc files from scratch for this project. However, for simplicity's sake, you can copy-and-paste the main\_Standard.asm and the derivative.inc files from the previous CodeWarrior project. For this project you should have a project directory named Model T. Within this folder, you should have another folder named Sources, which contains the two files described above. Using a text editor of your choice, the main\_Standard.asm file should be slightly modified so that it appears as below ([Listing 1.8 on page 56](#)):

#### Listing 1.8 main.asm\_Standard file

---

```
*****
;* This stationery serves as the framework for a user application. *
;* For a more comprehensive program that demonstrates the more *
;* advanced functionality of this processor, please see the *
;* demonstration applications, located in the examples *
;* subdirectory of the "Freescall CodeWarrior for HC08" program *
;* directory. *
*****

; export symbols
    XDEF _Startup, main
    ; we use export '_Startup' as symbol. This allows us to
    ; reference '_Startup' either in the linker .prm file
    ; or from C/C++ later on

    XREF __SEG_END_SSTACK    ; symbol defined by the linker
                           ; for the end of the stack
```

---



```
    Include derivative-specific definitions

    INCLUDE 'derivative.inc'

; variable/data section
MY_ZEROPAGE: SECTION  SHORT           ; Insert here your data definition
Counter:    DS.B    1
FiboRes:    DS.B    1

; code section
MyCode:     SECTION
main:
  _Startup:
        LDHX  #__SEG_END_SSTACK ; initialize the stack pointer
        TXS
        CLI           ; enable interrupts

mainLoop:
        CLRA           ; A contains counter
cntLoop:
        INCA
        CBEQA  #14,mainLoop ; larger values cause overflow.

        STA  Counter   ; update global.
        BSR  CalcFibo
        STA  FiboRes   ; store result
        LDA  Counter
        BRA  cntLoop   ; next round.

; Function to calculate fibonacci numbers. Argument is in A.
CalcFibo:
        DBNZA fiboDo   ; fiboDo
        INCA
        RTS

fiboDo:
        PSHA           ; the counter
        CLRX           ; second last = 0
        LDA  #$01      ; last = 1
FiboLoop:
        PSHA

        ADD  1,SP
        PULX
        DBNZ 1,SP,FiboLoop

FiboDone:
        PULH           ; release counter
        RTS           ; result in A
```

---

Now there are three files in the project ([Figure 1.39 on page 58](#)):

- the `project.ini` configuration file and


## Working with the Assembler

### Assembling your source files

---

- two files in the Sources folder:
  - main\_Standard.asm
  - derivative.inc.


Figure 1.39 Project files



## Assembling the assembly source-code files


Let's assemble the `main_Standard.asm` file. From the *File* menu, select *Assemble*. The *Select File to Assemble* dialog box appears ([Figure 1.40 on page 59](#)).

Figure 1.40 Select Files to Assemble dialog box



Browse to the `Sources` folder in the project directory and select the `main_Standard.asm` file. Press *Open* and the `main.asm` file should start assembling ([Figure 1.41 on page 59](#)).

Figure 1.41 Results of assembling the `main.asm` file...



The project window provides information about the assembly process or generates error messages if the assembly was unsuccessful. In this case an error message is generated - the *A2209 File not found* message. If you right-click on the text containing the error message, a context menu appears ([Figure 1.42 on page 60](#)).

---

**NOTE** If you get any other types of errors, make sure the `main_Standard.asm` file is modified as shown in [Listing 1.8 on page 56](#)


---

## Working with the Assembler

### Assembling your source files


---

Figure 1.42 Context menu



Select *Help on "file not found"* and help for the A2309 error message appears ([Figure 1.43 on page 61](#)).

Figure 1.43 A2309: File not found



You know that the file exists because it is included in the `Sources` folder that you imported into the project directory. The help message for the A2309 error states that the Assembler looks for this “missing” include file first in the current directory and then in the directory specified by the `GENPATH` environment variable. This suggests that the `GENPATH` environment variable should specify the location of the `derivative.inc` include file.

---

**NOTE** If you read the `main.asm` file, you could have anticipated this on account of this statement on line 20: `INCLUDE 'derivative.inc'`.

---


To fix this, select *File > Configuration*. The *Configuration* dialog box appears ([Figure 1.44 on page 62](#)).

## Working with the Assembler

### Assembling your source files


---

**Figure 1.44** Browsing for the Sources folder



Select the *Environment* tab and then *General Path*. Press the “...” button and navigate in the *Browse for Folder* dialog box for the folder that contains the derivative .inc file - the aforementioned *Sources* folder in the project directory. Press *OK* to close the *Browse for Folder* dialog box. The *Configuration* dialog box is now again active ([Figure 1.45 on page 63](#)).

Figure 1.45 Adding a GENPATH



Press the *Add* button, and the path to the derivative `.inc` file “`E:\Projects\Model T\Sources`” now appears in the lower panel. Press *OK*. An asterisk now appears in the Title bar, so save the change to the configuration by pressing the *Save* button in the Toolbar or by selecting *File > Save Configuration*. The asterisk disappears.

---

**TIP** You can clear the messages in the Assembler window at any time by selecting *View > Log > Clear Log*.

---

Now that you have supplied the path to the derivative `.inc` file, let’s attempt again to assemble the `main_Standard.asm` file.

Select *File > Assemble* and again navigate to the `main_Standard.asm` file and press *Open*. However, the `A2309` error message reappears but this time for a different include file - `MC68HC908GP32.inc`. ([Figure 1.46 on page 64](#)).

---

**NOTE** In this case, the derivative `.inc` file has this statement:  
`INCLUDE 'MC68HC908GP32.inc'`. Therefore, a prior reading of the assembly-code and include files would suggest these include files might require GENPATH configurations. Therefore, you should set any needed GENPATH in advance of assembling the source-code files.


---

## Working with the Assembler

### Assembling your source files

---

Figure 1.46 Assemble attempt #2



The screenshot shows the HCO8 Assembler window with the following content:

```
HC08 Assembler E:\Projects\Model T\project.ini
File Assembler View Help
E:\Projects\Model T\Sources\main_Standard.asm
"E:\Projects\Model T\Sources\main_Standard.asm"
Command Line: '-F2 -L=%(TEXTPATH)\%.lst -Li "E:\Projects\Model T\Sources\main_Standard.asm"'
Top: E:\Projects\Model T\Sources\main_Standard.asm
"E:\Projects\Model T\Sources\derivative.inc"
Could not open the file 'MC68HC908GP32.inc'

>> in "E:\Projects\Model T\Sources\derivative.inc", line 5, col 0, pos 184
    INCLUDE 'MC68HC908GP32.inc'
    ^
ERROR A2309: File not found
HC08 Assembler: *** 1 error(s), 0 warning(s), 0 information message(s) ***
*** command line: '-F2 -L=%(TEXTPATH)\%.lst -Li "E:\Projects\Model T\Sources\main_Standard.asm"' ***
HC08 Assembler: *** Error occurred while processing! ***

Processing failed! 05:55:32
```


You fix this by repeating the GENPATH routine for the other include file ([Figure 1.47 on page 65](#)). The MC68HC908GP32 .inc file is located at this path:

```
CW08 V5.x\lib\c08c\include
```

The include folder is the typical place for “missing” include files.




Figure 1.47 Adding another GENPATH



After the GENPATH is set up for the second include file and saved as before, you can try to assemble the `main_Standard.asm` file for the third time ([Figure 1.48 on page 65](#)).

Figure 1.48 Assemble attempt #3 - success!




## Working with the Assembler

### Assembling your source files

The Macro Assembler indicates successful assembling and indicated that the Code Size was 40 bytes. The message “\*\*\* 0 error(s),” indicates that the `main_Standard.asm` file assembled without errors. Do not forget to save the configuration one additional time.

The Assembler also generated a `main_Standard.dbg` file (for use with the Simulator/Debugger), a `main_Standard.o` object file (for further processing with the Linker), and a `main_Standard.lst` output listing file in the project directory. The binary object-code file has the same name as the input module, but with the `*.o` extension - `main_Standard.o`. The debug file has the same name as the input module, but with the `*.dbg` extension - `main_Standard.dbg` and the assembly output listing file has the `*.lst` extension ([Figure 1.49 on page 66](#)).

**Figure 1.49** Project directory after a successful assembly



The `ERR.TXT` file is present in the project directory on account of the earlier failed attempts at assembling. The `ERR.TXT` file is empty upon a successful assembly. You can delete this file. Let's take an additional look at the `project.ini` file ([Figure 1.8 on page 25](#)).

**Listing 1.9** `project.ini` file after `GENPATH` environmental variable is created

```
[AHC08_Assembler]
StatusBarEnabled=1
ToolBarEnabled=1
WindowPos=0,1,-1,-1,-1,-1,66,87,767,535
EditorType=1
Options=-F2 -L=%(TEXTSPATH)\%n.lst -Li
RecentCommandLine0="E:\Projects\Model T\Sources\main_Standard.asm"
CurrentCommandLine="E:\Projects\Model T\Sources\main_Standard.asm"
[Environment Variables]
GENPATH=C:\Program Files\Freescale\CW08 V5.x\
```

```
lib\hc08c\include;E:\Projects\Model T\Sources
OBJPATH=
TEXTPATH=
ABSPATH=
LIBPATH=
```

---

The haphazard running of this project was intentionally designed to fail in order to illustrate what would occur if the path of any include file is not properly configured. Be aware that include files may be included by either \*.asm or \*.inc files. In addition, remember that the lib folder in the CodeWarrior installation contains several derivative-specific include and prm files available for inclusion into your projects.

## Linking the application

Once the object files are available you can link your application. The linker organizes the code and data sections into ROM and RAM memory areas according to the project's linker parameter (PRM) file.

### Linking with CodeWarrior

The Linker's input files are object-code files from assembler and compiler, library files, and the Linker PRM file.

#### PRM file

If you are using CodeWarrior to manage your project, a pre-configured PRM file for a particular derivative is already set up ([Listing 1.10 on page 67](#)). [Listing 1.11 on page 68](#) is an example Linker PRM file for the RS08 derivative.

#### Listing 1.10 Linker PRM file for the GP32 derivative - Project.prm

---

```
/* This is a linker parameter file for the GP32 */

NAMES END /* CodeWarrior will pass all the needed files to the linker
by command line. But here you may add your own files too. */

SEGMENTS /* Here all RAM/ROM areas of the device are listed. Used in
          PLACEMENT below. */
    ROM                =  READ_ONLY      0x8000 TO 0xFDFE;
    Z_RAM              =  READ_WRITE     0x0040 TO 0x00FF;
    RAM                =  READ_WRITE     0x0100 TO 0x023F;
END

PLACEMENT /* Here all predefined and user segments are placed into the
          SEGMENTS defined above. */
    DEFAULT_RAM       INTO  RAM;
```

---

## Working with the Assembler

### Linking the application

---

```
        _DATA_ZEROPAGE, MY_ZEROPAGE      INTO  Z_RAM;
        DEFAULT_ROM, ROM_VAR, STRINGS    INTO  ROM;
END

STACKSIZE 0x50

//VECTOR 0 _Startup      /* Reset vector: This is the default entry
//                          point for a C/C++ application. */
//VECTOR 0 Entry /* Reset vector: this is the default entry point
//                          for an Assembly application. */
//INIT Entry /* For assembly applications: that this is as
//                          well the initialization entry point */
```

---

#### Listing 1.11 Linker PRM file for the RS08 derivative

---

```
LINK test_rs08.abs
NAMES test_rs08.o END
SEGMENTS
    TINY_RAM      = READ_WRITE 0x0000 TO 0x000D;
    DIRECT_RAM    = READ_WRITE 0x0020 TO 0x004F;
    ROM           = READ_ONLY  0x3800 TO 0x3FFB;
    RESET_JMP_AREA= READ_ONLY  0x3FFD TO 0x3FFF;
END

PLACEMENT
    DEFAULT_ROM      INTO ROM;
    DEFAULT_RAM      INTO DIRECT_RAM;

    TINY_RAM_VARS,   INTO TINY_RAM;
    DIRECT_RAM_VARS  INTO DIRECT_RAM;
TINY_RAM;
END

STACKSIZE 0x00 // no stack for RS08

VECTOR 0 Entry
INIT Entry
```


---

The Linker PRM file allocates memory for the stack and the sections named in the assembly source code files. If the sections in the source code are not specifically referenced in the PLACEMENT section, then these sections are included in DEFAULT\_ROM or DEFAULT\_RAM. You may use a different PRM file for each build target instead of the default PRM file generated by the Wizard - Project.prm.

The *Linker for HC08* preference panel controls which PRM file is used for your CodeWarrior project. The default PRM file for a CodeWarrior project is the PRM file in the project window. Let's see what other options exist for the PRM file. From the *Edit*

menu, select <target\_name> Settings... > Target > Linker for HC08. The Linker for HC08 preference panel appears (Figure 1.50 on page 69).

Figure 1.50 Linker for HC08 preference panel



There are three radio buttons for selecting the PRM file and another for selecting an absolute, single-file assembly project:

- *Use Custom PRM file*

This option will browse for an existing PRM file for the build target.

- *Use Template PRM file*

This option uses a template PRM in the pull-down menu and copies it for use in your build target.

- *Use PRM file from project* - the default
- *Absolute, Single-File Assembly project.*

An absolute assembly project does not require a PRM file. Therefore, the configuration information that is otherwise present in a PRM file must be included in a single-file \*.asm file. Only one \*.asm file is allowed for absolute assembly.

In case you want to change the filename of the application, you can determine the filename and its path with the *Application Filename:* text box.

## Working with the Assembler

### Linking the application


---

The 'STACKSIZE' entry is used to set the stack size. The size of the stack for this project is 80 bytes. Some entries in the Linker PRM file may be commented-out by the IDE, as are the three last items in the `Project.prm` file in [Listing 1.10 on page 67](#).

## Linking the object-code files

You can run this relocatable assembly project from the Project menu: Select *Project > Make* or *Project > Debug*. The Linker generates a `*.abs` file and a `*.abs.s19` standard S-Record File in the `bin` subfolder of the project directory. You can use an S-Record File to program ROM memory ([Figure 1.51 on page 70](#)).


**Figure 1.51** bin folder in the project directory in Windows Explorer after linking



The `Project.abs`, `Project.abs.s19`, and `Project.map` files in the Figure above are the Linker output files resulting from the object-code and PRM files and configuration in the build target that is selected in the *Targets* panel in the project window.

The *Full Chip Simulation* option in CodeWarrior was selected when the project was created, so if *Project > Debug* is selected, the debugger opens and you can follow each assembly-code instruction during the execution of the program with the Hiwave Simulator ([Figure 1.52 on page 71](#)).

Figure 1.52 hiwave.exe - Simulator/Debugger build tool



You can single-step the Simulator through the Fibonacci program from the *Run* menu in the Simulator (*Run > Assembly Step* or *Ctrl+F11*). You can monitor the seven panels in the Simulator while following the logic in the Fibonacci application.

## Linking with the Linker

If you are using the Linker (*SmartLinker*) build tool utility for a relocatable assembly project, you will use a PRM file for the Linker to allocate ROM and RAM memory areas.

- Using a text editor, create the project's linker parameter file. You can modify a \*.prm file from another project and rename it as <target\_name>.prm.
- Store the PRM file in a convenient location, such as the project directory.
- In the <project\_name>.prm file, change the name of the executable (\*.abs) file to whatever you choose, e.g., <project\_name>.abs. In addition, you can also modify the start and end addresses for the ROM and RAM memory areas. The module's Model T.prm file — a PRM file for an MC68HC908GP32 from another (CodeWarrior) project was adapted — is shown in [Listing 1.12 on page 72](#).

## Working with the Assembler

### Linking the application

---

#### Listing 1.12 Layout of a PRM file for the Linker - Model T.prm

---

```
/* This is a linker parameter file for the GP32 */

LINK Model_T.abs /* Absolute executable file */
NAMES main_Standard.o /* Input object-code files are listed here. */
END

SEGMENTS /* Here all RAM/ROM areas of the device are listed. Used in
          PLACEMENT below. */
    ROM          = READ_ONLY      0x8000 TO 0xFDFE;
    Z_RAM        = READ_WRITE     0x0040 TO 0x00FF;
    RAM          = READ_WRITE     0x0100 TO 0x023F;
END

PLACEMENT /* Here all predefined and user segments are placed into the
          SEGMENTS defined above. */
    DEFAULT_RAM  INTO RAM;
    _DATA_ZEROPAGE, MY_ZEROPAGE INTO Z_RAM;
    DEFAULT_ROM, ROM_VAR, STRINGS INTO ROM;
END

STACKSIZE 0x50

VECTOR 0 _Startup /* Reset vector: this is the default entry point
                  for an Assembly application. */
INIT _Startup /* For assembly applications: that this is as
              well the initialization entry point */
```

---

**NOTE** If you are adapting a PRM file from a CodeWarrior project, all you really need is adding the LINK portion and adding whatever object-code filenames that are to be linked in the NAMES portion.

---

**NOTE** The default size for the stack using the CodeWarrior Wizard for the GP32 is 80 bytes - (STACKSIZE 0x50). This Linker statement and `__SEG_END_SSTACK` in the assembly-code snippet below determine the size and placement of the stack in RAM:

```
MyCode: SECTION ; code section
main:
_Startup:
    LDHX #__SEG_END_SSTACK ; initialize stack pointer
    TXS
```

---



The statements in the linker parameter file are described in the Linker portion of the Build Tool Utilities manual.


- Start the Linker.

The SmartLinker tool is located in the `prog` folder in the CodeWarrior installation:  
`prog\linker.exe`

- Press *Close* to close the *Tip of the Day* dialog box.
- Load the project's configuration file. Use the same `<project.ini>` file that the Assembler used for its configuration - the `project.ini` file in the project directory:


*File > Load Configuration* and navigate to and select the project's configuration file ([Figure 1.53 on page 73](#)).

Figure 1.53 HC(S)08 Linker




- Press *Open* to load the configuration file. The project directory is now the current directory for the Linker. You should press the *Save* button to save the configuration. From the *File* menu in the Smart Linker, select *Link: (File > Link)*. The *Select File to Link* dialog box appears ([Figure 1.54 on page 74](#)).

**Figure 1.54** Select File to Link dialog box



- Browse to locate and select the PRM file for your project. Press *Open*. The Smart Linker links the object-code files in the NAMES section to produce the executable \* . abs file, as specified in the LINK portion of the Linker PRM file ([Figure 1.55 on page 75](#)).

Figure 1.55 Linker main window after linking



The messages in the linker's project window indicated that:

- The current directory for the Linker is the project directory, E:\Projects\Model T.
- The Model T.prm file was used to name the executable file, which object files were linked, and how the RAM and ROM memory areas were allocated for the relocatable sections. The Reset and application entry points were also specified in this file.
- There was one object file, main\_Standard.o.
- The output format was DWARF 2.0.
- The Code Size was 42 bytes.
- A Linker Map file - Model T.map was generated.
- No errors or warnings occurred and no information messages were issued.


The TEXTPATH environmental variable was not used for this project. Therefore, the Linker generates its \*.map Linker Map file in the same folder that contains the PRM file for the project. Because the ABSPATH environment variable was not used, the \*.abs executable file is generated in the same folder as the Linker PRM file. [Figure 1.56 on page 76](#) shows the contents of the project directory after the relocatable assembly project was linked.

## Working with the Assembler

### Linking the application

---


Figure 1.56 Project directory after linking



The Simulator/Debugger Build Tool, `hiwave.exe`, located in the `prog` folder in the CodeWarrior installation could be used to simulate the program that was assembled using the `main_standard.asm` source-code file and linked to generate the `Model_T.abs` executable.

Start the Simulator. The GUI for the Simulator appears ([Figure 1.57 on page 77](#)).

Figure 1.57 True-Time Simulator & Real-Time Debugger




Select *Set Connection...* from the *Component* menu. The *Set Connection* dialog box appears ([Figure 1.58 on page 78](#))

## Working with the Assembler

### Linking the application


---

Figure 1.58 Set Connection dialog box



The CPU derivative for this project is in the HC08 subfamily, so select *HC08* from the *Processor* pull-down menu. Select *Full Chip Simulation* in the *Connection* pull-down menu. Press *OK*. From the *File* menu, select *Load Application...* The *Load Executable File* dialog box appears ([Figure 1.59 on page 79](#))

Figure 1.59 Load Executable File dialog box




Browse to and select the Model\_T.abs file in the project directory. Press *Open*. The Simulator is now set up to be run ([Figure 1.60 on page 80](#)).

## Working with the Assembler

### Directly generating an ABS file

Figure 1.60 Simulator is now ready



You can repeatedly press the *Assembly Step* (*Ctrl+F11*) icon to single-step the Simulator through the assembly source-code and monitor the program's logic of the Fibonacci application in the eight panels within the Simulator's GUI.

## Directly generating an ABS file

You can also use CodeWarrior or the Assembler build tool to generate an ABS file directly from your assembly-source file. The Assembler may also be configured to generate an S-Record File at the same time.

When you use CodeWarrior or the Assembler to directly generate an ABS file, there is no Linker involved. This means that the application must be implemented in a single assembly unit and must contain only absolute sections.



## Using CodeWarrior to generate an ABS file

You can use the Wizard to produce an absolute assembly project. To do so, you follow the same steps in creating a relocatable-assembly project given earlier. There are some exceptions, however:

- No PRM file is required.
- The memory area allocation is determined directly in a single \*.asm file assembly source file.
- CodeWarrior needs some configurations to be applied to the Linker and Assembler preference panels.

Start the CodeWarrior Wizard and create an assembler project in the usual manner. See [“The Wizard” on page 19](#). Next, convert the main\_Standard.asm relocatable assembly file to the absolute assembly file below in [Listing 1.13 on page 81](#).

## Adapting the main\_Standard.asm file produced by the Wizard

Changing the SECTION directives in a relocatable assembly file to ORG directives is required. The ORG directives must specify the absolute memory areas for ROM and RAM. [Listing 1.13 on page 81](#) is an adaptation of the main\_Standard.asm file produced previously by the Wizard. This file may be used by CodeWarrior or the Assembler build tool.

### Listing 1.13 Example source file — main\_Standard.asm

```
*****
;* This stationery serves as the framework for a user          *
;* application. For a more comprehensive program that         *
;* demonstrates the more advanced functionality of this      *
;* processor, please see the demonstration applications       *
;* located in the examples subdirectory of Codewarrior        *
;* for the HC08 program directory.                             *
*****

; application entry point
      ABSENTRY _Startup
; export symbols
      XDEF _Startup, main
      ; we use '_Startup' as an export symbol. This allows
      ; us to reference '_Startup' either in the linker
      ; *.prm file or from C/C++ later on.

      ; Include derivative-specific definitions
      INCLUDE 'derivative.inc'

; variable/data section
```

## Working with the Assembler

### Directly generating an ABS file

---

```
                ORG    $0040
Counter:        DS.B   1
FiboRes:        DS.B   1

; initial value for SP
initStack:     EQU    $023E

; code section
                ORG    $8000
main:
_Startup:
    LDHX    #initStack    ; initialize the stack pointer
    TXS
    CLI                    ; enable interrupts
mainLoop:
    CLRA                    ; A contains a counter.
cntLoop:
    INCA
    CBEQA   #14,mainLoop   ; Larger values cause overflow.
    STA    COPCTL          ; Feed the watchdog.
    STA    Counter        ; update global
    BSR    CalcFibo
    STA    FiboRes        ; store result
    LDA    Counter
    BRA    cntLoop        ; next round

CalcFibo: ; Function to compute Fibonacci numbers. Argument is in A.
    DBNZA fiboDo          ; fiboDo
    INCA
    RTS

fiboDo:
    PSHA                    ; the counter
    CLRX                    ; second last = 0
    LDA    #$01            ; last = 1
FiboLoop:
    PSHA                    ; push last
    TXA
    ADD    1,SP
    PULX
    DBNZ   1,SP,FiboLoop
FiboDone:
    PULH                    ; release counter
    RTS                    ; Result in A

;*****
;* spurious - Spurious Interrupt Service Routine.          *
;*                (unwanted interrupt)                    *
;*****
spurious:
    NOP                    ; Put here so the security
    RTI                    ; value does not change
                        ; all the time.
```

```
;*****  
;*                Interrupt Vectors                *  
;*****  
                ORG    $FFFA  
                DC.W   spurious          ;  
                DC.W   spurious          ; SWI  
                DC.W   _Startup          ; Reset
```

---

[Listing 1.14 on page 83](#) is a similar example for RS08.

#### Listing 1.14 Example source file abstest\_rs08.asm

---

```
ABSENTRY entry; Specifies the application Entry point  
XDEF entry ; Make the symbol entry visible (needed for debugging)  
                ORG $40 ; Define an absolute constant section  
var1: DC.B 5 ; Assign 5 to the symbol var1  
                ORG $80 ; Define an absolute data section  
data: DS.B 1 ; Define one byte variable in RAM at $80  
                ORG $B00 ; Define an absolute code section  
entry:  
        LDA var1  
main:  
        INCA  
        STA data  
        BRA main
```

---

When writing your assembly source file for direct absolute file generation, pay special attention to the following points:

- The Reset vector is usually initialized in the assembly source file with the application entry point. An absolute section containing the application's entry point address is created at the reset vector address. To set the entry point of the application at address \$FFFA on the \_Startup label the following code is needed ([Listing 1.15 on page 83](#)).

#### Listing 1.15 Setting the Reset vector address

---

```
                ORG    $FFFA  
                DC.W   spurious          ;  
                DC.W   spurious          ; SWI  
                DC.W   _Startup          ; Reset
```

---

The ABSENTRY directive is used to write the address of the application entry point in the generated absolute file. To set the entry point of the application on the \_Startup label in the absolute file, the following code is needed ([Listing 1.16 on page 84](#)).

---

## Working with the Assembler

Directly generating an ABS file

---

### Listing 1.16 Using ABSENTRY to enter the entry-point address

---

```
ABSENTRY _Startup
```

---


**CAUTION** We strongly recommend that you use separate sections for code, (variable) data, and constants. All sections used in the assembler application must be absolute and defined using the `ORG` directive. The addresses for constant or code sections have to be located in the ROM memory area, while the data sections have to be located in a RAM area (according to the hardware that you intend to use). The programmer is responsible for making sure that no section overlaps occur.

---

## Reconfiguring CodeWarrior


From the *Edit* menu, open the *Assembler for HC08* preference panel. Select *Edit > <target\_name> Settings... > Target > Assembler for HC08*. The *Assembler* preference panel appears ([Figure 1.61 on page 84](#))

Figure 1.61 Assembler for HC08 preference panel




Press the *Options* button. The *HC08 Assembler Option Settings* dialog box appears ([Figure 1.62 on page 85](#)).

**Figure 1.62 HC08 Assembler Option Settings dialog box**



In the *Output* panel, select *Object File Format* > *ELF/DWARF 2.0 Absolute File*. Press *OK* to close the dialog box. Now, select the *Linker for HC08* preference panel and select *Options*. The *Linker for HC08* preference panel opens ([Figure 1.63 on page 86](#)).

**Figure 1.63 Linker for HC08 preference panel**



Select the *Absolute, Single-File Assembly project* radio button and press *OK*. The assembler is now configured to directly produce an absolute assembly \*.abs output file.

## Assembling and generating the application

All that is needed to produce the executable \*.abs file is to select *Project > Make* or *Project > Debug*. CodeWarrior produces the same \*.abs and \*.abs.s19 output files that the Assembler and Linker generated for relocatable assembly.

The \*.abs.s19 file generated in the bin subfolder of the project directory is a standard S-Record File. You can burn this file directly into a ROM memory.


If you selected *Project > Debug*, the debugger opens and you can follow the execution of the program while assemble-stepping the Simulator. You can single-step the simulator through the program from the *Run* menu in the Simulator (*Run > Assembly Step* or *Ctrl + F11*).

## Using the Assembler build tool for absolute assembly

Use the same project - Model T that was used for the relocatable assembly project. Use an absolute assembly source file of the type listed in [Listing 1.13 on page 81](#), name the file -main.asm, and insert this file into the Sources file in the project directory.

1. Start the Assembler. You can do this by opening the `ahc08.exe` file in the `prog` folder in the HC08 CodeWarrior installation. The Assembler opens. Close the *Tip of the Day* dialog box.
2. Using *File > Load Configuration*, browse for project directory and set it to be the current directory for the Assembler.
3. Select *Assembler > Options*. The *Option Settings* dialog box appears.
4. In the *Output* dialog box, select the check box in front of the label *Object File Format*. The Assembler displays more information at the bottom of the dialog box.
5. Select the *ELF/DWARF 2.0 Absolute File* menuitem in the pull-down menu. Click *OK*.
6. Select the assembly source-code file that will be assembled: Select *File > Assemble*. The *Select File to Assemble* dialog box appears ([Figure 1.64 on page 87](#)).

**Figure 1.64 Select File to Assemble dialog box**




7. Browse to the absolute-assembly source-code file - `main.asm`. Click *Open*. The Assembler now assembles the source code. Make sure that the `GENPATH` configurations are set for the two include files needed for the `main.asm` file in this project in case they have not yet been previously set. Messages about the assembly process are created in the assembler main window ([Figure 1.65 on page 88](#)).

## Working with the Assembler

### Directly generating an ABS file

Figure 1.65 Successful absolute assembly



The screenshot shows the HC08 Assembler window with the following text:

```
HC08 Assembler E:\Projects\Model T\project.ini
File Assembler View Help
"E:\Projects\Model T\Sources\main.asm"
Changed current directory to E:\Projects\Model T
"E:\Projects\Model T\Sources\main.asm"
Command Line: '-FA2 -L=%(TEXTPATH)\%n.lst -Li "E:\Projects\Model T\Sources\main.asm"'

Top: E:\Projects\Model T\Sources\main.asm

"E:\Projects\Model T\Sources\derivative.inc"
"C:\Program Files\Freescale\CW08 V5.0\lib\hc08c\include\MC68HC908GP32.inc"
writing debug listing to E:\Projects\Model T\main.dbg
Generating SRecord File 'E:\Projects\Model T\main.sx'
Output file: "E:\Projects\Model T\main.abs"
Code Size: 51
writing listing to E:\Projects\Model T\main.lst
HC08 Assembler: *** 0 error(s), 0 warning(s), 0 information message(s) ***
HC08 Assembler: *** Processing ok ***

Ready 09:58:22
```

The messages indicate that:

- An assembly source code (`main.asm`) file, plus `derivative.inc` and `MC68HC908GP32.inc` files were read as input.
- A debugging (`main.dbg`) file was generated in the project directory.
- An S-Record File was created, `main.sx`. This file can be used to program ROM memory.
- An absolute executable file was generated, `main.abs`.
- The Code Size is 51 bytes.
- An assembly outlet listing file (`main.lst`) was written to the project directory.

The `main.abs` file can be used as input to the Simulator, with which you can follow the execution of your program.



# Assembler Graphical User Interface

---

The Macro Assembler runs under *Windows 9X, Windows NT, 2000, XP, 2003, and compatible operating systems.*


This chapter covers the following topics:

- [Starting the Assembler on page 89](#)
- [Assembler Main Window on page 90](#)
- [Editor Setting dialog box on page 96](#)
- [Save Configuration dialog box on page 102](#)
- [Option Settings dialog box on page 105](#)
- [Message settings dialog box on page 106](#)
- [About... dialog box on page 110](#)
- [Specifying the input file on page 110](#)
- [Message/Error feedback on page 111](#)

## Starting the Assembler

When you start the Assembler, the Assembler displays a standard *Tip of the Day* ([Figure 2.1 on page 90](#)) window containing news and tips about the Assembler.

**Figure 2.1** Tip of the Day dialog box



Click *Next Tip* to see the next piece of information about the Assembler.

Click *Close* to close the *Tip of the Day* dialog box.

If you do not want the Assembler to automatically open the standard *Tip of the Day* window when the Assembler is started, uncheck *Show Tips on StartUp*.


If you want the Assembler to automatically open the standard *Tip of the Day* window at Assembler start up, choose *Help > Tip of the Day....* The Assembler displays the *Tip of the Day* dialog box. Check the *Show Tips on StartUp* check box.

## Assembler Main Window

This window is only visible on the screen when you do not specify any filename when you start the Assembler.

The assembler window consists of a window title, a menu bar, a toolbar, a content area, and a status bar ([Figure 2.2 on page 91](#)).

Figure 2.2 HC08 Assembler main window



## Window title

The window title displays the Assembler name and the project name. If a project is not loaded, the Assembler displays “*Default Configuration*” in the window title. An asterisk (\*) after the configuration name indicates that some settings have changed. The Assembler adds an asterisk (\*) whenever an option, the editor configuration, or the window appearance changes.

## Content area

The Assembler displays logging information about the assembly session in the content area. This logging information consists of:

- the name of the file being assembled,
- the whole name (including full path specifications) of the files processed (main assembly file and all included files),
- the list of any error, warning, and information messages generated, and
- the size of the code (in bytes) generated during the assembly session.

When a file is dropped into the assembly window content area, the Assembler either loads the corresponding file as a configuration file or the Assembler assembles the file. The Assembler loads the file as a configuration if the file has the \*.ini extension. If the file does not end with the \*.ini extension, the Assembler assembles the file using the current option settings.

## Assembler Graphical User Interface

### Assembler Main Window

---

All text in the assembler window content area can have context information consisting of two items:

- a filename including a position inside of a file and
- a message number.

File context information is available for all output lines where a filename is displayed. There are two ways to open the file specified in the file-context information in the editor specified in the editor configuration:




- If a file context is available for a line, double-click on a line containing file-context information.
- Click with the right mouse on the line and select “*Open...*”. This entry is only available if a file context is available.



If the Assembler cannot open a file even though a context menu entry is present, then the editor configuration information is incorrect (see the [on page 96 Editor Setting dialog box on page 96](#) section below).


The message number is available for any message output. There are three ways to open the corresponding entry in the help file:



- Select one line of the message and press the F1 key. If the selected line does not have a message number, the main help is displayed.
- Press *Shift-F1* and then click on the message text. If the point clicked does not have a message number, the main help is displayed.
- Click the right mouse button on the message text and select *Help on....* This entry is only available if a message number is available.




## Toolbar

The three buttons on the left hand side of the toolbar correspond to the menu items of the *File* menu. You can use the *New* , *Load*,  and *Save*  buttons to reset, load and save configuration files for the Macro Assembler.

The *Help* button  and the *Context Help* button  allow you to open the *Help* file or the *Context Help*.

When pressing  the buttons above, the mouse cursor changes to a question mark beside an arrow. The Assembler opens Help for the next item on which you click. You can get specific Help on menus, toolbar buttons, or on the window area by using this *Context Help*.

The editable combo box contains a list of the last commands which were executed. After a command line has been selected or entered in this combo box, click the *Assemble* button  to execute this command. The *Stop* button  becomes enabled whenever some file is assembled. When the *Stop* button is pressed, the assembler stops the assembly process.

Pressing the *Options Dialog Box* button  opens the *Option Settings* dialog box.  
Pressing the *Message Dialog Box* button  opens the *Message Settings* dialog box.  
Pressing the *Clear* button  clears the assembler window's content area.

## Status bar

When pointing to a button in the tool bar or a menu entry, the message area displays the function of the button or menu entry to which you are pointing.

Figure 2.3 Status bar



## Assembler menu bar

The following menus are available in the menu bar ([Table 2.1 on page 93](#)):

Table 2.1 Menu bar options

Menu	Description
<a href="#">File menu on page 93</a>	Contains entries to manage Assembler configuration files
<a href="#">Assembler menu on page 95</a>	Contains entries to set Assembler options
<a href="#">View menu on page 95</a>	Contains entries to customize the Assembler window output
Help	A standard Windows Help menu

## File menu

With the file menu, Assembler configuration files can be saved or loaded. An Assembler configuration file contains the following information:

- the assembler option settings specified in the assembler dialog boxes,
- the list of the last command line which was executed and the current command line,
- the window position, size, and font,

## Assembler Graphical User Interface

### Assembler Main Window

---

- the editor currently associated with the Assembler. This editor may be specifically associated with the Assembler or globally defined for all *Tools*. (See the [Editor Setting dialog box on page 96.](#)),
- the *Tips of the Day* settings, including its startup configuration, and what is the current entry, and
- Configuration files are text files which have the standard \*.ini extension. You can define as many configuration files as required for the project and can switch among the different configuration files using the *File > Load Configuration, File | Save Configuration* menu entries, or the corresponding toolbar buttons.

**Table 2.2 File menu options**

Menu entry	Description
Assemble	A standard <i>Open File</i> dialog box is opened, displaying the list of all the *.asm files in the project directory. The input file can be selected using the features from the standard <i>Open File</i> dialog box. The selected file is assembled when the <i>Open File</i> dialog box is closed by clicking <i>OK</i> .
New/Default Configuration	Resets the Assembler option settings to their default values. The default Assembler options which are activated are specified in the <a href="#">Assembler Options</a> chapter.
Load Configuration	A standard <i>Open File</i> dialog box is opened, displaying the list of all the *.ini files in the project directory. The configuration file can be selected using the features from the standard <i>Open File</i> dialog box. The configuration data stored in the selected file is loaded and used in further assembly sessions.
Save Configuration	Saves the current settings in the configuration file specified on the title bar.
Save Configuration As...	A standard <i>Save As</i> dialog box is opened, displaying the list of all the *.ini files in the project directory. The name or location of the configuration file can be specified using the features from the standard <i>Save As</i> dialog box. The current settings are saved in the specified configuration file when the <i>Save As</i> dialog box is closed by clicking <i>OK</i> .

**Table 2.2** File menu options (*continued*)

Menu entry	Description
Configuration...	Opens the <i>Configuration</i> dialog box to specify the editor used for error feedback and which parts to save with a configuration.  See <a href="#">Editor Setting dialog box on page 96</a> and <a href="#">Save Configuration dialog box on page 102</a> .
1. .... project.ini 2. ....	Recent project list. This list can be used to reopen a recently opened project.
Exit	Closes the Assembler.

## Assembler menu

The Assembler menu ([Table 2.3 on page 95](#)) allows you to customize the Assembler. You can graphically set or reset the Assembler options or to stop the assembling process.

**Table 2.3** Assembler menu options

Menu entry	Description
Options	Defines the options which must be activated when assembling an input file. (See <a href="#">Option Settings dialog box on page 105</a> )
Messages	Maps messages to a different message class (See <a href="#">Message settings dialog box on page 106</a> )
Stop assembling	Stops the assembling of the current source file.

## View menu

The View menu ([Table 2.4 on page 95](#)) lets you customize the assembler window. You can specify if the status bar or the toolbar must be displayed or be hidden. You can also define the font used in the window or clear the window.

**Table 2.4** View menu options

Menu entry	Description
Toolbar	Switches display from the toolbar in the assembler window.
Status Bar	Switches display from the status bar in the assembler window.

**Table 2.4** View menu options (*continued*)

Menu entry	Description
Log...	Customizes the output in the assembler window content area. The following two entries in this table are available when Log... is selected:
Change Font	Opens a standard font dialog box. The options selected in the font dialog box are applied to the assembler window content area.
Clear Log	Clears the assembler window content area.

## Editor Setting dialog box

The *Editor Setting* dialog box has a main selection entry. Depending on the main type of editor selected, the content below changes.

These are the main entries for the Editor configuration:


- [“Global Editor \(shared by all tools and projects\)” on page 96](#)
- [“Local Editor \(shared by all tools\)” on page 97](#)
- [“Editor started with the command line” on page 98](#)
- [“Editor started with DDE” on page 99](#)
- [“CodeWarrior with COM” on page 100](#)

## Global Editor (shared by all tools and projects)

This entry ([Figure 2.4 on page 97](#)) is shared by all tools (Compiler/Linker/Assembler/...) for all projects. This setting is stored in the [Editor] section of the `mcutools.ini` global initialization file. Some [Modifiers on page 101](#) can be specified in the editor command line.




Figure 2.4 Global Editor Configuration dialog box



## Local Editor (shared by all tools)

This entry ([on page 98](#)) is shared by all tools (Compiler, Linker, Assembler, ...) for the current project. This setting is stored in the [Editor] section of the local initialization file, usually `project.ini` in the current directory. Some [Modifiers on page 101](#) can be specified in the editor command line.

Figure 2.5 Local editor configuration dialog box




## Editor started with the command line

When this editor type is selected, a separate editor is associated with the Assembler for error feedback. The editor configured in the shell is not used for error feedback.

Enter the command which should be used to start the editor ([Figure 2.6 on page 99](#)).

The format from the editor command depends on the syntax which should be used to start the editor. Modifiers can be specified in the editor command line to refer to a filename and line and column position numbers. (See the [Modifiers on page 101](#) section below.)

Figure 2.6 Command-Line Editor configuration



## Example of configuring a command-line editor

The following case portrays the syntax used for configuring an external editors.

[Listing 2.1 on page 99](#) can be used for the UltraEdit-32 editor.

### Listing 2.1 UltraEdit-32 configuration

---

```
C:\UltraEdit32\uedit32.exe %f /#:%l
```

---

## Editor started with DDE


Enter the service, topic and client name to be used for a DDE (Dynamic Data Exchange) connection to the editor ([Figure 2.7 on page 100](#)). All entries can have modifiers for the filename and line number, as explained in the [Modifiers on page 101](#) section.

## Assembler Graphical User Interface

### Editor Setting dialog box

---

**Figure 2.7** DDE Editor configuration



For the Microsoft Developer Studio, use the settings in [Listing 2.2 on page 100](#):

#### **Listing 2.2** Microsoft Developer Studio configuration settings

---


```
Service Name: msdev
Topic Name:  system
Client Command: [open(%f)]
```

---

## CodeWarrior with COM

If CodeWarrior with COM is enabled, the CodeWarrior IDE (registered as a COM server by the installation script) is used as the editor ([Figure 2.8 on page 101](#)).

Figure 2.8 COM Editor Configuration



## Modifiers

The configurations may contain some modifiers to tell the editor which file to open and at which line and column.

- The %f modifier refers to the name of the file (including path and extension) where the error has been detected.
- The %l modifier refers to the line number where the message has been detected.
- The %c modifier refers to the column number where the message has been detected.

---

**CAUTION** The %l modifier can only be used with an editor which can be started with a line number as a parameter. This is not the case for WinEdit version 3.1 or lower or for the Notepad. When you work with such an editor, you can start it with the filename as a parameter and then select the menu entry 'Go to' to jump on the line where the message has been detected. *In that case the editor command looks like:*

```
C:\WINAPPS\WINEEDIT\Winedit.exe %f
```

## Assembler Graphical User Interface

### Save Configuration dialog box

---


**NOTE** Please check your editor manual to define the command line which should be used to start the editor.

---

## Save Configuration dialog box

The second index of the configuration dialog box contains all options for the save operation ([Figure 2.9 on page 102](#)).

**Figure 2.9** Save Configuration dialog box



In the *Save Configuration* index, there are four check boxes where you can choose which items to save into a project file when the configuration is saved.

This dialog box has the following configurations:

- *Options*: This item is related to the option and message settings. If this check box is set, the current option and message settings are stored in the project file when the configuration is saved. By disabling this check box, changes done to the option and message settings are not saved, and the previous settings remain valid.

- *Editor Configuration*: This item is related to the editor settings. If you set this check box, the current editor settings are stored in the project file when the configuration is saved. If you disable this check box, the previous settings remain valid.
- *Appearance*: This item is related to many parts like the window position (only loaded at startup time) and the command-line content and history. If you set this check box, these settings are stored in the project file when the current configuration is saved. If you disable this check box, the previous settings remain valid.
- *Environment Variables*: With this set, the environment variable changes done in the Environment property panel are also saved.

---

**NOTE** By disabling selective options only some parts of a configuration file can be written. For example, when the best Assembler options are found, the save option mark can be removed. Then future save commands will not modify the options any longer.

---

- *Save on Exit*: If this option is set, the Assembler writes the configuration on exit. The Assembler does not prompt you to confirm this operation. If this option is not set, the assembler does not write the configuration at exit, even if options or other parts of the configuration have changed. No confirmation will appear in any case when closing the assembler.

---

**NOTE** Almost all settings are stored in the project configuration file.  
The only exceptions are:  
- The recently used configuration list.  
- All settings in the Save Configuration dialog box.

---

---

**NOTE** The configurations of the Assembler can, and in fact are intended to, coexist in the same file as the project configuration of other tools and the IDF. When an editor is configured by the shell, the assembler can read this content out of the project file, if present. The default project configuration filename is `project.ini`. The assembler automatically opens an existing `project.ini` in the current directory at startup. Also when using the [-Prod: Specify project file at startup](#) assembler option at startup or loading the configuration manually, a different name other than `project.ini` can be chosen.

---


## Environment Configuration dialog box

The third page of the dialog box is used to configure the environment ([Figure 2.10 on page 104](#)).

## Assembler Graphical User Interface

### Save Configuration dialog box

Figure 2.10 Environment Configuration dialog box



The content of the dialog box is read from the actual project file out of the [Environment Variables] section.

The following variables are available ([Table 2.5 on page 104](#)):

Table 2.5 Path environment variables

Path	Environment variable
General	GENPATH
Object	OBJPATH
Text	TEXTPATH
Absolute	ABSPATH
Header File	LIBPATH

*Various Environment Variables:* other variables not covered in the above table.

The following buttons are available for the Configuration dialog box:




- *Add*: Adds a new line or entry
- *Change*: Changes a line or entry
- *Delete*: Deletes a line or entry
- *Up*: Moves a line or entry up
- *Down*: Moves a line or entry down

Note that the variables are written to the project file only if you press the *Save* button (or using *File -> Save Configuration* or *CTRL-S*). In addition, it can be specified in the *Save Configuration* dialog box if the environment is written to the project file or not.

## Option Settings dialog box

Use this dialog box ([Figure 2.11 on page 105](#)) to set or reset assembler options.

**Figure 2.11** Option Settings dialog box



## Assembler Graphical User Interface

### Message settings dialog box

---

The options available are arranged into different groups, and a sheet is available for each of these groups. The content of the list box depends on the selected sheet ([Table 2.6 on page 106](#)):

**Table 2.6 Option Settings options**

Group	Description
Output	Lists options related to the output files generation (which kind of file should be generated).
Input	Lists options related to the input files.
Language	Lists options related to the programming language (ANSI-C, C++, ...)
Host	Lists options related to the host.
Code Generation	Lists options related to code generation (memory models, ...).
Messages	Lists options controlling the generation of error messages.
Various	Lists various additional options (options used for compatibility, ...).

An assembler option is set when the check box in front of it is checked. To obtain more detailed information about a specific option, select it and press the *F1* key or the *Help* button. To select an option, click once on the option text. The option text is then displayed inverted.


When the dialog box is opened and no option is selected, pressing the *F1* key or the *Help* button shows the help about this dialog box.

The available options are listed in the [Assembler Options](#) chapter.

## Message settings dialog box

You can use the Message Settings ([Table 2.7 on page 107](#)) dialog box to map messages to a different message class.

**Figure 2.12** Message Settings dialog box



Some buttons in the dialog box may be disabled. For example, if an option cannot be moved to an information message, the ‘*Move to: Information*’ button is disabled. The buttons in [Table 2.7 on page 107](#) are available in the *Message Settings* dialog box:

**Table 2.7** Message Settings options

Button	Description
Move to: Disabled	The selected messages are disabled; they will no longer be displayed.
Move to: Information	The selected messages are changed to information messages.
Move to: Warning	The selected messages are changed to warning messages.
Move to: Error	The selected messages are changed to error messages.
Move to: Default	The selected messages are changed to their default message types.
Reset All	Resets all messages to their default message types.
OK	Exits this dialog box and saves any changes.

## Assembler Graphical User Interface

### Message settings dialog box

---

**Table 2.7 Message Settings options (continued)**

Button	Description
Cancel	Exits this dialog box without accepting any changes.
Help	Displays online help about this dialog box.

A panel is available for each error message class and the content of the list box depends on the selected panel ([Table 2.8 on page 108](#)):

**Table 2.8 Message classes**

Message group	Description
Disabled	Lists all disabled messages. That means that messages displayed in the list box will not be displayed by the Assembler.
Information	Lists all information messages. Information messages informs about action taken by the Assembler.
Warning	Lists all warning messages. When such a message is generated, translation of the input file continues and an object file will be generated.
Error	Lists all error messages. When such a message is generated, translation of the input file continues, but no object file will be generated.
Fatal	Lists all fatal error messages. When such a message is generated, translation of the input file stops immediately. Fatal messages cannot be changed. They are only listed to call context help.

Each message has its own character ('A' for Assembler message) followed by a 4- or 5-digit number. This number allows an easy search for the message on-line help.

## Changing the class associated with a message


You can configure your own mapping of messages to the different classes. To do this, use one of the buttons located on the right hand of the dialog box. Each button refers to a message class. To change the class associated with a message, you have to select the message in the list box and then click the button associated with the class where you want to move the message.

## Example

To define the *A2336: Value too big* warning as an error message:

- Click the *Warning* sheet to display the list of all warning messages in the list box.
- Click on the *A2336: Value too big* string in the list box to select the message.
- Click *Error* to define this message as an error message. The *ahc08* dialog box appears. Press *Yes* to close the *ahc08* dialog box ([Figure 2.13 on page 109](#)).

Figure 2.13 HC08 Assembler Message Settings dialog box



---

**NOTE** Messages cannot be moved from or to the fatal error class.

---

---

**NOTE** The *Move to* buttons are enabled when all selected messages can be moved. When one message is marked, which cannot be moved to a specific group, the corresponding *Move to* button is disabled (grayed).

---

If you want to validate the modification you have performed in the error message mapping, close the *HC08 Assembler Message Settings* dialog box with the *OK* button. If you close it using the *Cancel* button, the previous message mapping remains valid.

# About... dialog box

The *About...* dialog box can be opened with the menu *Help > About*. The *About...* dialog box contains much information including the current directory and the versions of subparts of the Assembler. The main Assembler version is displayed separately on top of the dialog box.

With the *Extended Information* button it is possible to get license information about all software components in the same directory of the executable.

Press *OK* to close this dialog box.

---

**NOTE** During assembling, the subversions of the subparts cannot be requested. They are only displayed if the Assembler is not processing files.

---

## Specifying the input file

There are different ways to specify the input file which must be assembled. During assembling of a source file, the options are set according to the configuration performed by the user in the different dialog boxes and according to the options specified on the command line.

Before starting to assemble a file, make sure you have associated a working directory with your assembler.

## Use the command line in the toolbar to assemble

You can use the command line to assemble a new file or to reassemble a previously created file.

## Assembling a new file

A new filename and additional assembler options can be entered in the command line. The specified file is assembled when you press the *Assemble* button in the tool bar or when you press the enter key.

## Assembling a file which has already been assembled

The commands executed previously can be displayed using the arrow on the right side of the command line. A command is selected by clicking on it. It appears in the command

line. The specified file will be processed when the button *Assemble* in the tool bar is selected.

## Use the File > Assemble... entry

When the menu entry *File > Assemble...* is selected a standard file *Open File* dialog box is opened, displaying the list of all the \*.asm files in the project directory. You can browse to get the name of the file that you want to assemble. Select the desired file and click *Open* in the *Open File* dialog box to assemble the selected file.

## Use Drag and Drop

A filename can be dragged from an external software (for example the *File Manager/Explorer*) and dropped into the assembler window. The dropped file will be assembled when the mouse button is released in the assembler window. If a file being dragged has the \*.ini extension, it is considered to be a configuration and it is immediately loaded and not assembled. To assemble a source file with the \*.ini extension, use one of the other methods.

# Message/Error feedback

After assembly, there are several ways to check where different errors or warnings have been detected. The default format of the error message is as [on page 111](#). A typical error message is like the one in [Listing 2.4 on page 111](#).

### Listing 2.3 Typical error feedback message

---

```
Default configuration of an error message
>> <FileName>, line <line number>, col <column number>,
pos <absolute position in file>
<Portion of code generating the problem>
<message class><message number>: <Message string>
```

---

### Listing 2.4 Error message example

---

```
>> in "C:\Freescale\demo\fiborr.asm", line 18, col 0, pos 722
    DC    label
        ^
ERROR A1104: Undeclared user defined symbol: label
```

---

For different message formats, see the following Assembler options:

- [-WmsgFi \(-WmsgFiv, -WmsgFim\): Set message file format for interactive mode](#)
- [-WmsgFob: Message format for batch mode](#)
- [-WmsgFoi: Message format for interactive mode](#)
- [-WmsgFonf: Message format for no file information](#)
- [-WmsgFonp: Message format for no position information.](#)

## Use information from the assembler window

Once a file has been assembled, the assembler window content area displays the list of all the errors or warnings detected.

The user can use his usual editor to open the source file and correct the errors.

## Use a user-defined editor

The editor for *Error Feedback* can be configured using the *Configuration* dialog box. Error feedback is performed differently, depending on whether or not the editor can be started with a line number.

## Line number can be specified on the command line

Editors like *UltraEdit-32* or *WinEdit* (v95 or higher) can be started with a line number in the command line. When these editors have been correctly configured, they can be started automatically by double clicking on an error message. The configured editor will be started, the file where the error occurs is automatically opened and the cursor is placed on the line where the error was detected.

## Line number cannot be specified on the command line

Editors like *WinEdit* v31 or lower, *Notepad*, or *Wordpad* cannot be started with a line number in the command line. When these editors have been correctly configured, they can be started automatically by double clicking on an error message. The configured editor will be started, and the file is automatically opened where the error occurs. To scroll to the position where the error was detected, you have to:

- Activate the assembler again.



- Click the line on which the message was generated. This line is highlighted on the screen.
- Copy the line in the clipboard by pressing *CTRL + C*.
- Activate the editor again.
- Select *Search > Find*; the standard *Find* dialog box is opened.
- Paste the contents of the clipboard in the Edit box pressing *CTRL + V*.
- Click *Forward* to jump to the position where the error was detected.

**Assembler Graphical User Interface**  
*Message/Error feedback*

---

# Environment

---

This part describes the environment variables used by the Assembler. Some of those environment variables are also used by other tools (e.g., Linker or Compiler), so consult also the respective documentation.

There are three ways to specify an environment:

- 1) The current project file with the Environment Variables section. This file may be specified on Tool startup using the [-Prod: Specify project file at startup](#) assembler option. This is the recommended method and is also supported by the IDE.
- 2) An optional 'default.env' file in the current directory. This file is supported for compatibility reasons with earlier versions. The name of this file may be specified using the [ENVIRONMENT: Environment file specification on page 126](#) environment variable. Using the default.env file is not recommended.
- 3) Setting environment variables on system level (DOS level). This is also not recommended.

Various parameters of the Assembler may be set in an environment using so-called environment variables. The syntax is always the same ([Listing 3.1 on page 115](#)).

## Listing 3.1 Syntax for setting environment variables

---

```
Parameter: KeyName=ParamDef
```

---

[Listing 3.2 on page 115](#) is a typical example of setting an environment variable.

## Listing 3.2 Setting the GENPATH environment variable

---

```
GENPATH=C:\INSTALL\LIB;D:\PROJECTS\TESTS;/usr/local/lib;  
/home/me/my_project
```

---

These parameters may be defined in several ways:

- Using system environment variables supported by your operating system.
- Putting the definitions in a file called default.env (.hidefaults for UNIX) in the default directory.
- Putting the definitions in a file given by the value of the ENVIRONMENT system environment variable.

## Environment

### Current directory

---

**NOTE** The default directory mentioned above can be set via the `DEFAULTDIR` system environment variable.

---

When looking for an environment variable, all programs first search the system environment, then the `default.env` (`.hidefaults` for UNIX) file and finally the global environment file given by `ENVIRONMENT`. If no definition can be found, a default value is assumed.

---

**NOTE** The environment may also be changed using the [-Env: Set environment variable](#) assembler option.

---

## Current directory

The most important environment for all tools is the current directory. The current directory is the base search directory where the tool starts to search for files (e.g., for the `default.env` or `.hidefaults`)

Normally, the current directory of a launched tool is determined by the operating system or by the program that launches another one (e.g., IDE, Make Utility, ...).

For the UNIX operating system, the current directory for an executable is also the current directory from where the binary file has been started.

For MS Windows-based operating systems, the current directory definition is quite complex:

- If the tool is launched using the File Manager/Explorer, the current directory is the location of the launched executable tool.
- If the tool is launched using an Icon on the Desktop, the current directory is the one specified and associated with the Icon in its properties.
- If the tool is launched by dragging a file on the icon of the executable tool on the desktop, the directory on the desktop is the current directory.
- If the tool is launched by another launching tool with its own current directory specification (e.g., an editor as IDE, a Make utility, ...), the current directory is the one specified by the launching tool.
- When a local project file is loaded, the current directory is set to the directory which contains the local project file. Changing the current project file also changes the current directory if the other project file is in a different directory. Note that browsing for an assembly source file does not change the current directory.

To overwrite this behavior, the [DEFAULTDIR: Default current directory on page 125](#) system environment variable may be used.

The current directory is displayed among other information with the [-V: Prints the Assembler version](#) assembler option and in the About... box.

## Environment macros

It is possible to use macros ([Listing 3.3 on page 117](#)) in your environment settings.

### Listing 3.3 Using a macro for setting environment variables

---

```
MyVAR=C:\test
TEXTPATH=$(MyVAR)\txt
OBJPATH=${MyVAR}\obj
```

---

In the example in [Listing 3.3 on page 117](#), TEXTPATH is expanded to 'C:\test\txt', and OBJPATH is expanded to 'C:\test\obj'.

From the example above, you can see that you either can use \$( ) or \${ }. However, the variable referenced has to be defined somewhere.

In addition, the following special variables in [Listing 3.4 on page 117](#) are allowed. Note that they are case-sensitive and always surrounded by { }. Also the variable content contains a directory separator '\ ' as well.

### Listing 3.4 Special variables used with macros for setting environment variables

---

{Compiler}

This is the path of the directory one level higher than the directory for executable tool. That is, if the executable is 'C:\Freescale\prog\linker.exe', then the variable is 'C:\Freescale\'. Note that {Compiler} is also used for the Assembler.

{Project}

Path of the directory containing the current project file. For example, if the current project file is 'C:\demo\project.ini', the variable contains 'C:\demo\ '.

{System}

This is the path where your Windows O/S is installed, e.g., 'C:\WINNT\ '.

---

## Global initialization file - mctools.ini (PC only)

All tools may store some global data into the mctools.ini file. The tool first searches for this file in the directory of the tool itself (path of the executable tool). If there is no

## Environment

Local configuration file (usually *project.ini*)

---

`mcutools.ini` file in this directory, the tool looks for an `mcutools.ini` file located in the *MS Windows* installation directory (e.g., `C:\WINDOWS`).

[Listing 3.5 on page 118](#) shows two typical locations used for the `mcutools.ini` files.

### Listing 3.5 Usual locations for the `mcutools.ini` files

---

```
C:\WINDOWS\mcutools.ini
D:\INSTALL\prog\mcutools.ini
```

---

If a tool is started in the `D:\INSTALL\prog\` directory, the initialization file located in the same directory as the tool is used (`D:\INSTALL\prog\mcutools.ini`).

But if the tool is started outside of the `D:\INSTALL\prog` directory, the initialization file in the *Windows* directory is used (`C:\WINDOWS\mcutools.ini`).

## Local configuration file (usually *project.ini*)

The Assembler does not change the `default.env` file in any way. The Assembler only reads the contents. All the configuration properties are stored in the configuration file. The same configuration file can and is intended to be used by different applications (Assembler, Linker, etc.).

The processor name is encoded into the section name, so that the Assembler for different processors can use the same file without any overlapping. Different versions of the same Assembler are using the same entries. This usually only leads to a potential problem when options only available in one version are stored in the configuration file. In such situations, two files must be maintained for the different Assembler versions. If no incompatible options are enabled when the file is last saved, the same file can be used for both Assembler versions.

The current directory is always the directory that holds the configuration file. If a configuration file in a different directory is loaded, then the current directory also changes. When the current directory changes, the whole `default.env` file is also reloaded. When a configuration file is loaded or stored, the options located in the [ASMOPTIONS: Default assembler options on page 123](#) environment variable are reloaded and added to the project's options.

This behavior has to be noticed when in different directories different `default.env` files exist which contain incompatible options in their `ASMOPTIONS` environment variables. When a project is loaded using the first `default.env` file, its `ASMOPTIONS` options are added to the configuration file. If this configuration is then stored in a different directory, where a `default.env` file exists with these incompatible options, the Assembler adds the options and remarks the inconsistency. Then a message box appears to inform the user that those options from the `default.env` file were not added. In such a

situation, the user can either remove the options from the configuration file with the advanced option dialog box or he can remove the option from the `default.env` file with the shell or a text editor depending upon which options should be used in the future.

At startup, the configuration stored in the `project.ini` file located in the current Paths Local Configuration File Entries documents the sections and entries you can put in a `project.ini` file.

Most environment variables contain path lists telling where to look for files. A path list is a list of directory names separated by semicolons following the syntax in [Listing 3.6 on page 119](#).

---

**Listing 3.6 Syntax used for setting path lists of environment variables**

---

```
PathList=DirSpec{" ;"DirSpec}  
DirSpec=["*"]DirectoryName
```

---

[Listing 3.7 on page 119](#) is a typical example of setting an environment variable.

---

**Listing 3.7 Setting the paths for the GEBNPATH environment variable**

---

```
GENPATH=C:\INSTALL\LIB;D:\PROJECTS\TESTS;/usr/local/Freescale/lib;/  
home/me/my_project
```

---

If a directory name is preceded by an asterisk (\*), the programs recursively search that whole directory tree for a file, not just the given directory itself. The directories are searched in the order they appear in the path list. [Listing 3.8 on page 119](#) shows the use of an asterisk (\*) for recursively searching the entire C drive for a configuration file with a `\INSTALL\LIB` path.

---

**Listing 3.8 Recursive search for a continuation line**

---

```
LIBPATH=*C:\INSTALL\LIB
```

---

---

**NOTE** Some DOS/UNIX environment variables (like `GENPATH`, `LIBPATH`, etc.) are used. For further details refer to [Environment variables details on page 121](#).

---

We strongly recommend working with the Shell and setting the environment by means of a `default.env` file in your project directory. (This 'project\_dir' can be set in the Shell's 'Configure' dialog box). Doing it this way, you can have different projects in different directories, each with its own environment.

---

## Environment

### Line continuation

---

**NOTE** When starting the Assembler from an external editor, do *not* set the `DEFAULTDIR` system environment variable. If you do so and this variable does not contain the project directory given in the editor's project configuration, files might not be put where you expect them to be put!

---

A synonym also exists for some environment variables. Those synonyms may be used for older releases of the Assembler, but they are deprecated and thus they will be removed in the future.

## Line continuation

It is possible to specify an environment variable in an environment file (`default.env` or `hidefaults`) over multiple lines using the line continuation character `'\'` ([Listing 3.9 on page 120](#)):

### Listing 3.9 Using multiple lines for an environment variable

---

```
ASMOPTIONS=\
  -W2\
  -WmsgNe=10
```

---

[Listing 3.9 on page 120](#) is the same as the alternate source code in [Listing 3.10 on page 120](#).

### Listing 3.10 Alternate form of using multiple lines

---

```
ASMOPTIONS=-W2 -WmsgNe=10
```

---

But this feature may be dangerous when used together with paths ([Listing 3.11 on page 120](#)).

### Listing 3.11 A path is included by the line continuation character

---

```
GENPATH=. \
TEXTFILE=.\txt
will result in
GENPATH=.TEXTFILE=.\txt
```

---

In order to avoid such problems, we recommend that you use a semicolon `' ; '` at the end of a path if there is a backslash `'\'` at the end ([Listing 3.12 on page 121 on page 121](#)).

---



**Listing 3.12 Recommended style whenever a backlash is present**

---

```
GENPATH= . \ ;  
TEXTFILE= . \txt
```

---

## Environment variables details

The remainder of this section is devoted to describing each of the environment variables available for the Assembler. The environment variables are listed in alphabetical order and each is divided into several sections ([Table 3.1 on page 121](#)).

**Table 3.1 Topics used for describing environment variables**

Topic	Description
Tools	Lists tools which are using this variable.
Synonym (where one exists)	A synonym exists for some environment variables. These synonyms may be used for older releases of the Assembler but they are deprecated and they will be removed in the future. A synonym has lower precedence than the environment variable.
Syntax	Specifies the syntax of the option in an EBNF format.
Arguments	Describes and lists optional and required arguments for the variable.
Default (if one exists)	Shows the default setting for the variable if one exists.
Description	Provides a detailed description of the option and its usage.
Example	Gives an example of usage and effects of the variable where possible. An example shows an entry in the default.env for the PC or in the .hidefaults for UNIX.
See also (if needed)	Names related sections.

## Environment

*Environment variables details*

---

### **ABSPATH: Absolute file path**

#### **Tools**

Compiler, Assembler, Linker, Decoder, or Debugger

#### **Syntax**

```
ABSPATH={ <path> }
```

#### **Arguments**

<path>: Paths separated by semicolons, without spaces

#### **Description**

This environment variable is only relevant when absolute files are directly generated by the Macro Assembler instead of relocatable object files. When this environment variable is defined, the Assembler will store the absolute files it produces in the first directory specified there. If `ABSPATH` is not set, the generated absolute files will be stored in the directory where the source file was found.

#### **Example**

```
ABSPATH=\sources\bin;..\..\headers;\usr\local\bin
```

## ASMOPTIONS: Default assembler options

### Tools

Assembler

### Syntax

```
ASMOPTIONS={<option>}
```

### Arguments

<option>: Assembler command-line option

### Description

If this environment variable is set, the Assembler appends its contents to its command line each time a file is assembled. It can be used to globally specify certain options that should always be set, so you do not have to specify them each time a file is assembled.

Options enumerated there must be valid assembler options and are separated by space characters.

### Example

```
ASMOPTIONS=-W2 -L
```

### See also

[Assembler Options](#) chapter

## Environment

*Environment variables details*

---

## COPYRIGHT: Copyright entry in object file

### Tools

Compiler, Assembler, Linker, or Librarian

### Syntax

```
COPYRIGHT=<copyright>
```

### Arguments

<copyright>: copyright entry

### Description

Each object file contains an entry for a copyright string. This information may be retrieved from the object files using the Decoder.

### Example

```
COPYRIGHT=Copyright
```

### See also

#### Environment variables:

- [USERNAME: User Name in object file on page 136](#)
- [INCLUDETIME: Creation time in the object file on page 131](#)

## **DEFAULTDIR: Default current directory**

### **Tools**

Compiler, Assembler, Linker, Decoder, Debugger, Librarian, or Maker

### **Syntax**

```
DEFAULTDIR=<directory>
```

### **Arguments**

<directory>: Directory to be the default current directory

### **Description**

The default directory for all tools may be specified with this environment variable. Each of the tools indicated above will take the directory specified as its current directory instead of the one defined by the operating system or launching tool (e.g., editor).

---

**NOTE** This is an environment variable on the system level (global environment variable). It cannot be specified in a default environment file (`default.env` or `hidefaults`).

---

### **Example**

```
DEFAULTDIR=C:\INSTALL\PROJECT
```

### **See also**

[“Current directory” on page 116](#)

“All tools may store some global data into the `mcutools.ini` file. The tool first searches for this file in the directory of the tool itself (path of the executable tool). If there is no `mcutools.ini` file in this directory, the tool looks for an `mcutools.ini` file located in the MS Windows installation directory (e.g., `C:\WINDOWS`).”

## Environment

*Environment variables details*

---

## ENVIRONMENT: Environment file specification

### Tools

Compiler, Assembler, Linker, Decoder, Debugger, Librarian, or Maker

### Synonym

HIENVIRONMENT

### Syntax

ENVIRONMENT=<file>

### Arguments

<file>: filename with path specification, without spaces

### Description

This variable has to be specified on the system level. Normally the Assembler looks in the current directory for an environment file named `default.env` (`.hidefaults` on UNIX). Using `ENVIRONMENT` (e.g., set in the `autoexec.bat` (DOS) or `.cshrc` (UNIX)), a different filename may be specified.

---

**NOTE** This is an environment variable on the system level (global environment variable). It cannot be specified in a default environment file (`default.env` or `.hidefaults`).

---

### Example

```
ENVIRONMENT=\Freescale\prog\global.env
```

## **ERRORFILE: Filename specification error**

### **Tools**

Compiler, Assembler, or Linker

### **Syntax**

```
ERRORFILE=<filename>
```

### **Arguments**

<filename>: Filename with possible format specifiers

### **Default**

EDOUT

### **Description**

The `ERRORFILE` environment variable specifies the name for the error file (used by the Compiler or Assembler).

Possible format specifiers are:

- '%n': Substitute with the filename, without the path.
- '%p': Substitute with the path of the source file.
- '%f': Substitute with the full filename, i.e., with the path and name (the same as '%p%n').

In case of an improper error filename, a notification box is shown.

### **Examples**

[Listing 3.13 on page 127](#) lists all errors into the `MyErrors.err` file in the current directory.

#### **Listing 3.13 Naming an error file**

---

```
ERRORFILE=MyErrors.err
```

---

[Listing 3.14 on page 128](#) lists all errors into the `errors` file in the `\tmp` directory.

## Environment

### Environment variables details

---

#### Listing 3.14 Naming an error file in a specific directory

---

```
ERRORFILE=\tmp\errors
```

---

[Listing 3.15 on page 128](#) lists all errors into a file with the same name as the source file, but with extension `*.err`, into the same directory as the source file, e.g., if we compile a file `\sources\test.c`, an error list file `\sources\test.err` will be generated.

#### Listing 3.15 Naming an error file as source filename

---

```
ERRORFILE=%f.err
```

---

For a `test.c` source file, a `\dir1\test.err` error list file will be generated ([Listing 3.16 on page 128](#)).

#### Listing 3.16 Naming an error file as source filename in a specific directory

---

```
ERRORFILE=\dir1\%n.err
```

---

For a `\dir1\dir2\test.c` source file, a `\dir1\dir2\errors.txt` error list file will be generated ([Listing 3.17 on page 128](#)).

#### Listing 3.17 Naming an error file as a source filename with full path

---

```
ERRORFILE=%p\errors.txt
```

---

If the `ERRORFILE` environment variable is not set, errors are written to the default error file. The default error filename depends on the way the Assembler is started.

If a filename is provided on the assembler command line, the errors are written to the `EDOUT` file in the project directory.

If no filename is provided on the assembler command line, the errors are written to the `err.txt` file in the project directory.

Another example ([Listing 3.18 on page 129](#)) shows the usage of this variable to support correct error feedback with the WinEdit Editor which looks for an error file called `EDOUT`:



**Listing 3.18 Configuring error feedback with WinEdit**

---

```
Installation directory: E:\INSTALL\prog
Project sources: D:\SRC
Common Sources for projects: E:\CLIB

Entry in default.env (D:\SRC\default.env) :
ERRORFILE=E:\INSTALL\prog\EDOUT

Entry in WinEdit.ini (in Windows directory):
OUTPUT=E:\INSTALL\prog\EDOUT
```

---

---

**NOTE** Be careful to set this variable if the WinEdit Editor is used, otherwise the editor cannot find the EDOUT file.

---

## Environment

Environment variables details

---

### GENPATH: Search path for input file

#### Tools

Compiler, Assembler, Linker, Decoder, or Debugger

#### Synonym

HIPATH

#### Syntax

```
GENPATH={ <path> }
```

#### Arguments

<path>: Paths separated by semicolons, without spaces.

#### Description

The Macro Assembler will look for the sources and included files first in the project directory, then in the directories listed in the GENPATH environment variable.

---

**NOTE** If a directory specification in this environment variables starts with an asterisk (\*), the whole directory tree is searched recursive depth first, i.e., all subdirectories and *their* subdirectories and so on are searched. Within one level in the tree, the search order of the subdirectories is indeterminate.

---

#### Example

```
GENPATH=\sources\include;..\..\headers;\usr\local\lib
```

## **INCLUDETIME: Creation time in the object file**

### **Tools**

Compiler, Assembler, Linker, or Librarian

### **Syntax**

```
INCLUDETIME= (ON | OFF)
```

### **Arguments**

ON: Include time information into the object file.

OFF: Do not include time information into the object file.

### **Default**

ON

-

### **Description**

Normally each object file created contains a time stamp indicating the creation time and data as strings. So whenever a new file is created by one of the tools, the new file gets a new time stamp entry.

This behavior may be undesired if for SQA reasons a binary file compare has to be performed. Even if the information in two object files is the same, the files do not match exactly because the time stamps are not the same. To avoid such problems this variable may be set to OFF. In this case the time stamp strings in the object file for date and time are “none” in the object file.

The time stamp may be retrieved from the object files using the Decoder.

### **Example**

```
INCLUDETIME=OFF
```

### **See also**

**Environment variables:**

- [COPYRIGHT: Copyright entry in object file on page 124](#)
- [USERNAME: User Name in object file on page 136](#)

## Environment

*Environment variables details*

---

### **OBJPATH: Object file path**

#### **Tools**

Compiler, Assembler, Linker, or Decoder

#### **Syntax**

```
OBJPATH={ <path> }
```

#### **Arguments**

<path>: Paths separated by semicolons, without spaces

#### **Description**

This environment variable is only relevant when object files are generated by the Macro Assembler. When this environment variable is defined, the Assembler will store the object files it produces in the first directory specified in `path`. If `OBJPATH` is not set, the generated object files will be stored in the directory the source file was found.

#### **Example**

```
OBJPATH=\sources\bin;..\..\headers;\usr\local\bin
```

## SRECORD: S-Record type

### Tools

Assembler, Linker, or Burner

### Syntax

```
SRECORD=<RecordType>
```

### Arguments

<RecordType>: Forces the type for the S-Record File which must be generated. This parameter may take the value 'S1', 'S2', or 'S3'.

### Description

This environment variable is only relevant when absolute files are directly generated by the Macro Assembler instead of object files. When this environment variable is defined, the Assembler will generate an S-Record File containing records from the specified type (S1 records when S1 is specified, S2 records when S2 is specified, and S3 records when S3 is specified).

---

**NOTE** If the SRECORD environment variable is set, it is the user's responsibility to specify the appropriate type of S-Record File. If you specify S1 while your code is loaded above 0xFFFF, the S-Record File generated will not be correct because the addresses will all be truncated to 2-byte values.

---

When this variable is not set, the type of S-Record File generated will depend on the size of the address, which must be loaded there. If the address can be coded on 2 bytes, an S1 record is generated. If the address is coded on 3 bytes, an S2 record is generated. Otherwise, an S3 record is generated.

### Example

```
SRECORD=S2
```

## Environment

*Environment variables details*

---

### TEXTPATH: Text file path

#### Tools

Compiler, Assembler, Linker, or Decoder

#### Syntax

```
TEXTPATH={ <path> }
```

#### Arguments

<path>: Paths separated by semicolons, without spaces.

#### Description

When this environment variable is defined, the Assembler will store the listing files it produces in the first directory specified in `path`. If `TEXTPATH` is not set, the generated listing files will be stored in the directory the source file was found.

#### Example

```
TEXTPATH=\sources\txt;..\..\headers;\usr\local\txt
```

## TMP: Temporary directory

### Tools

Compiler, Assembler, Linker, Debugger, or Librarian

### Syntax

```
TMP=<directory>
```

### Arguments

<directory>: Directory to be used for temporary files

### Description

If a temporary file has to be created, normally the ANSI function `tmpnam()` is used. This library function stores the temporary files created in the directory specified by this environment variable. If the variable is empty or does not exist, the current directory is used. Check this variable if you get an error message “*Cannot create temporary file*”.

---

**NOTE** TMP is an environment variable on the system level (global environment variable). It *CANNOT* be specified in a default environment file (default `.env` or `.hidefaults`).

---

### Example

```
TMP=C:\TEMP
```

### See also

[Current directory on page 116](#) section

## Environment

*Environment variables details*

---

## USERNAME: User Name in object file

### Tools

Compiler, Assembler, Linker, or Librarian

### Syntax

```
USERNAME=<user>
```

### Arguments

<user>: Name of user

### Description

Each object file contains an entry identifying the user who created the object file. This information may be retrieved from the object files using the decoder.

### Example

```
USERNAME=PowerUser
```

### See also

**Environment variables:**

- [COPYRIGHT: Copyright entry in object file on page 124](#)
- [INCLUDETIME: Creation time in the object file on page 131](#)



# Files

---

This chapter covers these topics:

- [Input files on page 137](#)
- [Output files on page 137](#)
- [Output files on page 137](#)

## Input files

Input files to the Assembler:

- [Source files on page 137](#)
- [Object files on page 138](#)

## Source files

The Macro Assembler takes any file as input. It does not require the filename to have a special extension. However, we suggest that all your source filenames have the `*.asm` extension and all included files have the `*.inc` extension. Source files will be searched first in the project directory and then in the directories enumerated in [GENPATH: Search path for input file](#)

## Include files

The search for include files is governed by the `GENPATH` environment variable. Include files are searched for first in the project directory, then in the directories given in the `GENPATH` environment variable. The project directory is set via the Shell, the Program Manager, or the [DEFAULTDIR: Default current directory](#) environment variable.

## Output files

Output files from the Assembler:

- [Object files on page 138](#)
- [Absolute files on page 138](#)
- [S-Record Files on page 138](#)

## Files

### Output files

---

- [Listing files on page 139](#)
- [Debug listing files on page 139](#)
- [Error listing file on page 139](#)

## Object files

After a successful assembling session, the Macro Assembler generates an object file containing the target code as well as some debugging information. This file is written to the directory given in the [OBJPATH: Object file path](#) environment variable. If that variable contains more than one path, the object file is written in the first directory given; if this variable is not set at all, the object file is written in the directory the source file was found. Object files always get the `*.o` extension.

## Absolute files

When an application is encoded in a single module and all the sections are absolute sections, the user can decide to generate directly an absolute file instead of an object file. This file is written to the directory given in the [ABSPATH: Absolute file path](#) environment variable. If that variable contains more than one path, the absolute file is written in the first directory given; if this variable is not set at all, the absolute file is written in the directory the source file was found. Absolute files always get the `*.abs` extension.

## S-Record Files

When an application is encoded in a single module and all the sections are absolute sections, the user can decide to generate directly an ELF absolute file instead of an object file. In that case an S-Record File is generated at the same time. This file can be burnt into an EPROM. It contains information stored in all the `READ_ONLY` sections in the application. The extension for the generated S-Record File depends on the setting from the [SRECORD: S-Record type](#) environment variable.

- If `SRECORD = S1`, the S-Record File gets the `*.s1` extension.
- If `SRECORD = S2`, the S-Record File gets the `*.s2` extension.
- If `SRECORD = S3`, the S-Record File gets the `*.s3` extension.
- If `SRECORD` is not set, the S-Record File gets the `*.sx` extension.

This file is written to the directory given in the `ABSPATH` environment variable. If that variable contains more than one path, the S-Record File is written in the first directory given; if this variable is not set at all, the S-Record File is written in the directory the source file was found.

## Listing files

After successful assembling session, the Macro Assembler generates a listing file containing each assembly instruction with their associated hexadecimal code. This file is always generated when the [-L: Generate a listing file](#) assembler option is activated (even when the Macro Assembler generates directly an absolute file).

This file is written to the directory given in the [TEXTPATH: Text file path](#) environment variable. If that variable contains more than one path, the listing file is written in the first directory given; if this variable is not set at all, the listing file is written in the directory the source file was found. Listing files always get the `*.lst` extension. The format of the listing file is described in the [Assembler Listing File](#) chapter.

## Debug listing files

After successful assembling session, the Macro Assembler generates a debug listing file, which will be used to debug the application. This file is always generated, even when the Macro Assembler directly generates an absolute file. The debug listing file is a duplicate from the source, where all the macros are expanded and the include files merged. This file is written to the directory given in the [OBJPATH: Object file path](#) environment variable. If that variable contains more than one path, the debug listing file is written in the first directory given; if this variable is not set at all, the debug listing file is written in the directory the source file was found. Debug listing files always get the `*.dbg` extension.

## Error listing file

If the Macro Assembler detects any errors, it does not create an object file but does create an error listing file. This file is generated in the directory the source file was found (see [ERRORFILE: Filename specification error](#)).

If the Assembler's window is open, it displays the full path of all include files read. After successful assembling, the number of code bytes generated is displayed, too. In case of an error, the position and filename where the error occurs is displayed in the assembler window.

If the Assembler is started from the *IDE* (with `%E'` given on the command line) or CodeWright (with `%b%e'` given on the command line), this error file is not produced. Instead, it writes the error messages in a special Microsoft default format in a file called `EDOUT`. Use *WinEdit's Next Error* or CodeWright's *Find Next Error* command to see both error positions and the error messages.

## Interactive mode (Assembler window open)

If `ERRORFILE` is set, the Assembler creates a message file named as specified in this environment variable.

If `ERRORFILE` is not set, a default file named `err.txt` is generated in the current directory.

## Batch mode (Assembler window not open)


If `ERRORFILE` is set, the Assembler creates a message file named as specified in this environment variable.

If `ERRORFILE` is not set, a default file named `EDOUT` is generated in the current directory.

# File Processing

[Figure 4.1 on page 140](#) shows the priority levels for the various files used by the Assembler.

**Figure 4.1 Files used with the Assembler**





## **Files**

*File Processing*

---

# Assembler Options

## Types of assembler options

The Assembler offers a number of assembler options that you can use to control the Assembler's operation. Options are composed of a dash/minus (-) followed by one or more letters or digits. Anything not starting with a dash/minus is supposed to be the name of a source file to be assembled. Assembler options may be specified on the command line or in the [ASMOPTIONS: Default assembler options \(Table 5.1 on page 143\)](#) environment variable. Typically, each Assembler option is specified only once per assembling session.

Command-line options are not case-sensitive. For example, "-Li" is the same as "-li". It is possible to coalescing options in the same group, i.e., one might also write "-Lci" instead of "-Lc -Li". However such a usage is not recommended as it make the command line less readable and it does also create the danger of name conflicts. For example "-Li -Lc" is not the same as "-LiC" because this is recognized as a separate, independent option on its own.

---

**NOTE** It is not possible to coalesce options in different groups, e.g., "-Lc -W1" *cannot* be abbreviated by the terms "-LC1" or "-LCW1".

---

**Table 5.1 ASMOPTIONS environment variable**

ASMOPTIONS	If this environment variable is set, the Assembler appends its contents to its command line each time a file is assembled. It can be used to globally specify certain options that should always be set, so you do not have to specify them each time a file is assembled.
------------	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

## Assembler Options

### Types of assembler options

---

Assembler options ([Table 5.2 on page 144](#)) are grouped by:

Output, Input, Language, Host, Code Generation, Messages, and Various.

**Table 5.2 Assembler option categories**

Group	Description
Output	Lists options related to the output files generation (which kind of file should be generated).
Input	Lists options related to the input files.
Language	Lists options related to the programming language (ANSI-C, C++, ...)
Host	Lists options related to the host.
Code Generation	Lists options related to code generation (memory models, ...).
Messages	Lists options controlling the generation of error messages.
Various	Lists various options.

The group corresponds to the property sheets of the graphical option settings.

Each option has also a scope ([Table 5.3 on page 144](#))

**Table 5.3 Scopes for assembler options**

Scope	Description
Application	This option has to be set for all files (assembly units) of an application. A typical example is an option to set the memory model. Mixing object files will have unpredictable results.
Assembly Unit	This option can be set for each assembling unit for an application differently. Mixing objects in an application is possible.
None	The scope option is not related to a specific code part. A typical example are options for the message management.

The options available are arranged into different groups, and a tab selection is available for each of these groups. The content of the list box depends upon the tab that is selected.



## Assembler Option details

The remainder of this section is devoted to describing each of the assembler options available for the Assembler. The options are listed in alphabetical order and each is divided into several sections ([Table 5.4 on page 145](#)).

**Table 5.4 Assembler option details**

Topic	Description
Group	Output, Input, Language, Host, Code Generation, Messages, or Various.
Scope	Application, Assembly Unit, Function, or None.
Syntax	Specifies the syntax of the option in an EBNF format.
Arguments	Describes and lists optional and required arguments for the option.
Default	Shows the default setting for the option.
Description	Provides a detailed description of the option and how to use it.
Example	Gives an example of usage, and effects of the option where possible. Assembler settings, source code and/or Linker PRM files are displayed where applicable. The examples shows an entry in the <code>default.env</code> for the PC or in the <code>.hidefaults</code> for UNIX.
See also (if needed)	Names related options.

## Using special modifiers

With some options it is possible to use special modifiers. However, some modifiers may not make sense for all options. This section describes those modifiers.

The following modifiers are supported ([Table 5.5 on page 145](#))

**Table 5.5 Special modifiers for assembler options**

Modifier	Description
%p	Path including file separator
%N	Filename in strict 8.3 format

## Assembler Options

### Assembler Option details

**Table 5.5 Special modifiers for assembler options (continued)**

Modifier	Description
%n	Filename without its extension
%E	Extension in strict 8.3 format
%e	Extension
%f	Path + filename without its extension
%"	A double quote (") if the filename, the path or the extension contains a space
%'	A single quote (') if the filename, the path, or the extension contains a space
%(ENV)	Replaces it with the contents of an environment variable
%%	Generates a single '%'

## Examples using special modifiers

The assumed path and filename (filename base for the modifiers) used for the examples Listing 5.2 through Listing 5.13 is displayed in [Listing 5.1 on page 146](#).

### Listing 5.1 Example filename and path used for the following examples

```
C:\Freescale\my_demo\TheWholeThing.myExt
```

Using the %p modifier as in [Listing 5.2 on page 146](#) displays the path with a file separator but without the filename.

### Listing 5.2 %p gives the path only with the final file separator

```
C:\Freescale\my_demo\
```

Using the %N modifier only displays the filename in 8.3 format but without the file extension ([Listing 5.3 on page 147](#)).

**Listing 5.3 %N results in the filename in 8.3 format (only the first 8 characters)**

---

```
TheWhole
```

---

The %n modifier returns the entire filename but with no file extension ([Listing 5.4 on page 147](#)).

**Listing 5.4 %n returns just the filename without the file extension**

---

```
TheWholeThing
```

---

Using %E as a modifier returns the first three characters in the file extension ([Listing 5.5 on page 147](#)).

**Listing 5.5 %E gives the file extension in 8.3 format (only the first 3 characters)**

---

```
myE
```

---

If you want the entire file extension, use the %e modifier ([Listing 5.6 on page 147](#)).

**Listing 5.6 %e is used for returning the whole extension**

---

```
myExt
```

---

The %f modifier returns the path and the filename but without the file extension ([Listing 5.7 on page 147](#)).

**Listing 5.7 %f gives the path plus the filename (no file extension)**

---

```
C:\Freescale\my demo\TheWholeThing
```

---

## Assembler Options

### Assembler Option details

---

The path in [Listing 5.1 on page 146](#) contains a space, therefore using %" or %' is recommended  
([Listing 5.8 on page 148](#) or [Listing 5.9 on page 148](#)).

#### Listing 5.8 Use %"%f%" in case there is a space in its path, filename, or extension

---

```
"C:\Freescale\my demo\TheWholeThing"
```

---

#### Listing 5.9 Use %'%f%' where there is a space in its path, filename, or extension

---

```
'C:\Freescale\my demo\TheWholeThing'
```

---

Using % (envVariable) an environment variable may be used. A file separator following % (envVariable) is ignored if the environment variable is empty or does not exist. If TEXTPATH is set as in [Listing 5.10 on page 148](#), then \$(TEXTPATH)\myfile.txt is expressed as in [Listing 5.11 on page 148](#).

#### Listing 5.10 Example for setting TEXTPATH

---

```
TEXTPATH=C:\Freescale\txt
```

---

#### Listing 5.11 \$(TEXTPATH)\myfile.txt where TEXTPATH is defined

---

```
C:\Freescale\txt\myfile.txt
```

---

However, if TEXTPATH does not exist or is empty, then \$(TEXTPATH)\myfile.txt is expressed as in [Listing 5.12 on page 148](#).

#### Listing 5.12 \$(TEXTPATH)\myfile.txt where TEXTPATH does not exist

---

```
myfile.txt
```

---

It is also possible to display the percent sign by using `%%. %e%` allows the expression of a percent sign after the extension as in [Listing 5.13 on page 149](#).

**Listing 5.13 %% allows a percent sign to be expressed**

---

```
myExt%
```

---

## List of Assembler options

The following table lists each command line option you can use with the Assembler ([Table 5.6 on page 149](#)).

**Table 5.6 Assembler options**

Assembler option
<a href="#">-Ci: Switch case sensitivity on label names OFF on page 152</a>
<a href="#">-CMacAngBrack: Angle brackets for grouping Macro Arguments on page 154</a>
<a href="#">-CMacBrackets: Square brackets for macro arguments grouping on page 155</a>
<a href="#">-Compat: Compatibility modes on page 156</a>
<a href="#">-CS08/-C08/-CRS08: Derivative family on page 159</a>
<a href="#">-D: Define Label on page 161</a>
<a href="#">-Env: Set environment variable on page 163</a>
<a href="#">-F (-Fh, -F2o, -FA2o, -F2, -FA2): Output-file format on page 164</a>
<a href="#">-H: Short Help on page 166</a>
<a href="#">-I: Include file path on page 167</a>
<a href="#">-L: Generate a listing file on page 168</a>
<a href="#">-Lasmc: Configure listing file on page 171</a>
<a href="#">-Lasms: Configure the address size in the listing file on page 173</a>
<a href="#">-Lc: No Macro call in listing file on page 175</a>
<a href="#">-Ld: No macro definition in listing file on page 178</a>

## Assembler Options

List of Assembler options

Table 5.6 Assembler options (*continued*)

Assembler option
<a href="#">-Le: No Macro expansion in listing file on page 181</a>
<a href="#">-Li: No included file in listing file on page 184</a>
<a href="#">-Lic: License information on page 186</a>
<a href="#">-LicA: License information about every feature in directory on page 187</a>
<a href="#">-LicBorrow: Borrow license feature on page 188</a>
<a href="#">-LicWait: Wait until floating license is available from floating License Server on page 190</a>
<a href="#">-Ll: Show label statistics on page 191</a>
<a href="#">-M (-Ms, -Mt): Memory model on page 193</a>
<a href="#">-MacroNest: Configure maximum macro nesting on page 195</a>
<a href="#">-MCUasm: Switch compatibility with MCUasm ON on page 196</a>
<a href="#">-N: Display notify box on page 197</a>
<a href="#">-NoBeep: No beep in case of an error on page 198</a>
<a href="#">-NoDebugInfo: No debug information for ELF/DWARF files on page 199</a>
<a href="#">-NoEnv: Do not use environment on page 200</a>
<a href="#">-ObjN: Object filename specification on page 201</a>
<a href="#">-Prod: Specify project file at startup on page 203</a>
<a href="#">-Struct: Support for structured types on page 204</a>
<a href="#">-V: Prints the Assembler version on page 205</a>
<a href="#">-View: Application standard occurrence on page 206</a>
<a href="#">-W1: No information messages on page 208</a>
<a href="#">-W2: No information and warning messages on page 209</a>
<a href="#">-WErrFile: Create "err.log" error file on page 210</a>
<a href="#">-Wmsg8x3: Cut filenames in Microsoft format to 8.3 on page 211</a>
<a href="#">-WmsgCE: RGB color for error messages on page 212</a>
<a href="#">-WmsgCF: RGB color for fatal messages on page 213</a>

**Table 5.6 Assembler options (continued)**

<b>Assembler option</b>
<a href="#">-WmsgCI: RGB color for information messages on page 214</a>
<a href="#">-WmsgCU: RGB color for user messages on page 215</a>
<a href="#">-WmsgCW: RGB color for warning messages on page 216</a>
<a href="#">-WmsgFb (-WmsgFbv, -WmsgFbm): Set message file format for batch mode on page 217</a>
<a href="#">-WmsgFi (-WmsgFiv, -WmsgFim): Set message file format for interactive mode on page 219</a>
<a href="#">-WmsgFob: Message format for batch mode on page 221</a>
<a href="#">-WmsgFoi: Message format for interactive mode on page 223</a>
<a href="#">-WmsgFonf: Message format for no file information on page 225</a>
<a href="#">-WmsgFonp: Message format for no position information on page 227</a>
<a href="#">-WmsgNe: Number of error messages on page 229</a>
<a href="#">-WmsgNi: Number of Information messages on page 230</a>
<a href="#">-WmsgNu: Disable user messages on page 231</a>
<a href="#">-WmsgNw: Number of Warning messages on page 233</a>
<a href="#">-WmsgSd: Setting a message to disable on page 234</a>
<a href="#">-WmsgSe: Setting a message to Error on page 235</a>
<a href="#">-WmsgSi: Setting a message to Information on page 236</a>
<a href="#">-WmsgSw: Setting a Message to Warning on page 237</a>
<a href="#">-WOutFile: Create error listing file on page 238</a>
<a href="#">-WStdout: Write to standard output on page 239</a>

## Detailed listing of all assembler options

The remainder of the chapter is a detailed listing of all assembler options arranged in alphabetical order.

## Assembler Options

*Detailed listing of all assembler options*

---

### **-Ci: Switch case sensitivity on label names OFF**

#### **Group**

Input

#### **Scope**

Assembly Unit

#### **Syntax**

-Ci

#### **Arguments**

None

#### **Default**

None

#### **Description**

This option turns off case sensitivity on label names. When this option is activated, the Assembler ignores case sensitivity for label names. If the Assembler generates object files but not absolute files directly (-FA2 assembler option), the case of exported or imported labels must still match. Or, the -Ci assembler option should be specified in the linker as well.



### Example

When case sensitivity on label names is switched off, the Assembler will not generate an error message for the assembly source code in [Listing 5.14 on page 153](#).

#### Listing 5.14 Example assembly source code

---

```
ORG $200
entry: NOP
      BRA Entry
```

---

The instruction 'BRA Entry' branches on the 'entry' label. The default setting for case sensitivity is ON, which means that the Assembler interprets the labels 'Entry' and 'entry' as two distinct labels.

### See also

[-F \(-Fh, -F2o, -FA2o, -F2, -FA2\): Output-file format on page 164](#) assembler option

## Assembler Options

Detailed listing of all assembler options

---

# -CMacAngBrack: Angle brackets for grouping Macro Arguments

### Group

Language

### Scope

Application

### Syntax

-CMacAngBrack (ON|OFF)

### Arguments

ON or OFF

### Default

None

### Description

This option controls whether the < > syntax for macro invocation argument grouping is available. When it is disabled, the Assembler does not recognize the special meaning for < in the macro invocation context. There are cases where the angle brackets are ambiguous. New code should use the [? ?] syntax instead.

### See also

[Macro argument grouping](#)

[-CMacBrackets: Square brackets for macro arguments grouping on page 155](#)  
option

## **-CMacBrackets: Square brackets for macro arguments grouping**

### **Group**

Language

### **Scope**

Application

### **Syntax**

`-CMacBrackets (ON|OFF)`

### **Arguments**

ON or OFF

### **Default**

ON

### **Description**

This option control whether the [? ?] syntax for macro invocation argument grouping is available. When it is disabled, the Assembler does not recognize the special meaning for [? in the macro invocation context.

### **See also**

[Macro argument grouping](#)

[-CMacAngBrack: Angle brackets for grouping Macro Arguments on page 154](#)  
option

## Assembler Options

Detailed listing of all assembler options

---

### -Compat: Compatibility modes

#### Group

Language

#### Scope

Application

#### Syntax

-Compat [= { ! | = | c | s | f | \$ | a | b }]

#### Arguments

See below.

#### Default

None

#### Description

This option controls some compatibility enhancements of the Assembler. The goal is not to provide 100% compatibility with any other Assembler but to make it possible to reuse as much as possible. The various suboptions control different parts of the assembly:

- =: Operator != means equal

The Assembler takes the default value of the != operator as *not equal*, as it is in the C language. For compatibility, this behavior can be changed to *equal* with this option. Because the danger of this option for existing code, a message is issued for every != which is treated as *equal*.

- !: Support additional ! operators

The following additional operators are defined when this option is used:

- !^: exponentiation
- !m: modulo
- !@: signed greater or equal
- !g: signed greater

- !%: signed less or equal
- !t: signed less than
- !\$: unsigned greater or equal
- !S: unsigned greater
- !&: unsigned less or equal
- !l: unsigned less
- !n: one complement
- !w: low operator
- !h: high operator

---

**NOTE** The default values for the following ! operators are defined:

- !.: binary AND
- !x: exclusive OR
- !+: binary OR

---

- c: Alternate comment rules

With this suboption, comments implicitly start when a space is present after the argument list. A special character is not necessary. Be careful with spaces when this option is given because part of the intended arguments may be taken as a comment. However, to avoid accidental comments, the Assembler does issue a warning if such a comment does not start with a "\*" or a ";".

## Examples

[Listing 5.15 on page 157](#) demonstrates that when `-Compat=c`, comments can start with a `*`.

### Listing 5.15 Comments starting with an asterisk (\*)

---

```
NOP * Anything following an asterisk is a comment.
```

---

When the `-Compat=c` assembler option is used, the first `DC.B` directive in [Listing 5.16 on page 158](#) has `" + 1 , 1"` as a comment. A warning is issued because the "comment" does not start with a ";" or a "\*". With `-Compat=c`, this code generates a warning and three bytes with constant values 1, 2, and 1. Without it, this code generates four 8-bit constants of 2, 1, 2, and 1.

## Assembler Options

*Detailed listing of all assembler options*

---

### Listing 5.16 Implicit comment start after a space

---

```
DC.B 1 + 1 , 1
DC.B 1+1,1
```

---

- **s**: Symbol prefixes  
With this suboption, some compatibility prefixes for symbols are supported. With this option, the Assembler accepts "pgz:" and "byte:" prefixed for symbols in XDEFs and XREFs. They correspond to XREF.B or XDEF.B with the same symbols without the prefix.
- **f**: Ignore FF character at line start  
With this suboption, an otherwise improper character recognized from feed character is ignored.
- **\$**: Support the \$ character in symbols  
With this suboption, the Assembler supports to start identifiers with a \$ sign.
- **a**: Add some additional directives  
With this suboption, some additional directives are added for enhanced compatibility.  
The Assembler actually supports a SECT directive as an alias of the usual [SECTION - Declare Relocatable Section](#) assembly directive. The SECT directive takes the section name as its first argument.
- **b**: support the FOR directive  
With this suboption, the Assembler supports a [FOR - Repeat assembly block](#) assembly directive to generate repeated patterns more easily without having to use recursive macros.

## **-CS08/-C08/-CRS08: Derivative family**

### **Group**

Code Generation

### **Scope**

Application

### **Syntax**

-C08 | -CS08 | -CRS08

### **Arguments**

none

### **Default**

-C08

### **Description**

The Assembler supports 3 different HC08 derived cores. The HC08 itself (-C08), the enhanced HCS08 (-CS08) and the reduced RS08 (-CRS08).

The HCS08 family supports additional addressing modes for the CPHX, LDHX, and STHX instructions and also a new BGND instruction. All these enhancements are allowed when the -CS08 option is specified. All instructions and addressing modes available for the HC08 are also available for the HCS08 so that this core remains binary compatible with its predecessor.

The RS08 family does not support all instructions and addressing modes of the HC08. Also, the encoding of the supported instructions is not binary compatible.

## Assembler Options

Detailed listing of all assembler options

---

**Table 5.7** Table of new instructions or addressing modes for the HCS08

<b>Instruction</b>	<b>Addr. mode</b>	<b>Description</b>
LDHX	EXT IX IX1 IX2 SP1	load from a 16-bit absolute address load HX via 0,X load HX via 1,X...255,X load HX via old HX+ any offset load HX from stack
STHX	EXT SP1	store HX to a 16-bit absolute address store HX to stack
CPHX	EXT SP1	compare HX with a 16-bit address compare HX with the stack
BGND		enter the Background Debug Mode



## **-D: Define Label**

### **Group**

Input

### **Scope**

Assembly Unit

### **Syntax**

`-D<LabelName> [=<Value>]`

### **Arguments**

`<LabelName>`: Name of label.

`<Value>`: Value for label. 0 if not present.

### **Default**

0 for Value.

### **Description**

This option behaves as if a “Label: EQU Value” would be at the start of the main source file. When no explicit value is given, 0 is used as the default.

This option can be used to build different versions with one common source file.

### **Example**

Conditional inclusion of a copyright notice. See [Listing 5.17 on page 161](#) and [Listing 5.18 on page 162](#).

#### **Listing 5.17 Source code that conditionally includes a copyright notice**

---

```
YearAsString: MACRO
    DC.B $30+(\1 /1000)%10
    DC.B $30+(\1 / 100)%10
    DC.B $30+(\1 / 10)%10
    DC.B $30+(\1 / 1)%10
ENDM
```

## Assembler Options

Detailed listing of all assembler options

---

```
ifdef ADD_COPYRIGHT
  ORG $1000
  DC.B "Copyright by "
  DC.B "John Doe"
ifdef YEAR
  DC.B " 1999-"
  YearAsString YEAR
endif
  DC.B 0
endif
```

---

When assembled with the option "-dADD\_COPYRIGHT -dYEAR=2005",  
[Listing 5.18 on page 162](#) is generated:

### Listing 5.18 Generated list file

---

```
1 1 YearAsString: MACRO
2 2 DC.B $30+(\1 /1000)%10
3 3 DC.B $30+(\1 / 100)%10
4 4 DC.B $30+(\1 / 10)%10
5 5 DC.B $30+(\1 / 1)%10
6 6 ENDM
7 7
8 8 0000 0001 ifdef ADD_COPYRIGHT
9 9 ORG $1000
10 10 a001000 436F 7079 DC.B "Copyright by "
    001004 7269 6768
    001008 7420 6279
    00100C 20
11 11 a00100D 4A6F 686E DC.B "John Doe"
    001011 2044 6F65
12 12 0000 0001 ifdef YEAR
13 13 a001015 2031 3939 DC.B " 1999-"
    001019 392D
14 14 YearAsString YEAR
15 2m a00101B 32 + DC.B $30+(YEAR /1000)%10
16 3m a00101C 30 + DC.B $30+(YEAR / 100)%10
17 4m a00101D 30 + DC.B $30+(YEAR / 10)%10
18 5m a00101E 31 + DC.B $30+(YEAR / 1)%10
19 15 endif
20 16 a00101F 00 DC.B 0
21 17 endif
```

---

## **-Env: Set environment variable**

### **Group**

Host

### **Scope**

Assembly Unit

### **Syntax**

`-Env<EnvironmentVariable>=<VariableSetting>`

### **Arguments**

`<EnvironmentVariable>`: Environment variable to be set  
`<VariableSetting>`: Setting of the environment variable

### **Default**

None

### **Description**

This option sets an environment variable.

### **Example**

```
ASMOPTIONS=-EnvOBJPATH=\sources\obj
```

This is the same as:

```
OBJPATH=\sources\obj
```

in the `default.env` file.

### **See also**

[“Environment variables details” on page 121](#)

## Assembler Options

*Detailed listing of all assembler options*

---

### **-F (-Fh, -F2o, -FA2o, -F2, -FA2): Output-file format**

#### **Group**

Output

#### **Scope**

Application

#### **Syntax**

`-F (h | 2o | A2o | 2 | A2)`

#### **Arguments**

`h`: HIWARE object-file format; this is the default

`2o`: Compatible ELF/DWARF 2.0 object-file format

`A2o`: Compatible ELF/DWARF 2.0 absolute-file format

`2`: ELF/DWARF 2.0 object-file format

`A2`: ELF/DWARF 2.0 absolute-file format

#### **Default**

`-F2`

#### **Description**

Defines the format for the output file generated by the Assembler:

- With the `-Fh` option set, the Assembler uses a proprietary (HIWARE) object-file format.
- With the `-F2` option set, the Assembler produces an ELF/DWARF object file. This object-file format may also be supported by other Compiler or Assembler vendors.
- With the `-FA2` option set, the Assembler produces an ELF/DWARF absolute file. This file format may also be supported by other Compiler or Assembler vendors.

Note that the ELF/DWARF 2.0 file format has been updated in the current version of the Assembler. If you are using HI-WAVE version 5.2 (or an earlier version),

-F2 $\circ$  or -FA2 $\circ$  must be used to generate the ELF/DWARF 2.0 object files which can be loaded in the debugger.

**Example**

```
ASMOPTIONS=-F2
```

---

**NOTE** For the RS08 the HIWARE object file format is not available.

---

## Assembler Options

Detailed listing of all assembler options

---

### -H: Short Help

#### Group

Various

#### Scope

None

#### Syntax

-H

#### Arguments

None

#### Default

None

#### Description

The -H option causes the Assembler to display a short list (i.e., help list) of available options within the assembler window. Options are grouped into Output, Input, Language, Host, Code Generation, Messages, and Various.

No other option or source files should be specified when the -H option is invoked.

#### Example

[Listing 5.19 on page 166](#) is a portion of the list produced by the -H option:

#### Listing 5.19 Example Help listing

---

```
...
MESSAGE:
-N          Show notification box in case of errors
-NoBeep    No beep in case of an error
-W1        Do not print INFORMATION messages
-W2        Do not print INFORMATION or WARNING messages
-WErrFile  Create "err.log" Error File
...
```

---

## **-I: Include file path**

### **Group**

Input

### **Scope**

None

### **Syntax**

`-I<path>`

### **Arguments**

`<path>`: File path to be used for includes

### **Default**

None

### **Description**

With the `-I` option it is possible to specify a file path used for include files.

### **Example**

`-Id:\mySources\include`

## Assembler Options

Detailed listing of all assembler options

---

### -L: Generate a listing file

#### Group

Output

#### Scope

Assembly unit

#### Syntax

-L [=<dest>]

#### Arguments

<dest>: the name of the listing file to be generated.

It may contain special modifiers (see [“Using special modifiers” on page 145](#)).

#### Default

No generated listing file

#### Description

Switches on the generation of the listing file. If `dest` is not specified, the listing file will have the same name as the source file, but with extension `*.lst`. The listing file contains macro definition, invocation, and expansion lines as well as expanded include files.

#### Example

```
ASMOPTIONS=-L
```

In the following example of assembly code ([Listing 5.20 on page 169](#)), the `cpChar` macro accepts two parameters. The macro copies the value of the first parameter to the second one.

When the `-L` option is specified, the portion of assembly source code in [Listing 5.20 on page 169](#), together with the code from an include file ([Listing 5.21 on page 169](#)) generates the output listing in [Listing 5.22 on page 169](#).



**Listing 5.20 Example assembly source code**

```

                XDEF Start
MyData: SECTION
char1: DS.B 1
char2: DS.B 1
                INCLUDE "macro.inc"
CodeSec: SECTION
Start:
                cpChar char1, char2
                NOP

```

**Listing 5.21 Example source code from an include file**

```

cpChar: MACRO
        LDA \1
        STA \2
        ENDM

```

**Listing 5.22 Assembly output listing**

Abs.	Rel.	Loc	Obj. code	Source line
----	----	----	-----	-----
1	1			XDEF Start
2	2			MyData: SECTION
3	3	000000		char1: DS.B 1
4	4	000001		char2: DS.B 1
5	5			INCLUDE "macro.inc"
6	1i			cpChar: MACRO
7	2i			LDA \1
8	3i			STA \2
9	4i			ENDM
10	6			CodeSec: SECTION
11	7			Start:
12	8			cpChar char1, char2
13	2m	000000	C6 xxxx +	LDA char1
14	3m	000003	C7 xxxx +	STA char2
15	9	000006	9D	NOP

The Assembler stores the content of included files in the listing file. The Assembler also stores macro definitions, invocations, and expansions in the listing file.

## Assembler Options

*Detailed listing of all assembler options*

---

For a detailed description of the listing file, see the [Assembler Listing File](#) chapter.

### See also

#### Assembler options:

- [-Lasmc: Configure listing file on page 171](#)
- [-Lasms: Configure the address size in the listing file on page 173](#)
- [-Lc: No Macro call in listing file on page 175](#)
- [-Ld: No macro definition in listing file on page 178](#)
- [-Le: No Macro expansion in listing file on page 181](#)
- [-Li: No included file in listing file on page 184](#)

## **-Lasmc: Configure listing file**

### **Group**

Output

### **Scope**

Assembly unit

### **Syntax**

`-Lasmc={s|r|m|l|k|i|c|a}`

### **Arguments**

- s - Do not write the source column
- r - Do not write the relative column (Rel.)
- m - Do not write the macro mark
- l - Do not write the address (Loc)
- k - Do not write the location type
- i - Do not write the include mark column
- c - Do not write the object code
- a - Do not write the absolute column (Abs.)

### **Default**

Write all columns.

### **Description**

The default-configured listing file shows a lot of information. With this option, the output can be reduced to columns which are of interest. This option configures which columns are printed in a listing file. To configure which lines to print, see the following assembler options: [-Lc: No Macro call in listing file on page 175](#), [-Ld: No macro definition in listing file on page 178](#), [-Le: No Macro expansion in listing file on page 181](#), and [-Li: No included file in listing file on page 184](#).

## Assembler Options

Detailed listing of all assembler options

---

### Example

For the following assembly source code, the Assembler generates the default-configured output listing ([Listing 5.23 on page 172](#)):

```
DC.B "Hello World"  
DC.B 0
```

### Listing 5.23 Example assembler output listing

---

Abs.	Rel.	Loc	Obj. code	Source line
----	----	-----	-----	-----
1	1	000000	4865 6C6C	DC.B "Hello World"
		000004	6F20 576F	
		000008	726C 64	
2	2	00000B	00	DC.B 0

---

In order to get this output without the source file line numbers and other irrelevant parts for this simple DC.B example, the following option is added:

"-Lasmc=ramki". This generates the output listing in [Listing 5.24 on page 172](#):

### Listing 5.24 Example output listing

---

Loc	Obj. code	Source line
-----	-----	-----
000000	4865 6C6C	DC.B "Hello World"
000004	6F20 576F	
000008	726C 64	
00000B	00	DC.B 0

---

For a detailed description of the listing file, see the [Assembler Listing File](#) chapter.

### See also

#### Assembler options:

- [-L: Generate a listing file on page 168](#)
- [-Lc: No Macro call in listing file on page 175](#)
- [-Ld: No macro definition in listing file on page 178](#)
- [-Le: No Macro expansion in listing file on page 181](#)
- [-Li: No included file in listing file on page 184](#)
- [-Lasms: Configure the address size in the listing file on page 173](#)

## **-Lasms: Configure the address size in the listing file**

### **Group**

Output

### **Scope**

Assembly unit

### **Syntax**

`-Lasms { 1 | 2 | 3 | 4 }`

### **Arguments**

- 1 - The address size is xx
- 2 - The address size is xxxx
- 3 - The address size is xxxxxx
- 4 - The address size is xxxxxxxx

### **Default**

`-Lasms3`

### **Description**

The default-configured listing file shows a lot of information. With this option, the size of the address column can be reduced to the size of interest. To configure which columns are printed, see the [-Lasmc: Configure listing file on page 171](#) option. To configure which lines to print, see the [-Lc: No Macro call in listing file on page 175](#), [-Ld: No macro definition in listing file on page 178](#), [-Le: No Macro expansion in listing file on page 181](#), and [-Li: No included file in listing file on page 184](#) assembler options.

### **Example**

For the following instruction:

NOP

## Assembler Options

Detailed listing of all assembler options

---

the Assembler generates this default-configured output listing ([Listing 5.25 on page 174](#)):

### Listing 5.25 Example assembler output listing

---

Abs.	Rel.	Loc	Obj. code	Source line
-----	-----	-----	-----	-----
1	1	000000	XX	NOP

---

In order to change the size of the address column the following option is added: "-Lasms1". This changes the address size to two digits.

### Listing 5.26 Example assembler output listing configured with -Lasms1

---

Abs.	Rel.	Loc	Obj. code	Source line
-----	-----	-----	-----	-----
1	1	00	XX	NOP

---

### See also

[Assembler Listing File](#) chapter

Assembler options:

- [-Lasmc: Configure listing file on page 171](#)
- [-L: Generate a listing file on page 168](#)
- [-Lc: No Macro call in listing file on page 175](#)
- [-Ld: No macro definition in listing file on page 178](#)
- [-Le: No Macro expansion in listing file on page 181](#)
- [-Li: No included file in listing file on page 184](#)

## **-Lc: No Macro call in listing file**

### **Group**

Output

### **Scope**

Assembly unit

### **Syntax**

-Lc

### **Arguments**

none

### **Default**

none

### **Description**

Switches on the generation of the listing file, but macro invocations are not present in the listing file. The listing file contains macro definition and expansion lines as well as expanded include files.

### **Example**

```
ASMOPTIONS=-Lc
```

In the following example of assembly code, the `cpChar` macro accept two parameters. The macro copies the value of the first parameter to the second one.

When the `-Lc` option is specified, the following portion of assembly source code in [Listing 5.27 on page 175](#):

#### **Listing 5.27 Example assembly source code**

---

```
                XDEF Start
MyData: SECTION
char1: DS.B 1
char2: DS.B 1
```

## Assembler Options

Detailed listing of all assembler options

---

```
        INCLUDE "macro.inc"
CodeSec: SECTION
Start:
        cpChar char1, char2
        NOP
```

---

along with additional source code ([Listing 5.28 on page 176](#)) from the `macro.inc` include file generates the following output in the assembly listing file ([Listing 5.29 on page 176](#)):

### Listing 5.28 Example source code from the macro.inc file

---

```
cpChar:  MACRO
         LDA \1
         STA \2
        ENDM
```

---

### Listing 5.29 Output assembly listing

---

Abs.	Rel.	Loc	Obj. code	Source line
----	----	----	-----	-----
1	1			XDEF Start
2	2			MyData: SECTION
3	3	000000		char1: DS.B 1
4	4	000001		char2: DS.B 1
5	5			INCLUDE "macro.inc"
6	1i			cpChar: MACRO
7	2i			LDA \1
8	3i			STA \2
9	4i			ENDM
10	6			CodeSec: SECTION
11	7			Start:
13	2m	000000	C6 xxxx	+ LDA char1
14	3m	000003	C7 xxxx	+ STA char2
15	9	000006	9D	NOP

---

The Assembler stores the content of included files in the listing file. The Assembler also stores macro definitions, invocations, and expansions in the listing file.

The listing file does not contain the line of source code that invoked the macro.

For a detailed description of the listing file, see the [Assembler Listing File](#) chapter.

---



**See also**

**Assembler options:**

- [-L: Generate a listing file on page 168](#)
- [-Ld: No macro definition in listing file on page 178](#)
- [-Le: No Macro expansion in listing file on page 181](#)
- [-Li: No included file in listing file on page 184](#)

## Assembler Options

Detailed listing of all assembler options

---

### -Ld: No macro definition in listing file

#### Group

Output

#### Scope

Assembly unit

#### Syntax

-Ld

#### Arguments

None

#### Default

None

#### Description

Instructs the Assembler to generate a listing file but not including any macro definitions. The listing file contains macro invocation and expansion lines as well as expanded include files.

#### Example

```
ASMOPTIONS=-Ld
```

In the following example of assembly code, the `cpChar` macro accepts two parameters. The macro copies the value of the first parameter to the second one.

When the `-Ld` option is specified, the assembly source code in [Listing 5.30 on page 178](#) along with additional source code ([Listing 5.31 on page 179](#)) from the `macro.inc` file generates an assembler output listing ([Listing 5.32 on page 179](#)) file:

#### Listing 5.30 Example assembly source code

---

```
                XDEF  Start
MyData:        SECTION
char1:         DS.B  1
char2:         DS.B  1
```

---

```
        INCLUDE "macro.inc"
CodeSec: SECTION
Start:
        cpChar char1, char2
        NOP
```

---

**Listing 5.31 Example source code from an include file**

---

```
cpChar: MACRO
        LDA  \1
        STA  \2
ENDM
```

---

**Listing 5.32 Example assembler output listing**

---

Abs.	Rel.	Loc	Obj.	code	Source line
1	1				XDEF Start
2	2				MyData: SECTION
3	3	000000			char1: DS.B 1
4	4	000001			char2: DS.B 1
5	5				INCLUDE "macro.inc"
6	1i				cpChar: MACRO
10	6				CodeSec: SECTION
11	7				Start:
12	8				cpChar char1, char2
13	2m	000000	C6	xxxx +	LDA char1
14	3m	000003	C7	xxxx +	STA char2
15	9	000006	9D		NOP

---

The Assembler stores that content of included files in the listing file. The Assembler also stores macro invocation and expansion in the listing file.

The listing file does not contain the source code from the macro definition.

For a detailed description of the listing file, see the [Assembler Listing File](#) chapter.

**See also**

**Assembler options:**

- [-L: Generate a listing file on page 168](#)
- [-Lc: No Macro call in listing file on page 175](#)
- [-Le: No Macro expansion in listing file on page 181](#)

## Assembler Options

*Detailed listing of all assembler options*

---

- [-Li: No included file in listing file on page 184](#)

## **-Le: No Macro expansion in listing file**

### **Group**

Output

### **Scope**

Assembly unit

### **Syntax**

-Le

### **Arguments**

None

### **Default**

None

### **Description**

Switches on the generation of the listing file, but macro expansions are not present in the listing file. The listing file contains macro definition and invocation lines as well as expanded include files.

### **Example**

```
ASMOPTIONS=-Le
```

In the following example of assembly code, the `cpChar` macro accepts two parameters. The macro copies the value of the first parameter to the second one.

When the `-Le` option is specified, the assembly code in [Listing 5.33 on page 181](#) along with additional source code ([Listing 5.34 on page 182](#)) from the `macro.inc` file generates an assembly output listing file ([Listing 5.35 on page 182](#)):

#### **Listing 5.33 Example assembly source code**

---

```
XDEF Start
MyData: SECTION
char1: DS.B 1
```

---

## Assembler Options

Detailed listing of all assembler options

---

```
char2:   DS.B 1
        INCLUDE "macro.inc"
CodeSec: SECTION
Start:
        cpChar char1, char2
        NOP
```

---

### Listing 5.34 Example source code from an included file

---

```
cpChar:  MACRO
        LDA  \1
        STA  \2
        ENDM
```

---

### Listing 5.35 Example assembler output listing

---

Abs. Rel.	Loc	Obj. code	Source line
----	----	-----	-----
1	1		XDEF Start
2	2		MyData: SECTION
3	3	000000	char1: DS.B 1
4	4	000001	char2: DS.B 1
5	5		INCLUDE "macro.inc"
6	1i		cpChar: MACRO
7	2i		LDA \1
8	3i		STA \2
9	4i		ENDM
10	6		CodeSec: SECTION
11	7		Start:
12	8		cpChar char1, char2
15	9	000006 9D	NOP

---

The Assembler stores the content of included files in the listing file. The Assembler also stores the macro definition and invocation in the listing file.

The Assembler does not store the macro expansion lines in the listing file.

For a detailed description of the listing file, see the [Assembler Listing File](#) chapter.

### See also

[-L: Generate a listing file on page 168](#)

[-Lc: No Macro call in listing file on page 175](#)

## **Assembler Options**

*Detailed listing of all assembler options*

---

[-Ld: No macro definition in listing file on page 178-Li: No included file in listing file on page 184](#)

## Assembler Options

Detailed listing of all assembler options

---

### -Li: No included file in listing file

#### Group

Output

#### Scope

Assembly unit

#### Syntax

-Li

#### Arguments

None

#### Default

None

#### Description

Switches on the generation of the listing file, but include files are not expanded in the listing file. The listing file contains macro definition, invocation, and expansion lines.

#### Example

```
ASMOPTIONS=-Li
```

In the following example of assembly code, the `cpChar` macro accepts two parameters. The macro copies the value of the first parameter to the second one.

When `-Li` option is specified, the assembly source code in [Listing 5.36 on page 184](#) along with additional source code ([Listing 5.37 on page 185](#)) from the `macro.inc` file generates the following output in the assembly listing file:

#### Listing 5.36 Example assembly source code

---

```
MyData: XDEF Start
SECTION DS.B 1
char1:  DS.B 1
char2:  DS.B 1
INCLUDE "macro.inc"
```



```
CodeSec: SECTION
Start:
    cpChar char1, char2
    NOP
```

---

**Listing 5.37 Example source code in an include file**

---

```
cpChar:  MACRO
        LDA  \1
        STA  \2
        ENDM
```

---

**Listing 5.38 Example assembler output listing**

---

Abs.	Rel.	Loc	Obj. code	Source line
1	1			XDEF Start
2	2			MyData: SECTION
3	3	000000		char1: DS.B 1
4	4	000001		char2: DS.B 1
5	5			INCLUDE "macro.inc"
10	6			CodeSec: SECTION
11	7			Start:
12	8			cpChar char1, char2
13	2m	000000	C6 xxxx +	LDA char1
14	3m	000003	C7 xxxx +	STA char2
15	9	000006	9D	NOP

---

The Assembler stores the macro definition, invocation, and expansion in the listing file.

The Assembler does not store the content of included files in the listing file.

For a detailed description of the listing file, see the [Assembler Listing File](#) chapter.

**See also**

**Assembler options:**

- [-L: Generate a listing file on page 168](#)
- [-Lc: No Macro call in listing file on page 175](#)
- [-Ld: No macro definition in listing file on page 178](#)
- [-Le: No Macro expansion in listing file on page 181](#)

## Assembler Options

Detailed listing of all assembler options

---

### -Lic: License information

#### Group

Various

#### Scope

None

#### Syntax

-Lic

#### Arguments

None

#### Default

None

#### Description

The -Lic option prints the current license information (e.g., if it is a demo version or a full version). This information is also displayed in the About... box.

#### Example

```
ASMOPTIONS=-Lic
```

#### See also

##### Assembler options:

- [-LicA: License information about every feature in directory on page 187](#)
- [-LicBorrow: Borrow license feature on page 188](#)
- [-LicWait: Wait until floating license is available from floating License Server on page 190](#)

## **-LicA: License information about every feature in directory**

### **Group**

Various

### **Scope**

None

### **Syntax**

`-LicA`

### **Arguments**

None

### **Default**

None

### **Description**

The `-LicA` option prints the license information of every tool or DLL in the directory where the executable is (e.g., if tool or feature is a demo version or a full version). Because the option has to analyze every single file in the directory, this may take a long time.

### **Example**

```
ASMOPTIONS=-LicA
```

### **See also**

#### **Assembler options:**

- [-Lic: License information on page 186](#)
- [-LicBorrow: Borrow license feature on page 188](#)
- [-LicWait: Wait until floating license is available from floating License Server on page 190](#)

## Assembler Options

*Detailed listing of all assembler options*

---

### **-LicBorrow: Borrow license feature**

#### **Group**

Host

#### **Scope**

None

#### **Syntax**

`-LicBorrow<feature> [;<version>] :<Date>`

#### **Arguments**

`<feature>`: the feature name to be borrowed (e.g., HI100100).

`<version>`: optional version of the feature to be borrowed (e.g., 3.000).

`<date>`: date with optional time until when the feature shall be borrowed (e.g., 15-Mar-2005:18:35).

#### **Default**

None

#### **Defines**

None

#### **Pragmas**

None

#### **Description**

This option lets you borrow a license feature until a given date/time. Borrowing allows you to use a floating license even if disconnected from the floating license server.

You need to specify the feature name and the date until you want to borrow the feature. If the feature you want to borrow is a feature belonging to the tool where you use this option, then you do not need to specify the version of the feature (because the tool is aware of the version). However, if you want to borrow any feature, you need to specify the feature's version number.

You can check the status of currently borrowed features in the tool's About . . . box.

---

**NOTE** You only can borrow features if you have a floating license and if your floating license is enabled for borrowing. See the provided FLEXlm documentation about details on borrowing.

---

### **Example**

```
-LicBorrowHI100100;3.000:12-Mar-2005:18:25
```

### **See also**

#### **Assembler options:**

- [-Lic: License information on page 186](#)
- [-LicA: License information about every feature in directory on page 187](#)
- [-LicWait: Wait until floating license is available from floating License Server on page 190](#)

## Assembler Options

Detailed listing of all assembler options

---

### **-LicWait: Wait until floating license is available from floating License Server**

#### **Group**

Host

#### **Scope**

None

#### **Syntax**

`-LicWait`

#### **Arguments**

None

#### **Default**

None

#### **Description**

If a license is not available from the floating license server, then the default condition is that the application will immediately return. With the `-LicWait` assembler option set, the application will wait (blocking) until a license is available from the floating license server.

#### **Example**

```
ASMOPTIONS=-LicWait
```

#### **See also**

##### **Assembler options:**

- [-Lic: License information on page 186](#)
- [-LicA: License information about every feature in directory on page 187](#)
- [-LicBorrow: Borrow license feature on page 188](#)

## **-LI: Show label statistics**

### **Group**

OUTPUT

### **Scope**

Assembly unit

### **Syntax**

"-LI"

### **Arguments**

None

### **Default**

No label statistics

### **Description**

Appends a section to the listing file that shows how much space would be gained if a certain label were in the short (or tiny) memory area. The statistics take into consideration the relocatable symbols only (labels defined by an EQU directive are not taken into consideration). This option has no effect if no listing file is generated (i.e. -L is not active too). This is an RS08 specific option, and is not supported for any other HC08 derivative.

### **Example:**

```
XREF label_a, label_b
MY_CODE_SECTION: SECTION
label_c:
    LDA label_a
    STA label_b
    INCA
    ADD label_b
    LDA label_c
```

## Assembler Options

Detailed listing of all assembler options

---

Assembling the code above (with -L -L1) results in the following listing file:

---

Freescale HC08-Assembler

(c) Copyright Freescale 1987-2006

Abs.	Rel.	Loc	Obj. code	Source line
----	----	----	----	-----
1	1			XREF label_a, label_b
2	2			MY_CODE_SECTION: SECTION
3	3			label_c:
4	4	000000	B6 xx	LDA label_a
5	5	000002	B7 xx	STA label_b
6	6	000004	4C	INCA
7	7	000005	BB xx	ADD label_b
8	8	000007	B6 xx	LDA label_c
9	9			

Freescale Assembler

Ind.	Name	tiny	short
----	----	----	-----
1	label_a		1 1
2	label_b		2 1
3	label_c		1 1

---

The table at the end of the listing file shows that:

- 1) If label\_a were either in the tiny or short memory area, one byte would be gained in terms of code size (since the LDA at line 4 would use the short addressing mode in either of the two cases).
- 2) If label\_b were in the tiny memory area, two bytes would be gained since the STA at line 5 would use the short addressing mode and the ADD at line 7 would use the tiny addressing mode.
- 3) If label\_c were in the short (or tiny) memory area one byte would be gained since the LDA at line 8 would use the short addressing mode.



## **-M (-Ms, -Mt): Memory model**

### **Group**

Code Generation

### **Scope**

Application

### **Syntax**

`-M(s|b|t)`

### **Arguments**

s: small memory model

t: tiny memory model

### **Default**

-Ms

### **Description**

The Assembler for the MC68HC(S)08 supports two different memory models. The default is the small memory model, which corresponds to the normal setup, i.e., a 64kB code-address space. The tiny memory model corresponds to the situation where the default RAM is in the zero page.

---

**NOTE** For the Assembler, the memory model does not matter at all. The memory model is used by the compiler to specify the default allocation of variable and functions. The Assembler has this option only to generate “compatible” object files for the memory model consistency check of the linker.

---

---

**NOTE** In the tiny memory model, the default for the compiler is to use zero-page addressing. The default for the Assembler is to still use extended-addressing modes. See the [Using the direct addressing mode to access symbols](#) section to see how to generate zero-page accesses.

---

## Assembler Options

*Detailed listing of all assembler options*

---

### Example

```
ASMOPTIONS=-Mt
```

## **-MacroNest: Configure maximum macro nesting**

### **Group**

Language

### **Scope**

Assembly Unit

### **Syntax**

`-MacroNest<Value>`

### **Arguments**

`<Value>`: max. allowed nesting level

### **Default**

3000

### **Description**

This option controls how deep macros calls can be nested. Its main purpose is to avoid endless recursive macro invocations.

### **Example**

See the description of message A1004 for an example.

### **See also**

Message A1004 (available in the Online Help)

## Assembler Options

*Detailed listing of all assembler options*

---

### **-MCUasm: Switch compatibility with MCUasm ON**

#### **Group**

Various

#### **Scope**

Assembly Unit

#### **Syntax**

-MCUasm

#### **Arguments**

None

#### **Default**

None

#### **Description**

This switches ON compatibility mode with the MCUasm Assembler. Additional features supported, when this option is activated are enumerated in the [MCUasm Compatibility](#) chapter in the Appendices.

#### **Example**

```
ASMOPTIONS=-MCUasm
```

## **-N: Display notify box**

### **Group**

Messages

### **Scope**

Assembly Unit

### **Syntax**

-N

### **Arguments**

None

### **Default**

None

### **Description**

Makes the Assembler display an alert box if there was an error during assembling. This is useful when running a makefile (please see the manual about *Build Tools*) because the Assembler waits for the user to acknowledge the message, thus suspending makefile processing. (The 'N' stands for "Notify".)

This feature is useful for halting and aborting a build using the Make Utility.

### **Example**

```
ASMOPTIONS=-N
```

If an error occurs during assembling, an alert dialog box will be opened.

## Assembler Options

*Detailed listing of all assembler options*

---

### **-NoBeep: No beep in case of an error**

#### **Group**

Messages

#### **Scope**

Assembly Unit

#### **Syntax**

-NoBeep

#### **Arguments**

None

#### **Default**

None

#### **Description**

Normally there is a 'beep' notification at the end of processing if there was an error. To have a silent error behavior, this 'beep' may be switched off using this option.

#### **Example**

```
ASMOPTIONS=-NoBeep
```

## **-NoDebugInfo: No debug information for ELF/DWARF files**

### **Group**

Language

### **Scope**

Assembly Unit

### **Syntax**

-NoDebugInfo

### **Arguments**

None

### **Default**

None

### **Description**

By default, the Assembler produces debugging info for the produced ELF/DWARF files. This can be switched off with this option.

### **Example**

```
ASMOPTIONS=-NoDebugInfo
```

## Assembler Options

Detailed listing of all assembler options

---

### **-NoEnv: Do not use environment**

#### **Group**

Startup (This option cannot be specified interactively.)

#### **Scope**

Assembly Unit

#### **Syntax**

-NoEnv

#### **Arguments**

None

#### **Default**

None

#### **Description**

This option can only be specified at the command line while starting the application. It cannot be specified in any other circumstances, including the `default.env` file, the command line or whatever.

When this option is given, the application does not use any environment (`default.env`, `project.ini` or `tips` file).

#### **Example**

```
xx.exe -NoEnv
```

(Use the actual executable name instead of "xx")

#### **See also**

[Environment](#) chapter



## **-ObjN: Object filename specification**

### **Group**

Output

### **Scope**

Assembly Unit

### **Syntax**

`-ObjN<FileName>`

### **Arguments**

`<FileName>`: Name of the binary output file generated.

### **Default**

`-ObjN%n.o` when generating a relocatable file or  
`-ObjN%n.abs` when generating an absolute file file.

### **Description**

Normally, the object file has the same name than the processed source file, but with the ".o" extension when relocatable code is generated or the ".abs" extension when absolute code is generated. This option allows a flexible way to define the output filename. The modifier "%n" can also be used. It is replaced with the source filename. If `<file>` in this option contains a path (absolute or relative), the OBJPATH environment variable is ignored.

### **Example**

For `ASMOPTIONS=-ObjNa.out`, the resulting object file will be "a.out". If the OBJPATH environment variable is set to "`\src\obj`", the object file will be "`\src\obj\a.out`".

For `fibonacci.c -ObjN%n.obj`, the resulting object file will be "fibonacci.obj".

For `myfile.c -ObjN..\objects\_%n.obj`, the object file will be named relative to the current directory to "`..\objects\_myfile.obj`". Note that the environment variable OBJPATH is ignored, because `<file>` contains a path.

## **Assembler Options**

*Detailed listing of all assembler options*

---

### **See also**

[OBJPATH: Object file path](#) environment variable

## **-Prod: Specify project file at startup**

### **Group**

None (This option cannot be specified interactively.)

### **Scope**

None

### **Syntax**

`-Prod=<file>`

### **Arguments**

`<file>`: name of a project or project directory

### **Default**

None

### **Description**

This option can only be specified at the command line while starting the application. It cannot be specified in any other circumstances, including the `default.env` file, the command line or whatever.

When this option is given, the application opens the file as configuration file. When the filename does only contain a directory, the default name `project.ini` is appended. When the loading fails, a message box appears.

### **Example**

```
assembler.exe -Prod=project.ini
```

(Use the Assembler's executable name instead of "assembler".)

### **See also**

[Environment](#) chapter

## Assembler Options

*Detailed listing of all assembler options*

---

### **-Struct: Support for structured types**

#### **Group**

Input

#### **Scope**

Assembly Unit

#### **Syntax**

`-Struct`

#### **Arguments**

None

#### **Default**

None

#### **Description**

When this option is activated, the Macro Assembler also support the definition and usage of structured types. This is interesting for application containing both ANSI-C and Assembly modules.

#### **Example**

```
ASMOPTIONS=-Struct
```

#### **See also**

[Mixed C and Assembler Applications](#) chapter

## **-V: Prints the Assembler version**

### **Group**

Various

### **Scope**

None

### **Syntax**

-V

### **Arguments**

None

### **Default**

None

### **Description**

Prints the Assembler version and the current directory.

---

**NOTE** Use this option to determine the current directory of the Assembler.

---

### **Example**

-V produces the following listing ([Listing 5.39 on page 205](#)):

#### **Listing 5.39 Example of a version listing**

---

```
Command Line '-v'
Assembler V-5.0.8, Jul  7 2005
Directory: C:\Freescale\demo

Common Module V-5.0.7, Date Jul  7 2005
User Interface Module, V-5.0.17, Date Jul  7 2005
Assembler Kernel, V-5.0.13, Date Jul  7 2005
Assembler Target, V-5.0.8, Date Jul  7 2005
```

---

## Assembler Options

Detailed listing of all assembler options

---

### -View: Application standard occurrence

#### Group

Host

#### Scope

Assembly Unit

#### Syntax

`-View<kind>`

#### Arguments

`<kind>` is one of the following:

- "Window": Application window has the default window size.
- "Min": Application window is minimized.
- "Max": Application window is maximized.
- "Hidden": Application window is not visible (only if there are arguments).

#### Default

Application is started with arguments: Minimized.

Application is started without arguments: Window.

#### Description

Normally, the application (e.g., Assembler, Linker, Compiler, ...) is started with a normal window if no arguments are given. If the application is started with arguments (e.g., from the Maker to assemble, compile, or link a file), then the application is running minimized to allow for batch processing. However, the application's window behavior may be specified with the View option.

Using `-ViewWindow`, the application is visible with its normal window. Using `-ViewMin` the application is visible iconified (in the task bar). Using `-ViewMax`, the application is visible maximized (filling the whole screen). Using `-ViewHidden`, the application processes arguments (e.g., files to be compiled or linked) completely invisible in the background (no window or icon visible in the task bar). However, for example, if you are using the [-N: Display notify box on page 197](#) assembler option, a dialog box is still possible.

**Example**

```
C:\Freescale\prog\linker.exe -ViewHidden fibo.prm
```

## Assembler Options

*Detailed listing of all assembler options*

---

### **-W1: No information messages**

#### **Group**

Messages

#### **Scope**

Assembly Unit

#### **Syntax**

-W1

#### **Arguments**

None

#### **Default**

None

#### **Description**

Inhibits the Assembler's printing INFORMATION messages. Only WARNING and ERROR messages are written to the error listing file and to the assembler window.

#### **Example**

```
ASMOPTIONS=-W1
```



## **-W2: No information and warning messages**

### **Group**

Messages

### **Scope**

Assembly Unit

### **Syntax**

-W2

### **Arguments**

None

### **Default**

None

### **Description**

Suppresses all messages of INFORMATION or WARNING types. Only ERROR messages are written to the error listing file and to the assembler window.

### **Example**

```
ASMOPTIONS=-W2
```

## Assembler Options

Detailed listing of all assembler options

---

### -WErrFile: Create "err.log" error file

#### Group

Messages

#### Scope

Assembly Unit

#### Syntax

`-WErrFile (On|Off)`

Arguments

None

#### Default

An `err.log` file is created or deleted.

#### Description

The error feedback from the Assembler to called tools is now done with a return code. In 16-bit Windows environments this was not possible. So in case of an error, an "err.log" file with the numbers of written errors was used to signal any errors. To indicate no errors, the "err.log" file would be deleted. Using UNIX or WIN32, a return code is now available. Therefore, this file is no longer needed when only UNIX or WIN32 applications are involved. To use a 16-bit Maker with this tool, an error file must be created in order to signal any error.

#### Example

- `-WErrFileOn`  
`err.log` is created or deleted when the application is finished.
- `-WErrFileOff`  
existing `err.log` is not modified.

#### See also

[-WStdout: Write to standard output on page 239](#)

[-WOutFile: Create error listing file on page 238](#)

## **-Wmsg8x3: Cut filenames in Microsoft format to 8.3**

### **Group**

Messages

### **Scope**

Assembly Unit

### **Syntax**

-Wmsg8x3

### **Default**

None

### **Description**

Some editors (e.g., early versions of WinEdit) are expecting the filename in the Microsoft message format in a strict 8.3 format. That means the filename can have at most 8 characters with not more than a 3-character extension. Using Win95, WinNT, or a newer Windows O/S, longer file names are possible. With this option the filename in the Microsoft message is truncated to the 8.3 format.

### **Example**

---

```
x:\mysourcefile.c(3) : INFORMATION C2901: Unrolling loop
```

With the -Wmsg8x3 option set, the above message will be

```
x:\mysource.c(3) : INFORMATION C2901: Unrolling loop
```

---

### **See also**

- [-WmsgFb \(-WmsgFbv, -WmsgFbm\): Set message file format for batch mode on page 217](#)
- [-WmsgFi \(-WmsgFiv, -WmsgFim\): Set message file format for interactive mode on page 219](#)
- [-WmsgFoi: Message format for interactive mode on page 223](#)
- [-WmsgFob: Message format for batch mode on page 221 Option](#)

## Assembler Options

*Detailed listing of all assembler options*

---

- [--WmsgFonp: Message format for no position information on page 227](#)

## **-WmsgCE: RGB color for error messages**

### **Group**

Messages

### **Scope**

Compilation Unit

### **Syntax**

`-WmsgCE<RGB>`

### **Arguments**

`<RGB>`: 24-bit RGB (red green blue) value.

### **Default**

`-WmsgCE16711680 (rFF g00 b00, red)`

### **Description**

It is possible to change the error message color with this option. The value to be specified has to be an RGB (Red-Green-Blue) value and has to be specified in decimal.

### **Example**

`-WmsgCE255` changes the error messages to blue.

## Assembler Options

*Detailed listing of all assembler options*

---

### **-WmsgCF: RGB color for fatal messages**

#### **Group**

Messages

#### **Scope**

Compilation Unit

#### **Syntax**

`-WmsgCF<RGB>`

#### **Arguments**

`<RGB>`: 24-bit RGB (red green blue) value.

#### **Default**

`-WmsgCF8388608 (r80 g00 b00, dark red)`

#### **Description**

It is possible to change the fatal message color with this option. The value to be specified has to be an RGB (Red-Green-Blue) value and has to be specified in decimal.

#### **Example**

`-WmsgCF255` changes the fatal messages to blue.

## **-WmsgCI: RGB color for information messages**

### **Group**

Messages

### **Scope**

Compilation Unit

### **Syntax**

`-WmsgCI<RGB>`

### **Arguments**

`<RGB>`: 24-bit RGB (red green blue) value.

### **Default**

`-WmsgCI32768 (r00 g80 b00, green)`

### **Description**

It is possible to change the information message color with this option. The value to be specified has to be an RGB (Red-Green-Blue) value and has to be specified in decimal.

### **Example**

`-WmsgCI255` changes the information messages to blue.

## Assembler Options

*Detailed listing of all assembler options*

---

### **-WmsgCU: RGB color for user messages**

#### **Group**

Messages

#### **Scope**

Compilation Unit

#### **Syntax**

`-WmsgCU<RGB>`

#### **Arguments**

`<RGB>`: 24-bit RGB (red green blue) value.

#### **Default**

`-WmsgCU0 (r00 g00 b00, black)`

#### **Description**

It is possible to change the user message color with this option. The value to be specified has to be an RGB (Red-Green-Blue) value and has to be specified in decimal.

#### **Example**

`-WmsgCU255` changes the user messages to blue.



## **-WmsgCW: RGB color for warning messages**

### **Group**

Messages

### **Scope**

Compilation Unit

### **Syntax**

`-WmsgCW<RGB>`

### **Arguments**

`<RGB>`: 24-bit RGB (red green blue) value.

### **Default**

`-WmsgCW255 (r00 g00 bFF, blue)`

### **Description**

It is possible to change the warning message color with this option. The value to be specified has to be an RGB (Red-Green-Blue) value and has to be specified in decimal.

### **Example**

`-WmsgCW0` changes the warning messages to black.

## Assembler Options

Detailed listing of all assembler options

---

### **-WmsgFb (-WmsgFbv, -WmsgFbm): Set message file format for batch mode**

#### **Group**

Messages

#### **Scope**

Assembly Unit

#### **Syntax**

`-WmsgFb [v | m]`

#### **Arguments**

v: Verbose format.

m: Microsoft format.

#### **Default**

`-WmsgFbm`

#### **Description**

The Assembler can be started with additional arguments (e.g., files to be assembled together with assembler options). If the Assembler has been started with arguments (e.g., from the *Make tool*), the Assembler works in the batch mode. That is, no assembler window is visible and the Assembler terminates after job completion.

If the Assembler is in batch mode, the Assembler messages are written to a file and are not visible on the screen. This file only contains assembler messages (see examples below).

The Assembler uses a *Microsoft* message format as the default to write the assembler messages (errors, warnings, or information messages) if the Assembler is in the batch mode.

With this option, the default format may be changed from the *Microsoft* format (with only line information) to a more verbose error format with line, column, and source information.

### Example

Assume that the assembly source code in [Listing 5.40 on page 218](#) is to be assembled in the batch mode.

#### Listing 5.40 Example assembly source code

---

```
var1:  equ 5
var2:  equ 5
    if (var1=var2)
        NOP
    endif
endif
```

---

The Assembler generates the error output ([Listing 5.41 on page 218](#)) in the assembler window if it is running in batch mode:

#### Listing 5.41 Example error listing in the Microsoft (default) format for batch mode

---

```
X:\TW2.ASM(12):ERROR: Conditional else not allowed here.
```

---

If the format is set to verbose, more information is stored in the file:

#### Listing 5.42 Example error listing in the verbose format for batch mode

---

```
ASMOPTIONS=-WmsgFbv
>> in "C:\tw2.asm", line 6, col 0, pos 81
    endif
    ^
ERROR A1001: Conditional else not allowed here
```

---

### See also

[ERRORFILE: Filename specification error](#)

[-WmsgFi \(-WmsgFiv, -WmsgFim\): Set message file format for interactive mode on page 219](#)

[-WmsgFob: Message format for batch mode on page 221](#)

[-WmsgFoi: Message format for interactive mode on page 223](#)

[-WmsgFonf: Message format for no file information on page 225](#)

[-WmsgFonp: Message format for no position information on page 227](#)

## Assembler Options

Detailed listing of all assembler options

---

### **-WmsgFi (-WmsgFiv, -WmsgFim): Set message file format for interactive mode**

#### **Group**

Messages

#### **Scope**

Assembly Unit

#### **Syntax**

`-WmsgFi [v|m]`

#### **Arguments**

v: Verbose format.

m: Microsoft format.

#### **Default**

`-WmsgFiv`

#### **Description**

If the Assembler is started without additional arguments (e.g., files to be assembled together with Assembler options), the Assembler is in the interactive mode (that is, a window is visible).

While in interactive mode, the Assembler uses the default verbose error file format to write the assembler messages (errors, warnings, information messages).

Using this option, the default format may be changed from verbose (with source, line and column information) to the *Microsoft* format (which displays only line information).

---

**NOTE** Using the Microsoft format may speed up the assembly process because the Assembler has to write less information to the screen.

---

## Example

If the Assembler is running in interactive mode, the default error output is shown in the assembler window as in [Listing 5.44 on page 220](#).

### Listing 5.43 Example error listing in the default mode for interactive mode

---

```
>> in "X:\TWE.ASM", line 12, col 0, pos 215
      endif
      endif
^
ERROR A1001: Conditional else not allowed here
```

---

Setting the format to Microsoft, less information is displayed:

### Listing 5.44 Example error listing in Microsoft format for interactive mode

---

```
ASMOPTIONS=-WmsgFim
X:\TWE.ASM(12): ERROR: conditional else not allowed here
```

---

## See also

[ERRORFILE: Filename specification error](#) environment variable

### Assembler options:

- [-WmsgFb \(-WmsgFbv, -WmsgFbm\): Set message file format for batch mode on page 217](#)
- [-WmsgFob: Message format for batch mode on page 221](#)
- [-WmsgFoi: Message format for interactive mode on page 223](#)
- [-WmsgFonf: Message format for no file information on page 225](#)
- [-WmsgFonp: Message format for no position information on page 227](#)

## Assembler Options

Detailed listing of all assembler options

---

### -WmsgFob: Message format for batch mode

#### Group

Messages

#### Scope

Assembly Unit

#### Syntax

-WmsgFob<string>

#### Arguments

<string>: format string (see below).

#### Default

-WmsgFob"%f%e(%l): %K %d: %m\n"

#### Description

With this option it is possible to modify the default message format in the batch mode. The formats in [Listing 5.45 on page 221](#) are supported (assumed that the source file is `x:\Freescale\sourcefile.asm`).

#### Listing 5.45 Supported formats for messages in the batch mode

---

Format	Description	Example
-----		
%s	Source Extract	
%p	Path	x:\Freescale\
%f	Path and name	x:\Freescale\sourcefile
%n	Filename	sourcefile
%e	Extension	.asmx
%N	File (8 chars)	sourcefi
%E	Extension (3 chars)	.asm
%l	Line	3
%c	Column	47
%o	Pos	1234
%K	Uppercase kind	ERROR
%k	Lowercase kind	error

---

%d	Number	A1051
%m	Message	text
%%	Percent	%
\n	New line	

---

### Example

```
ASMOPTIONS=-WmsgFob"%f%e(%l): %k %d: %m\n"
```

produces a message displayed in [Listing 5.46 on page 222](#) using the format in [Listing 5.45 on page 221](#). The options are set for producing the path of a file with its filename , extension, and line

### Listing 5.46 Error message

---

```
x:\Freescale\sourcefile.asm(3): error A1051: Right parenthesis expected
```

---

### See also

#### Assembler options:

- [-WmsgFb \(-WmsgFbv, -WmsgFbm\): Set message file format for batch mode on page 217](#)
- [-WmsgFi \(-WmsgFiv, -WmsgFim\): Set message file format for interactive mode on page 219](#)
- [-WmsgFoi: Message format for interactive mode on page 223](#)
- [-WmsgFonf: Message format for no file information on page 225](#)
- [-WmsgFonp: Message format for no position information on page 227](#)

## Assembler Options

Detailed listing of all assembler options

---

### -WmsgFoi: Message format for interactive mode

#### Group

Messages

#### Scope

Assembly Unit

#### Syntax

-WmsgFoi<string>

#### Arguments

<string>: format string (see below)

#### Default

-WmsgFoi"\n>> in \"%f%e\", line %l, col %c, pos %o\n%s\n%K %d: %m\n"

#### Description

With this option it is possible modify the default message format in interactive mode. The following formats are supported (supposed that the source file is x:\Freescale\sourcefile.asm):

#### Listing 5.47 Supported message formats - interactive mode

---

Format	Description	Example
%s	Source Extract	
%p	Path	x:\Freescale\
%f	Path and name	x:\Freescale\sourcefile
%n	Filename	sourcefile
%e	Extension	.asmx
%N	File (8 chars)	sourcefi
%E	Extension (3 chars)	.asm
%l	Line	3
%c	Column	47
%o	Pos	1234
%K	Uppercase kind	ERROR

---



%k	Lowercase kind	error
%d	Number	A1051
%m	Message	text
%%	Percent	%
\n	New line	

---

### Example

```
ASMOPTIONS=-WmsgFoi"%f%e(%l): %k %d: %m\n"
```

produces a message in following format ([Listing 5.48 on page 224](#)):

### Listing 5.48 Error message resulting from the statement above

---

```
x:\Freescale\sourcefile.asm(3): error A1051: Right parenthesis  
expected
```

---

### See also

[ERRORFILE: Filename specification error](#) environment variable

#### Assembler options:

- [-WmsgFb \(-WmsgFbv, -WmsgFbm\): Set message file format for batch mode on page 217](#)
- [-WmsgFi \(-WmsgFiv, -WmsgFim\): Set message file format for interactive mode on page 219](#)
- [-WmsgFob: Message format for batch mode on page 221](#)
- [-WmsgFonf: Message format for no file information on page 225](#)
- [-WmsgFonp: Message format for no position information on page 227](#)

## Assembler Options

Detailed listing of all assembler options

---

### -WmsgFonf: Message format for no file information

#### Group

Messages

#### Scope

Assembly Unit

#### Syntax

-WmsgFonf<string>

#### Arguments

<string>: format string (see below)

#### Default

-WmsgFonf"%K %d: %m\n"

#### Description

Sometimes there is no file information available for a message (e.g., if a message not related to a specific file). Then this message format string is used. The following formats are supported:

#### Listing 5.49

---

Format	Description	Example
-----	-----	-----
%K	Uppercase kind	ERROR
%k	Lowercase kind	error
%d	Number	L10324
%m	Message	text
%%	Percent	%
\n	New line	

---

### Example

```
ASMOPTIONS=-WmsgFonf"%k %d: %m\n"
```

produces a message in following format:

```
information L10324: Linking successful
```

### See also

[ERRORFILE: Filename specification error](#) environment variable

#### Assembler options:

- [-WmsgFb \(-WmsgFbv, -WmsgFbm\): Set message file format for batch mode on page 217](#)
- [-WmsgFi \(-WmsgFiv, -WmsgFim\): Set message file format for interactive mode on page 219](#)
- [-WmsgFob: Message format for batch mode on page 221](#)
- [-WmsgFoi: Message format for interactive mode on page 223](#)
- [-WmsgFonp: Message format for no position information on page 227](#)

## Assembler Options

Detailed listing of all assembler options

---

### -WmsgFonp: Message format for no position information

#### Group

Messages

#### Scope

Assembly Unit

#### Syntax

-WmsgFonp<string>

#### Arguments

<string>: format string (see below)

#### Default

-WmsgFonp"%f%e: %K %d: %m\n"

#### Description

Sometimes there is no position information available for a message (e.g., if a message not related to a certain position). Then this message format string is used. The following formats are supported (supposed that the source file is x:\Freescale\sourcefile.asm):

#### Listing 5.50 Supported message formats for when there is no position information

---

Format	Description	Example
%p	Path	x:\Freescale\
%f	Path and name	x:\Freescale\sourcefile
%n	Filename	sourcefile
%e	Extension	.asmx
%N	File (8 chars)	sourcefi
%E	Extension (3 chars)	.asm
%K	Uppercase kind	ERROR
%k	Lowercase kind	error
%d	Number	L10324
%m	Message	text

---

%%	Percent	%
\n	New line	

---

### Example

```
ASMOPTIONS=-WmsgFonf" %k %d: %m\n"
```

produces a message in following format:

```
information L10324: Linking successful
```

### See also

[ERRORFILE: Filename specification error](#) environment variable

#### Assembler options:

- [-WmsgFb \(-WmsgFbv, -WmsgFbm\): Set message file format for batch mode on page 217](#)
- [-WmsgFi \(-WmsgFiv, -WmsgFim\): Set message file format for interactive mode on page 219](#)
- [-WmsgFob: Message format for batch mode on page 221](#)
- [-WmsgFoi: Message format for interactive mode on page 223](#)
- [-WmsgFonf: Message format for no file information on page 225](#)

## Assembler Options

*Detailed listing of all assembler options*

---

### **-WmsgNe: Number of error messages**

#### **Group**

Messages

#### **Scope**

Assembly Unit

#### **Syntax**

`-WmsgNe<number>`

#### **Arguments**

`<number>`: Maximum number of error messages.

#### **Default**

50

#### **Description**

With this option the amount of error messages can be reported until the Assembler stops assembling. Note that subsequent error messages which depends on a previous one may be confusing.

#### **Example**

```
ASMOPTIONS=-WmsgNe2
```

The Assembler stops assembling after two error messages.

#### **See also**

##### **Assembler options:**

- [-WmsgNi: Number of Information messages on page 230](#)
- [-WmsgNw: Number of Warning messages on page 233](#)

## **-WmsgNi: Number of Information messages**

### **Group**

Messages

### **Scope**

Assembly Unit

### **Syntax**

`-WmsgNi<number>`

### **Arguments**

`<number>`: Maximum number of information messages.

### **Default**

50

### **Description**

With this option the maximum number of information messages can be set.

### **Example**

```
ASMOPTIONS=-WmsgNi10
```

Only ten information messages are logged.

### **See also**

#### **Assembler options:**

- [-WmsgNe: Number of error messages on page 229](#)
- [-WmsgNw: Number of Warning messages on page 233](#)

## Assembler Options

*Detailed listing of all assembler options*

---

### **-WmsgNu: Disable user messages**

#### **Group**

Messages

#### **Scope**

None

#### **Syntax**

`-WmsgNu [= { a | b | c | d }]`

#### **Arguments**

- a: Disable messages about include files
- b: Disable messages about reading files
- c: Disable messages about generated files
- d: Disable messages about processing statistics
- e: Disable informal messages

#### **Default**

None

#### **Description**

The application produces some messages which are not in the normal message categories (WARNING, INFORMATION, ERROR, or FATAL). With this option such messages can be disabled. The purpose for this option is to reduce the amount of messages and to simplify the error parsing of other tools:

- a: The application provides information about all included files. With this suboption this option can be disabled.
- b: With this suboption messages about reading files e.g., the files used as input can be disabled.
- c: Disables messages informing about generated files.
- d: At the end of the assembly, the application may provide information about statistics, e.g., code size, RAM/ROM usage, and so on. With this suboption this option can be disabled.



## Assembler Options

*Detailed listing of all assembler options*

---

- e: With this option, informal messages (e.g., memory model, floating point format, ...) can be disabled.

---

**NOTE** Depending on the application, not all suboptions may make sense. In this case they are just ignored for compatibility.

---

### Example

`-WmsgNu=c`

## Assembler Options

Detailed listing of all assembler options

---

### **-WmsgNw: Number of Warning messages**

#### **Group**

Messages

#### **Scope**

Assembly Unit

#### **Syntax**

-WmsgNw<number>

#### **Arguments**

<number>: Maximum number of warning messages.

#### **Default**

50

#### **Description**

With this option the maximum number of warning messages can be set.

#### **Example**

```
ASMOPTIONS=-WmsgNw15
```

Only 15 warning messages are logged.

#### **See also**

##### **Assembler options:**

- [-WmsgNe: Number of error messages on page 229](#)
- [-WmsgNi: Number of Information messages on page 230](#)

## **-WmsgSd: Setting a message to disable**

### **Group**

Messages

### **Scope**

Assembly Unit

### **Syntax**

`-WmsgSd<number>`

### **Arguments**

`<number>`: Message number to be disabled, e.g., 1801

### **Default**

None

### **Description**

With this option a message can be disabled so it does not appear in the error output.

### **Example**

`-WmsgSd1801`

### **See also**

#### **Assembler options:**

- [-WmsgSe: Setting a message to Error on page 235](#)
- [-WmsgSi: Setting a message to Information on page 236](#)
- [-WmsgSw: Setting a Message to Warning on page 237](#)

## Assembler Options

*Detailed listing of all assembler options*

---

### **-WmsgSe: Setting a message to Error**

#### **Group**

Messages

#### **Scope**

Assembly Unit

#### **Syntax**

`-WmsgSe<number>`

#### **Arguments**

`<number>`: Message number to be an error, e.g., 1853

#### **Default**

None

#### **Description**

Allows changing a message to an error message.

#### **Example**

`-WmsgSe1853`

#### **See also**

**Assembler options:**

- [-WmsgSd: Setting a message to disable on page 234](#)
- [-WmsgSi: Setting a message to Information on page 236](#)
- [-WmsgSw: Setting a Message to Warning on page 237](#)

## **-WmsgSi: Setting a message to Information**

### **Group**

Messages

### **Scope**

Assembly Unit

### **Syntax**

`-WmsgSi<number>`

### **Arguments**

`<number>`: Message number to be an information, e.g., 1853

### **Default**

None

### **Description**

With this option a message can be set to an information message.

### **Example**

`-WmsgSi1853`

### **See also**

#### **Assembler options:**

- [-WmsgSd: Setting a message to disable on page 234](#)
- [-WmsgSe: Setting a message to Error on page 235](#)
- [-WmsgSw: Setting a Message to Warning on page 237](#)

## Assembler Options

*Detailed listing of all assembler options*

---

### **-WmsgSw: Setting a Message to Warning**

#### **Group**

Messages

#### **Scope**

Assembly Unit

#### **Syntax**

`-WmsgSw<number>`

#### **Arguments**

`<number>`: Error number to be a warning, e.g., 2901

#### **Default**

None

#### **Description**

With this option a message can be set to a warning message.

#### **Example**

`-WmsgSw2901`

#### **See also**

**Assembler options:**

- [-WmsgSd: Setting a message to disable on page 234](#)
- [-WmsgSe: Setting a message to Error on page 235](#)
- [-WmsgSi: Setting a message to Information on page 236](#)

## **-WOutFile: Create error listing file**

### **Group**

Messages

### **Scope**

Assembly Unit

### **Syntax**

`-WOutFile (On|Off)`

### **Arguments**

None

### **Default**

Error listing file is created.

### **Description**

This option controls if a error listing file should be created at all. The error listing file contains a list of all messages and errors which are created during a assembly process. Since the text error feedback can now also be handled with pipes to the calling application, it is possible to obtain this feedback without an explicit file. The name of the listing file is controlled by the environment variable [ERRORFILE: Filename specification error](#).

### **Example**

`-WOutFileOn`

The error file is created as specified with `ERRORFILE`.

`-WErrFileOff`

No error file is created.

### **See also**

**Assembler options:**

- [-WErrFile: Create "err.log" error file on page 210](#)
- [-WStdout: Write to standard output on page 239](#)

## Assembler Options

Detailed listing of all assembler options

---

### -WStdout: Write to standard output

#### Group

Messages

#### Scope

Assembly Unit

#### Syntax

-WStdout (On|Off)

#### Arguments

None

#### Default

output is written to `stdout`

#### Description

With Windows applications, the usual standard streams are available. But text written into them does not appear anywhere unless explicitly requested by the calling application. With this option is can be controlled if the text to error file should also be written into `stdout`.

#### Example

`-WStdoutOn`

All messages are written to `stdout`.

`-WErrFileOff`

Nothing is written to `stdout`.

#### See also

**Assembler options:**

- [-WErrFile: Create "err.log" error file on page 210](#)
- [-WOutFile: Create error listing file on page 238](#)





## **Assembler Options**

*Detailed listing of all assembler options*

---

# Sections

---

Sections are portions of code or data that cannot be split into smaller elements. Each section has a name, a type, and some attributes.

Each assembly source file contains at least one section. The number of sections in an assembly source file is only limited by the amount of memory available on the system at assembly time. If several sections with the same name are detected inside of a single source file, the code is concatenated into one large section.

Sections from different modules, but with the same name, will be combined into a single section at linking time.

Sections are defined through [Section attributes on page 241](#) and [Section types on page 242](#). The last part of the chapter deals with the merits of using relocatable sections. (See [“Relocatable vs. absolute sections” on page 247.](#))

## Section attributes

An attribute is associated with each section according to its content. A section may be:

- a [data section](#),
- a [constant data section](#), or
- a [code section](#).

## Code sections

A section containing at least one instruction is considered to be a code section. Code sections are always allocated in the target processor's ROM area.

Code sections should not contain any variable definitions (variables defined using the DS directive). You do not have any write access on variables defined in a code section. In addition, variables in code sections cannot be displayed in the debugger as data.

## Constant sections

A section containing only constant data definition (variables defined using the DC or DCB directives) is considered to be a constant section. Constant sections should be allocated in the target processor's ROM area, otherwise they cannot be initialized at application loading time.

## Sections

### Section types

---

## Data sections

A section containing only variables (variables defined using the DS directive) is considered to be a data section. Data sections are always allocated in the target processor's RAM area.

---

**NOTE** A section containing variables (DS) and constants (DC) or code is not a data section. The default for such a section with mixed DC and code content is to put that content into ROM.

---

We strongly recommend that you use separate sections for the definition of variables and constant variables. This will prevent problems in the initialization of constant variables.

## Section types

First of all, you should decide whether to use relocatable or absolute code in your application. The Assembler allows the mixing of absolute and relocatable sections in a single application and also in a single source file. The main difference between absolute and relocatable sections is the way symbol addresses are determined.

This section covers these two types of sections:

- [Absolute sections on page 242](#)
- [Relocatable sections on page 244](#)

## Absolute sections

The starting address of an absolute section is known at assembly time. An absolute section is defined through the [ORG - Set Location Counter](#) assembler directive. The operand specified in the ORG directive determines the start address of the absolute section. See [Listing 6.1 on page 242](#) for an example of constructing absolute sections using the ORG assembler directive.

### Listing 6.1 Example source code using ORG for absolute sections

---

```
XDEF  entry
      ORG  $8000 ; Absolute constant data section.
cst1: DC.B  $26
cst2: DC.B  $BC
...
      ORG  $080  ; Absolute data section.
var:  DS.B  1

      ORG  $8010 ; Absolute code section.
```

```
entry:
    LDA    cst1    ; Loads value in cst1
    ADD    cst2    ; Adds value in cst2
    STA    var     ; Stores result into var
    BRA    entry
```

---

In the previous example, two bytes of storage are allocated starting at address \$A00. The *constant* variable - `cst1` - will be allocated one byte at address \$8000 and another constant - `cst2` - will be allocated one byte at address \$8001. All subsequent instructions or data allocation directives will be located in this absolute section until another section is specified using the `ORG` or `SECTION` directives.

When using absolute sections, it is the user's responsibility to ensure that there is no overlap between the different absolute sections defined in the application. In the previous example, the programmer should ensure that the size of the section starting at address \$8000 is not bigger than \$10 bytes, otherwise the section starting at \$8000 and the section starting at \$8010 will overlap.

Even applications containing only absolute sections must be linked. In that case, there should not be any overlap between the address ranges from the absolute sections defined in the assembly file and the address ranges defined in the linker parameter (PRM) file.

The PRM file used to link the example above, can be defined as in [Listing 6.2 on page 243](#).

**Listing 6.2 Example PRM file for [Listing 6.1 on page 242](#)**

---

```
LINK test.abs /* Name of the executable file generated.      */
NAMES test.o  /* Name of the object file in the application */
END
SECTIONS
/* READ_ONLY memory area. There should be no overlap between this
   memory area and the absolute sections defined in the assembly
   source file. */
MY_ROM = READ_ONLY 0x8000 TO 0xFDFE;
/* READ_WRITE memory area. There should be no overlap between this
   memory area and the absolute sections defined in the assembly
   source file. */
MY_RAM = READ_WRITE 0x0100 TO 0x023F;
END

PLACEMENT
/* Relocatable variable sections are allocated in MY_RAM.      */
DEFAULT_RAM, SSTACK INTO MY_RAM;
/* Relocatable code and constant sections are allocated in MY_ROM. */
DEFAULT_ROM      INTO MY_ROM;
END
```

---

## Sections

### Section types

---

```
STACKSTOP $014F /* Initializes the stack pointer */
INIT    entry /* entry is the entry point to the application. */
VECTOR ADDRESS 0xFFFFE entry /* Initialization for Reset vector.*/
```

---

The linker PRM file contains at least:

- The name of the absolute file (LINK command).
- The name of the object file which should be linked (NAMES command).
- The specification of a memory area where the sections containing variables must be allocated. At least the predefined DEFAULT\_RAM (or its ELF alias ``.data'`) section must be placed there. For applications containing only absolute sections, nothing will be allocated (SECTIONS and PLACEMENT commands).
- The specification of a memory area where the sections containing code or constants must be allocated. At least the predefined section DEFAULT\_ROM (or its ELF alias ``.data'`) must be placed there. For applications containing only absolute sections, nothing will be allocated (SECTIONS and PLACEMENT commands).
- The specification of the application entry point (INIT command)
- The definition of the reset vector (VECTOR ADDRESS command)

## Relocatable sections

The starting address of a relocatable section is evaluated at linking time according to the information stored in the linker parameter file. A relocatable section is defined through the [SECTION - Declare Relocatable Section](#) assembler directive. See [Listing 6.3 on page 244](#) for an example using the SECTION directive.

### Listing 6.3 Example source code using SECTION for relocatable sections

---

```
        XDEF    entry
constSec: SECTION    ; Relocatable constant data section.
cst1:    DC.B    $A6
cst2:    DC.B    $BC

dataSec: SECTION    ; Relocatable data section.
var:     DS.B    1

codeSec: SECTION    ; Relocatable code section.
entry:
        LDA    cst1 ; Load value into cst1
        ADD    cst2 ; Add value in cst2
        STA    var  ; Store into var
        BRA    entry
```

---

In the previous example, two bytes of storage are allocated in the `constSec` section. The constant `cst1` is allocated at the start of the section at address `$A00` and another constant `cst2` is allocated at an offset of 1 byte from the beginning of the section. All subsequent instructions or data allocation directives will be located in the relocatable `constSec` section until another section is specified using the `ORG` or `SECTION` directives.

When using relocatable sections, the user does not need to care about overlapping sections. The linker will assign a start address to each section according to the input from the linker parameter file.

The user can decide to define only one memory area for the code and constant sections and another one for the variable sections or to split the sections over several memory areas.

## Example: Defining one RAM and one ROM area.

When all constant and code sections as well as data sections can be allocated consecutively, the PRM file used to assemble the example above can be defined as in [Listing 6.4 on page 245](#).

### Listing 6.4 PRM file for [Listing 6.3 on page 244](#) defining one RAM area and one ROM area

---

```
LINK test.abs/* Name of the executable file generated.      */
NAMES test.o /* Name of the object file in the application */
END

SECTIONS
/* READ_ONLY memory area.                                  */
MY_ROM = READ_ONLY 0x8000 TO 0xFDFD;
/* READ_WRITE memory area. */
MY_RAM = READ_WRITE 0x0100 TO 0x023F;
END

PLACEMENT
/* Relocatable variable sections are allocated in MY_RAM.  */
DEFAULT_RAM, dataSec , SSTACK INTO MY_RAM;
/* Relocatable code and constant sections are allocated in MY_ROM. */
DEFAULT_ROM, constSec      INTO MY_ROM;
END

INIT entry /* entry is the entry point to the application. */
VECTOR ADDRESS 0xFFFFE entry /* Initialization for Reset vector.*/
```

---

The linker PRM file contains at least:

- The name of the absolute file (`LINK` command).
- The name of the object files which should be linked (`NAMES` command).

## Sections

### Section types

---

- The specification of a memory area where the sections containing variables must be allocated. At least the predefined `DEFAULT_RAM` section (or its ELF alias ``.data'``) must be placed there (`SECTIONS` and `PLACEMENT` commands).
- The specification of a memory area where the sections containing code or constants must be allocated. At least, the predefined `DEFAULT_ROM` section (or its ELF alias ``.text'``) must be placed there (`SECTIONS` and `PLACEMENT` commands).
- Constants sections should be defined in the ROM memory area in the `PLACEMENT` section (otherwise, they are allocated in RAM).
- The specification of the application entry point (`INIT` command).
- The definition of the reset vector (`VECTOR ADDRESS` command).

According to the PRM file above:

- the `dataSec` section will be allocated starting at `0x0080`.
- the `codeSec` section will be allocated starting at `0x0B00`.
- the `constSec` section will be allocated next to the `codeSec` section.

## Example: Defining multiple RAM and ROM areas

When all constant and code sections as well as data sections cannot be allocated consecutively, the PRM file used to link the example above can be defined as in [Listing 6.5 on page 246](#):

### Listing 6.5 PRM file for [Listing 6.3 on page 244](#) defining multiple RAM and ROM areas

---

```
LINK test.abs /* Name of the executable file generated. */
NAMES
    test.o /* Name of the object file in the application. */
END
SECTIONS
    /* Two READ_ONLY memory areas */
    ROM_AREA_1= READ_ONLY 0x8000 TO 0x800F;
    ROM_AREA_2= READ_ONLY 0x8010 TO 0xFDFE;
    /* Three READ_WRITE memory areas */
    RAM_AREA_1= READ_WRITE 0x0040 TO 0x00FF; /* zero-page memory area */
    RAM_AREA_2= READ_WRITE 0x0100 TO 0x01FF;
    MY_STK = READ_WRITE 0x0200 TO 0x023F; /* Stack memory area */
END
PLACEMENT
/* Relocatable variable sections are allocated in MY_RAM. */
dataSec INTO RAM_AREA_2;
DEFAULT_RAM INTO RAM_AREA_1;
SSTACK INTO MY_STK; /* Stack allocated in MY_STK */

/* Relocatable code and constant sections are allocated in MY_ROM. */
constSec INTO ROM_AREA_2;
codeSec, DEFAULT_ROM INTO ROM_AREA_1;
```



```
END
INIT   entry           /* Application's entry point.          */
VECTOR 0 entry /* Initialization of the reset vector. */
```

---

The linker PRM file contains at least:

- The name of the absolute file (LINK command).
- The name of the object files which should be linked (NAMES command).
- The specification of memory areas where the sections containing variables must be allocated. At least, the predefined DEFAULT\_RAM section (or its ELF alias ``.data'`) must be placed there (SECTIONS and PLACEMENT commands).
- The specification of memory areas where the sections containing code or constants must be allocated. At least the predefined DEFAULT\_ROM section (or its ELF alias ``.text'`) must be placed there (SECTIONS and PLACEMENT commands).
- Constants sections should be defined in the ROM memory area in the PLACEMENT section (otherwise, they are allocated in RAM).
- The specification of the application entry point (INIT command)
- The definition of the reset vector (VECTOR command)

According to the PRM file in [Listing 6.5 on page 246](#),

- the `dataSec` section is allocated starting at `0x0100`.
- the `constSec` section is allocated starting at `0x8000`.
- the `codeSec` section is allocated starting at `0x8010`.
- 64 bytes of RAM are allocated in the stack starting at `0x0200`.

## Relocatable vs. absolute sections

Generally, we recommend developing applications using relocatable sections. Relocatable sections offer several advantages.

### Modularity

An application is more modular when programming can be divided into smaller units called sections. The sections themselves can be distributed among different source files.

### Multiple developers

When an application is split over different files, multiple developers can be involved in the development of the application. To avoid major problems when merging the different files, attention must be paid to the following items:

## Sections

### *Relocatable vs. absolute sections*

---

- An include file must be available for each assembly source file, containing XREF directives for each exported variable, constant and function. In addition, the interface to the function should be described there (parameter passing rules as well as the function return value).
- When accessing variables, constants, or functions from another module, the corresponding include file must be included.
- Variables or constants defined by another developer must always be referenced by their names.
- Before invoking a function implemented in another file, the developer should respect the function interface, i.e., the parameters are passed as expected and the return value is retrieved correctly.

## Early development

The application can be developed before the application memory map is known. Often the application's definitive memory map can only be determined once the size required for code and data can be evaluated. The size required for code or data can only be quantified once the major part of the application is implemented. When absolute sections are used, defining the definitive memory map is an iterative process of mapping and remapping the code. The assembly files must be edited, assembled, and linked several times. When relocatable sections are used, this can be achieved by editing the PRM file and linking the application.

## Enhanced portability

As the memory map is not the same for each derivative (MCU), using relocatable sections allow easy porting of the code for another MCU. When porting relocatable code to another target you only need to link the application again with the appropriate memory map.

## Tracking overlaps

When using absolute sections, the programmer must ensure that there is no overlap between the sections. When using relocatable sections, the programmer does not need to be concerned about any section overlapping another. The labels' offsets are all evaluated relatively to the beginning of the section. Absolute addresses are determined and assigned by the linker.

## Reusability

When using relocatable sections, code implemented to handle a specific I/O device (serial communication device), can be reused in another application without any modification.

# Assembler Syntax

---

An assembler source program is a sequence of source statements. Each source statement is coded on one line of text and can be either a:

- [Comment line on page 249](#) or a
- [Source line on page 249](#).

## Comment line

A comment can occupy an entire line to explain the purpose and usage of a block of statements or to describe an algorithm. A comment line contains a semicolon followed by a text ([Listing 7.1 on page 249](#)). Comments are included in the assembly listing, but are not significant to the Assembler.

An empty line is also considered to be a comment line.

### Listing 7.1 Examples of comments

---

```
; This is a comment line followed by an empty line and non comments  
... (non comments)
```

---

## Source line

Each source statement includes one or more of the following four fields:

- a [Label field on page 250](#),
- an [Operation field on page 250](#),
- one or several operands, or
- a comment.

Characters on the source line may be either upper or lower case. Directives and instructions are case-insensitive, whereas symbols are case-sensitive unless the assembler option for case insensitivity on label names ([-Ci: Switch case sensitivity on label names OFF](#)) is activated.

### Label field

The label field is the first field in a source line. A label is a symbol followed by a colon. Labels can include letters ('A'..'Z' or 'a'..'z'), underscores, periods and numbers. The first character must not be a number.

---

**NOTE** For compatibility with other Assembler vendors, an identifier starting on column 1 is considered to be a label, even when it is not terminated by a colon. When the [-MCUasm: Switch compatibility with MCUasm ON](#) assembler option is activated, you *MUST* terminate labels with a colon. The Assembler produces an error message when a label is not followed by a colon.

---

Labels are required on assembler directives that define the value of a symbol (SET or EQU). For these directives, labels are assigned the value corresponding to the expression in the operand field.

Labels specified in front of another directive, instruction or comment are assigned the value of the location counter in the current section.

---

**NOTE** When the Macro Assembler expands a macro it generates internal symbols starting with an underscore '\_' . Therefore, to avoid potential conflicts, user defined symbols should not begin with an underscore

---

---

**NOTE** For the Macro Assembler, a .B or .W at the end of a label has a specific meaning. Therefore, to avoid potential conflicts, user- defined symbols should not end with .B or .W.

---

### Operation field

The operation field follows the label field and is separated from it by a white space. The operation field must not begin in the first column. An entry in the operation field is one of the following:

- an instruction's mnemonic - an abbreviated, case-insensitive name for a member in the [Instruction sets on page 250](#)
- a [Directive on page 265](#) name, or
- a [Macro on page 265](#) name.

### Instruction sets

Executable instructions for the M68HC08 processor are defined in the "CPU08 Reference Manual".

## HC08 instruction set

[Table 7.2 on page 259](#) presents an overview of the instructions available for the HC08:

**Table 7.1 HC08 instruction set**

Instruction	Addressing modes	Description
ADC	#<expression> <expression> <expression>,X ,X <expression>,SP	Add with Carry
ADD	#<expression> <expression> <expression>,X ,X <expression>,SP	Add without carry
AIS	#<expression>	Add Immediate value (signed) to Stack Pointer
AIX	#<expression>	Add Immediate value (signed) to Index register H:X
AND	#<expression> <expression> <expression>,X ,X <expression>,SP	Logical AND
ASL	<expression> <expression>,X ,X <expression>,SP	Arithmetic Shift Left
ASLA		Arithmetic Shift Left Accumulator
ASLX		Arithmetic Shift Left register X
ASR	<expression> <expression>,X ,X <expression>,SP	Arithmetic Shift Right
ASRA		Arithmetic Shift Right Accumulator
ASRX		Arithmetic Shift Right register X

## Assembler Syntax

Source line

Table 7.1 HC08 instruction set (*continued*)

Instruction	Addressing modes	Description
BCC	<label>	Branch if Carry bit Clear
BCLR	BitNumber, <expression>	Clear one Bit in memory
BCS	<label>	Branch if Carry bit Set
BEQ	<label>	Branch if Equal
BGE	<label>	Branch if Greater Than or Equal to
BGND		Enter Background Debug Mode. only available for HCS08 ( -CS08 option)
BGT	<label>	Branch if Greater Than
BHCC	<label>	Branch if Half Carry bit Clear
BHCS	<label>	Branch if Half Carry bit Set
BHI	<label>	Branch if Higher
BHS	<label>	Branch if Higher or Same
BIH	<label>	Branch if /IRQ Pin High
BIL	<label>	Branch if /IRQ Pin Low
BIT	#<expression> <expression> <expression>,X ,X <expression>,SP	Bit Test
BLE	<label>	Branch if Less Than or Equal To
BLO	<label>	Branch if Lower (same as BCS)
BLS	<label>	Branch if Lower or Same
BLT	<label>	Branch if Less Than
BMC	<label>	Branch if interrupt Mask Clear
BMI	<label>	Branch if Minus
BMS	<label>	Branch If interrupt Mask Set

**Table 7.1 HC08 instruction set (continued)**

<b>Instruction</b>	<b>Addressing modes</b>	<b>Description</b>
BNE	<label>	Branch if Not Equal
BPL	<label>	Branch if Plus
BRA	<label>	Branch Always
BRCLR	BitNumber, <expression>, <label>	Branch if Bit is Clear
BRN	<label>	Branch Never
BRSET	BitNumber, <expression>, <label>	Branch if Bit Set
BSET	BitNumber, <expression>	Set Bit in memory
BSR	<label>	Branch to Subroutine
CBEQ	<expression>, <label> <expression>, X+, <label> X+, <label> <expression>, SP, <label>	Compare and Branch if Equal
CBEQA	#<expression>, <label>	
CBEQX	#<expression>, <label>	
CLC		Clear Carry bit
CLI		Clear Interrupt mask bit
CLR	<expression> <expression>, X , X <expression>, SP	Clear memory
CLRA		Clear Accumulator A
CLRH		Clear index Register H
CLR X		Clear index Register X
CMP	#<expression> <expression> <expression>, X , X <expression>, SP	Compare accumulator with memory

## Assembler Syntax

Source line

Table 7.1 HC08 instruction set (*continued*)

Instruction	Addressing modes	Description
COM	<expression> <expression>,X ,X <expression>,SP	One's complement on memory location
COMA		One's complement on accumulator A
COMX		One's complement on register X
CPHX	#<expression> <expression> <expression>,SP	Compare index register H:X with memory Stack pointer and Extended addressing modes only available for HCS08 (-CS08 option)
CPX	#<expression> <expression> <expression>,X ,X <expression>,SP	Compare index register X with memory
DAA		Decimal Adjust Accumulator
DBNZ	<expression>,<label> <expression>,X,<label> X,<label> <expression>,SP,<label>	Decrement counter and Branch if Not Zero
DBNZA	<label>	
DBNZX	<label>	
DEC	<expression> <expression>,X ,X <expression>,SP	Decrement memory location
DECA		Decrement Accumulator
DECX		Decrement Index register
DIV		Divide



**Table 7.1 HC08 instruction set (continued)**

<b>Instruction</b>	<b>Addressing modes</b>	<b>Description</b>
EOR	#<expression> <expression> <expression>,X ,X <expression>,SP	Exclusive OR Memory with accumulator
INC	<expression> ,X <expression>,X <expression>,SP	Increment memory location
INCA		Increment Accumulator
INCX		Increment register X
JMP	<expression> <expression>,X ,X	Jump to label
JSR	<expression> <expression>,X ,X	Jump to Subroutine
LDA	#<expression> <expression> <expression>,X ,X <expression>,SP	Load Accumulator
LDHX	#<expression> <expression> <expression>,X ,X <expression>,SP	Load Index register H:X from memory Indexed, Stack pointer and extended addressing modes are only available for HCS08 (-CS08 option).
LDX	#<expression> <expression> <expression>,X ,X <expression>,SP	Load index Register X from memory
LSL	<expression> <expression>,X ,X <expression>,SP	Logical Shift Left in memory

## Assembler Syntax

Source line

Table 7.1 HC08 instruction set (*continued*)

Instruction	Addressing modes	Description
LSLA		Logical Shift Left Accumulator
LSLX		Logical Shift Left register X
LSR	<expression> <expression>,X ,X <expression>,SP	Logical Shift Right in memory
LSRA		Logical Shift Right Accumulator
LSRX		Logical Shift Right register X
MOV	<expression>,<expression> <expression>,X+ #<expression>,<expression> X+,<expression>	Memory-to-memory byte Move
MUL		Unsigned multiply
NEG	<expression> <expression>,X ,X <expression>,SP	Two's complement in memory
NEGA		Two's complement on Accumulator
NEGX		Two's complement on register X
NOP		No operation
NSA		Nibble Swap Accumulator
ORA	#<expression> <expression> <expression>,X ,X <expression>,SP	Inclusive OR between Accumulator and memory
PSHA		Push Accumulator onto stack
PSHH		Push index register H onto stack
PSHX		Push index register X onto stack
PULA		Pull Accumulator from stack

**Table 7.1 HC08 instruction set (continued)**

<b>Instruction</b>	<b>Addressing modes</b>	<b>Description</b>
PULH		Pull index register H from stack
PULX		Pull index register X from stack
ROL	<expression> <expression>,X ,X <expression>,SP	Rotate memory Left
ROLA		Rotate Accumulator Left
ROLX		Rotate register X Left
ROR	<expression> <expression>,X ,X <expression>,SP	Rotate memory Right
RORA		Rotate Accumulator Right
RORX		Rotate register X Right
RSP		Reset Stack Pointer
RTI		Return from Interrupt
RTS		Return from Subroutine
SBC	#<expression> <expression> <expression>,X ,X <expression>,SP	Subtract with Carry
SEC		Set Carry bit
SEI		Set Interrupt mask bit
STA	<expression> <expression>,X ,X <expression>,SP	Store Accumulator in Memory

## Assembler Syntax

Source line

Table 7.1 HC08 instruction set (*continued*)

Instruction	Addressing modes	Description
STHX	<expression> <expression>,SP	Store Index register H:X Stack pointer and extended addressing modes are only available for HCS08 (-CS08 option)
STOP		Enable /IRQ pin and Stop oscillator
STX	<expression> <expression>,X ,X <expression>,SP	Store index register X in memory
SUB	#<expression> <expression> <expression>,X ,X <expression>,SP	Subtract
SWI		Software Interrupt
TAP		Transfer Accumulator to CCR
TAX		Transfer Accumulator to index Register X
TPA		Transfer CCR to Accumulator
TST	<expression> <expression>,X ,X <expression>,SP	Test memory for negative or zero
TSTA		Test Accumulator for negative or zero
TSTX		Test register X for negative or zero
TSX		Transfer SP to index register H:X
TXA		Transfer index register X to Accumulator

**Table 7.1 HC08 instruction set (continued)**

Instruction	Addressing modes	Description
TXS		Transfer index register X to SP
WAIT		Enable interrupts; stop processor

## Special HCS08 instructions

The HCS08 core provides the following instructions in addition to the HC08 core instructions ([Table 7.4 on page 265](#)):

**Table 7.2 Special HC(S)08 instructions**

Instruction	Addressing modes	Description
BGND		Enter Background Debug Mode. only available with the <a href="#">-CS08/-C08/-CRS08: Derivative family</a> assembler options.
CPHX	#<expression> <expression> <expression>,SP	Compare index register H:X with memory Stack pointer and extended addressing modes are only available with the -CS08, -C08, or -CRS08 assembler options.
LDHX	#<expression> <expression> <expression>,X ,X <expression>,SP	Load index register H:X from memory Indexed, stack pointer, and extended addressing modes are only available with the -CS08 option
STHX	<expression> <expression>,SP	Store index register H:X Stack pointer and extended addressing modes are only available with the -CS08 option.

## RS08 instruction set

[Table 7.3 on page 260](#) presents an overview of the instructions available for the RS08.

## Assembler Syntax

Source line

---

**Table 7.3 RS08 instructions**

Instruction	Addressing Modes	Description
ADC	#<expression> <expression> ,X D[X] X	Add with Carry
ADCX		Alias for ADC X
ADD	#<expression> <expression> ,X D[X] X	Add without Carry
ADDX		Alias for ADD X
AND	#<expression> <expression> ,X D[X] X	Logical AND
ANDX		Alias for AND X
ASLA		Arithmetic Shift Left Accumulator (alias for LSLA)
BCC	<label>	Branch if Carry Bit Clear
BCLR	BitNumber, <expression> BitNumber,D[X] BitNumber,X	Clear one Bit in Memory
BCS	<label>	Branch if Carry Bit Set
BEQ	<label>	Branch if Equal
BGND		Background
BHS	<label>	Branch if Higher or Same
BLO	<label>	Branch if Lower
BNE	<label>	Branch if Not Equal
BRN	<label>	Branch Never (Alias for BRA *+)\$2)

**Table 7.3 RS08 instructions (continued)**

<b>Instruction</b>	<b>Addressing Modes</b>	<b>Description</b>
BRCLR	BitNumber, <expression>, <label> BitNumber,D[X],<label> BitNumber,X,<label>	Branch if Bit is Clear
BRSET	BitNumber, <expression>, <label> BitNumber,D[X],<label> BitNumber,X,<label>	Branch if Bit Set
BSET	BitNumber,<expression> BitNumber,D[X] BitNumber,X	Set Bit in Memory
BSR	<label>	Branch to Subroutine
CBEQ	<expression>,<label> #<expression>,<label> ,X,<label> D[X],<label> X,<label>	Compare and Branch if Equal
CBEQA	<label>	
CBEQX	<label>	
CLC		Clear Carry Bit
CLR	<expression> ,X D[X] X	Clear Memory
CLR X		Clear Index Register X
CMP	#<expression> <expression> ,X D[X] X	Compare Accumulator with Memory
COMA		Complement (One's Complement)

## Assembler Syntax

Source line

Table 7.3 RS08 instructions (*continued*)

Instruction	Addressing Modes	Description
DBNZ	<expression>, <label> , X, <label> D[X], <label> X, <label>	Decrement Counter and Branch if Not Zero
DBNZA	<label>	
DBNZX	<label>	
DEC	<expression> , X D[X] X	Decrement Memory Location
DEC	<\$13	Force tiny addressing (will use \$03)
DECA		Decrement Accumulator
DECX		Decrement Index Register
EOR	#<expression> <expression> D[X] , X X	Exclusive OR Memory with Accumulator
EORX		Exclusive OR (index register and accumulator)
INC	<expression> , X D[X] X	Increment Memory Location
INC	>\$01	Force direct addressing
INCA		Increment Accumulator
INCX		Increment Register X
JMP	<label>	Jump to Label
JSR	<label>	Jump to Subroutine



**Table 7.3 RS08 instructions (continued)**

Instruction	Addressing Modes	Description
LDA	#<expression> <expression> ,X D[X] X	Load Accumulator indexed
LDA	<\$OFF	Force short addressing (will use \$1F)
LDX	#<expression> <expression> ,X D[X] X	Load Index Register X from Memory
LDX	\$OFF	Load Direct
LSLA		Logical Shift Left Accumulator
LSRA		Logical Shift Right Accumulator
MOV	<expression>,<expression> #<expression>,<expression> D[X],<expression> <expression>,D[X] #<expression>,D[X]	Memory to Memory Byte Move
NOP		No Operation
ORA	#<expression> <expression> ,X D[X] X	Inclusive OR between Accumulator and Memory
ORAX		Inclusive OR between Accumulator and Index Register
ROLA		Rotate Accumulator Left
RORA		Rotate Accumulator Right
RTS		Return from Subroutine

## Assembler Syntax

Source line

Table 7.3 RS08 instructions (*continued*)

Instruction	Addressing Modes	Description
SBC	#<expression> <expression> ,X D[X] X	Subtract with Carry
SBCX		Subtract with Carry (Index Register content from Accumulator)
SEC		Set Carry Bit
SHA		Swap Shadow PC High with A
SLA		Swap Shadow PC Low with A
STA	<expression> ,X D[X] X	Store Accumulator in Memory
STOP		Stop Processing
STX	<expression>	Store Index Register X in Memory
SUB	#<expression> <expression> ,X D[X]	Subtract
SUBX		
TAX		Transfer Accumulator to Index Register X
TST	#<expression> <expression> ,X D[X]	Test for zero (alias for MOV <expression>, <expression>)
TSTA		Test Accumulator (alias for ORA #0)
TSTX		Test Index Register X (alias for MOV X,X)

**Table 7.3 RS08 instructions (continued)**

Instruction	Addressing Modes	Description
TXA		Transfer Index Register X to Accumulator
WAIT		Enable Interrupts; Stop Processor

---

**NOTE** For RS08 both D[X] and ,X notations refer to the memory location \$000E. The ,X notation is supported for compatibility reasons with HC(S)08. Wherever ,X is supported, D[X] is also supported. In situations where the use of ,X would lead to double commas (e.g. BCLR 0,,X) the use of ,X is not allowed.

---

## Directive

Assembler directives are described in the [“Assembler Directives”](#) chapter of this manual.

## Macro

A user-defined macro can be invoked in the assembler source program. This results in the expansion of the code defined in the macro. Defining and using macros are described in the [“Macros”](#) chapter in this manual.

## Operand field: Addressing modes (HC08 / HCS08)

The operand fields, when present, follow the operation field and are separated from it by a white space. When two or more operand subfields appear within a statement, a comma must separate them.

The following addressing mode notations are allowed in the operand field ([Table 7.4 on page 265](#)):

**Table 7.4 HC(S)08 addressing mode notation**

Addressing Mode	Notation	Example
<a href="#">Inherent on page 266</a>	No operands	RSP
<a href="#">Immediate on page 267</a>	#<expression>	ADC #\$01

## Assembler Syntax

Source line

Table 7.4 HC(S)08 addressing mode notation (*continued*)

Addressing Mode	Notation	Example
<a href="#">Direct on page 267</a>	<expression>	ADC byte
<a href="#">Extended on page 268</a>	<expression>	ADC word
<a href="#">Indexed, no offset on page 268</a>	,X	ADC ,X
<a href="#">Indexed, 8-bit offset on page 269t</a>	<expression>,X	ADC Offset,X
<a href="#">Indexed, 16-bit offset on page 270</a>	<expression>,X	ADC Offset,X
<a href="#">Relative on page 270</a>	<label>	BRA Label
<a href="#">Stack Pointer, 8-bit offset on page 271</a>	<expression>,SP	ADC Offset,SP
<a href="#">Stack Pointer, 16-bit offset on page 271</a>	<expression>,SP	ADC Offset,SP
<a href="#">Memory-to-memory immediate-to-direct on page 272</a>	#<expression>,<expression>	MOV #\$05,MyDataByte
<a href="#">Memory-to-memory direct-to-direct on page 272</a>	<expression>,<expression>	MOV DatLoc1,DatLoc2
<a href="#">Memory-to-memory indexed-to-direct with post-increment on page 273t</a>	X+,<expression>	MOV X+,<expression>
<a href="#">Memory-to-memory direct-to-indexed with post-increment on page 274</a>	<expression>,X+	MOV <expression>,X+
<a href="#">Indexed with post-increment on page 274</a>	X+	CBEQ X+, Data
<a href="#">Indexed, 8-bit offset, with post-increment on page 275</a>	#<expression>,X+	CBEQ #offset,X+,Data

## Inherent

Instructions using this addressing mode do not have any associated instruction fetch ([Listing 7.2 on page 266](#)). Some of them are acting on data in the CPU registers.

---

**Listing 7.2 Inherent addressing-mode instructions**

---

```
CLRA
DAA
```

---

## Immediate

The opcode contains the value to use with the instruction rather than the address of this value.

The effective address of the instruction is specified using the # character as in the [Listing 7.3 on page 267](#).

---

**Listing 7.3 Immediate addressing mode**

---

```
                XDEF  Entry
initStack: EQU  $0400

MyData:        SECTION
data:          DS.B 1

MyCode:        SECTION
Entry:

                LDHX  #initStack ; init Stack Pointer
                TXS   ; with value $400-1 = $03FF

main:          LDA   #100          ; load register A with (decimal) 100
                BRA   main
```

---

In this example, the hexadecimal value \$0400 is loaded in value in the register HX and the decimal value 100 is loaded into register A.

## Direct

The direct addressing mode is used to address operands in the direct page of the memory (location \$0000 to \$00FF).

For most of the direct instructions, only two bytes are required: the first byte is the opcode and the second byte is the operand address located in page zero. See [Listing 7.4 on page 267](#) for an example of the direct addressing mode.

## Assembler Syntax

Source line

---

### Listing 7.4 Direct addressing mode

---

```
                XDEF   Entry
initStack:     EQU    $0400
MyData:        SECTION SHORT
data:          DS.B   1
MyCode:        SECTION
Entry:
                LDHX  #initStack ; init Stack Pointer
                TXS   ; with value $400 - 1 = $03FF
main:          LDA   #$55
                STA   data
                BRA   main
```

---

In this example, the value \$55 is stored in the variable data, which is located on the direct page. The MyData section must be defined in the direct page in the linker parameter file. The opcode generated for the STA data instruction is two bytes long.

## Extended

The extended addressing mode is used to access memory location located above the direct page in a 64-kiloByte memory map.

For the extended instructions, three bytes are required: the first byte is the opcode and the second and the third bytes are the most and least significant bytes of the operand address. See [Listing 7.5 on page 268](#) for an example of the extended addressing mode.

### Listing 7.5 Extended addressing mode

---

```
                XDEF   Entry
initStack:     EQU    $0400
                ORG    $B00
data:          DS.B   1
MyCode:        SECTION
Entry:
                LDHX  #initStack ; init Stack Pointer
                TXS   ; with value $400-1 = $03FF
main:          LDA   #$55
                STA   data
                BRA   main
```

---

In this example, the value \$55 is stored in the variable data. This variable is located at address \$0B00 in the memory map. The opcode of the STA data instruction is then three bytes long.

## Indexed, no offset

This addressing mode is used to access data with variable addresses through the HX index register of the HC08 controller. The X index register contains the least significant byte of the operand while the H index register contains the most significant byte.

Indexed, no offset instructions are one byte long. See [Listing 7.6 on page 269](#) for an example of using the indexed (no offset) addressing mode.

### Listing 7.6 Indexed (no offset) addressing mode

---

```
...
Entry:
    ...

    LDHX  #$0FFE
    LDA   ,X
    ...
    JMP   ,X
    ...
```

---

The value stored in memory location \$0FFE is loaded into accumulator A. The JMP instruction causes the program to jump to the address pointed to by the HX register.

## Indexed, 8-bit offset

This addressing mode is useful when selecting the k-th element in an n-element table. The size of the table is limited to 256 bytes.

Indexed, 8-bit offset instructions are two byte long. The first byte is the opcode and the second byte contains the index register offset byte. See [Listing 7.7 on page 269](#) for an example of using the indexed (8-bit offset) addressing mode.

### Listing 7.7 Index (8-bit offset) addressing mode

---

```
                XDEF  Entry
initStack: EQU  $0400
MyData:      SECTION SHORT
data:        DS.B  8
MyCode:      SECTION
Entry:
```

## Assembler Syntax

Source line

---

```
LDHX #initStack ; init Stack Pointer
TXS          ; with value $400-1 = $03FF
main:
LDHX #data
LDA  5 ,X
...
JMP  $FF,X
...
```

The value contained in the memory at the location calculated using the address of data (pointed to by the HX register) + 5 is loaded in accumulator A. The JMP instruction causes the program to jump to the address pointed to by the HX register + \$FF.

## Indexed, 16-bit offset

This addressing mode is useful when selecting the k-th element in an n-element table. The size of the table is limited to \$FFFF bytes.

Indexed,16-bit offset instructions are three byte long. The first byte contains the opcode and the second and the third the high and low index register offset bytes. See [Listing 7.8 on page 270](#) for an example of using the indexed (16-bit offset) addressing mode.

### Listing 7.8 Indexed (16-bit offset) addressing mode

---

```
XDEF  Entry
initStack: EQU  $0400
MyData: SECTION
data:    DS.B  8
MyCode: SECTION
Entry:
LDHX #initStack ; init Stack Pointer
TXS          ; with value $400-1 = $03FF
main:
LDHX #table
STA  $500 ,X
...
JMP  $1000,X
...
```

---

The value contained in the memory at the location calculated using the address of data (pointed to by register HX) + \$500 is loaded in accumulator A. The JMP instruction causes the program to jump to the address pointed to by the HX register + \$1000.



## Relative

This addressing mode is used by all branch instructions to determine the destination address. The signed byte following the opcode is added to the contents of the program counter.

As the offset is coded on a signed byte, the branching range is -127 to +128. The destination address of the branch instruction must be in this range. See [Listing 7.9 on page 271](#) for an example of using the relative addressing mode.

### Listing 7.9 Relative addressing mode

---

```
main:
    NOP
    NOP
    BRA    main
```

---

## Stack Pointer, 8-bit offset

Stack Pointer, 8-bit offset instructions behave the same way than Indexed 8-bit offset instructions, except that the offset is added to the Stack Pointer SP in place of the HX Index register.

This addressing mode allow easy access of the data on the stack. If the interrupts are disabled, the Stack pointer can also be used as a second Index register. See [Listing 7.10 on page 271](#) for an example of using the Stack Pointer \*(8-bit offset) addressing mode.

### Listing 7.10 Stack Pointer (8-bit offset) addressing mode

---

```
entry:
    LDHX    #$0500    ; init Stack Pointer to 04FF
    TXS

    LDA    #$40
    STA    $50, SP    ; Location $54F = $40
```

---

In this example, stack pointer, 8-bit offset mode is used to store the value \$40 in memory location \$54F.

### Stack Pointer, 16-bit offset

Stack Pointer, 16-bit offset instructions behave the same way than Indexed, 16-bit offset instructions, except that the offset is added to the Stack Pointer (SP) in place of the HX Index register.

This addressing mode allow easy access of the data on the stack. If the interrupts are disabled, the Stack pointer can also be used as a second Index register. See [Listing 7.11 on page 271](#) for an example of using the Stack Pointer (16-bit offset) addressing mode.

#### Listing 7.11 Stack Pointer (16-bit offset) addressing mode

---

```
entry:
    LDHX    #$0100    ; init Stack Pointer to 00FF
    TXS
    LDA     $0500, SP ; Content of memory location $5FF is loaded in A
```

---

In this example, stack pointer, 16-bit offset mode is used to store the value in memory location \$5FF in accumulator A.

### Memory-to-memory immediate-to-direct

This addressing mode is generally used to initialize variables and registers in page zero. The register A is not affected. See [Listing 7.12 on page 272](#) for an example for using the memory-to- memory immediate-to-direct addressing mode.

#### Listing 7.12 Memory-to-memory immediate-to-direct addressing mode

---

```
MyData:    EQU     $50
entry:
    MOV     #$20, MyData
```

---

The MOV #\$20, MyData instruction stores the value \$20 in memory location \$50 'MyData'.

### Memory-to-memory direct-to-direct

This addressing mode is generally used to transfer variables and registers in page zero. The A register is not affected. See [Listing 7.13 on page 272](#) for an example of using the memory-to- memory direct-to-direct addressing mode.

**Listing 7.13 Memory-to-memory direct-to-direct addressing mode**

```
MyData1: EQU    $50
MyData2: EQU    $51
entry:
        MOV    #$10, MyData1
        MOV    MyData1, MyData2
```

The `MOV #$10, MyData1` instruction stores the value `$10` in memory location `$50` 'MyData1' using the memory-to-memory Immediate-to-Direct addressing mode. The `MOV MyData1, MyData2` instruction moves the content of `MyData1` into `MyData2` using memory to memory Direct-to-Direct addressing mode. The content of `MyData2` (memory location `$51`) is then `$10`.

## Memory-to-memory indexed-to-direct with post-increment

This addressing mode is generally used to transfer tables addressed by the index register to a register in page zero.

The operand addressed by the HX index register is stored in the direct page location addressed by the byte following the opcode. The HX index register is automatically incremented. The A register is not affected. See [Listing 7.14 on page 273](#) for an example of using the memory-to-memory indexed to direct with post-increment addressing mode.

**Listing 7.14 Memory-to-memory indexed-to-direct with post increment addressing mode.**

```

XDEF    Entry

ConstSCT: SECTION
Const:  DC.B  1, 11, 21, 31, 192, 12, 0

DataSCT: SECTION SHORT
MyReg:   DS.B  1

CodeSCT: SECTION
Entry:   LDHX  #$00FF
        TXS

main:

        LDHX  #Const
LOOP:   MOV   X+, MyReg
        BEQ  main
```

## Assembler Syntax

Source line

---

```
BRA    LOOP
```

---

In this example, the table `Const` contains seven bytes defined in a constant section in ROM. The last value of this table is zero.

The HX register is initialized with the address of `Const`. All the values of this table are stored one after another in page-zero memory location `MyReg` using the `MOV X+, MyReg` instruction. When the value 0 is encountered, the HX register is reset with the address of the first element of the `#Const` table.

## Memory-to-memory direct-to-indexed with post-increment

This addressing mode is generally used to fill tables addressed by the index register from registers in page zero.

The operand in the direct page location addressed by the byte following the opcode is stored in the memory location pointed to by the HX index register. The HX index register is automatically incremented. The A register is not affected. See [Listing 7.15 on page 274](#) for an example of using the memory-to-memory direct-to-indexed with post-increment addressing mode.

### Listing 7.15 Memory-to-memory direct-to-indirect with post-increment addressing mode

---

```
XDEF    entry
MyData: SECTION SHORT
MyReg1: DS.B  1
MyReg2: DS.B  1
MyCode: SECTION
entry:
    LDA    #$02
    STA    MyReg1
    INCA
    STA    MyReg2

    LDHX   #$1000
    MOV    MyReg1, X+
    MOV    MyReg2, X+
main:    BRA    main
```

---

The page-zero memory locations `MyReg1` and `MyReg2` are first respectively initialized with `$02` and `$03`. The contents of those data are then written in memory location `$1000` and `$1001`. The HX register points to memory location `$1002`.

## Indexed with post-increment

The operand is addressed then the HX register is incremented.

This addressing mode is useful for searches in tables. It is only used with the CBEQ instruction. See [Listing 7.16 on page 275](#) for an example of an example of using the indexed with post-increment addressing mode.

### Listing 7.16 Example of the indexed with post-increment addressing mode

---

```

XDEF Entry
ORG   $F000
data: DC.B 1,11,21,31,$C0,12
CodeSCT: SECTION
Entry: LDHX  #$00FF
      TXS
main:
      LDA  #$C0

      LDHX #data
LOOP: CBEQ X+, IS_EQUAL

      BRA  LOOP
IS_EQUAL: ...

```

---

Using this addressing mode, it is possible to scan the memory to find a location containing a specific value.

The value located at the memory location pointed to by HX is compared to the value in the A register. If the two values match, the program branches to IS\_EQUAL. HX points to the memory location next to the one containing the searched value.

In this example, the value \$C0 is searched starting at memory location \$F000. This value is found at the memory location \$F004, the program branches to IS\_EQUAL, and the HX register contains \$F005.

## Indexed, 8-bit offset, with post-increment

The address of the operand is the sum of the 8-bit offset added to the value in register HX.

The operand is addressed, then the HX register is incremented.

This addressing mode is useful for searches in tables. It is only used with the CBEQ instruction. See [Listing 7.17 on page 275](#) for an example of the indexed (8-bit offset) with post-increment addressing mode.

## Assembler Syntax

Source line

---

### Listing 7.17 Indexed (8-bit offset) with post-increment addressing mode

---

```

        XDEF  Entry
        ORG  $F000
data:   DCB.B $40,$00
        DC.B 1,11,21,31,$C0,12 ; $C0 is located at $F000+$40+4
CodeSCT: SECTION
Entry:  LDHX  #$00FF
        TXS
main:
        LDA  #$C0

        LDHX #data
LOOP:   CBEQ  $30,X+,IS_EQUAL

        BRA  LOOP
IS_EQUAL: ...
```

---

Using this addressing mode, it is possible to scan the memory to find a location containing a specific value starting at a specified location to which is added an offset.

The value located at memory location pointed to by  $HX + \$30$  is compared to the value in the A register. If the two values match, program branch to `IS_EQUAL`. `HX` points to memory location next to the one containing the searched value.

In this example, the value `$C0` is searched starting at memory location  $\$F000 + \$30 = \$F030$ . This value is found at memory location  $\$F044$ , the program branches to `IS_EQUAL`. The `HX` register contains the memory location of the searched value minus the offset, incremented by one:  $\$F044 - \$30 + 1 = \$F015$ .

## Operand Field: Addressing Modes (RS08)

The following addressing mode notations are allowed in the operand field for the RS08:

**Table 7.5 Operand Field RS08 Addressing Modes**

Inherent	No operands	RTS
Tiny	<expression>	ADD fourbits
Short	<expression>	CLR fivebits
Direct	<expression>	ADC byte
Extended	<expression>	JSR word

**Table 7.5 Operand Field RS08 Addressing Modes (continued)**

Relative	<label>	BRA Label
Immediate	#<expression>	ADC #<expression>
Indexed	D[X] or ,X	ADC D[X] or ADC ,X

## Inherent (RS08)

Instructions using this addressing mode don't have any instruction fetch associated. Some of them are acting on data in the CPU registers.

Example:

```
CLRA
INCA
NOP
```

## Tiny

The tiny addressing mode is used to access only the first 16 bytes of the memory map (addresses from \$0000 to \$000F). The instructions using this addressing mode are encoded using one byte only. This addressing mode is available for INC, DEC, ADD and SUB instructions.

Example:

```
XDEF Entry
MyData: SECTION RS08_TINY
data: DS.B 1
MyCode: SECTION
Entry:
main: ADD data
      BRA main
```

In this example, the value of the variable data is added to the accumulator. The data is located in the tiny memory area, so the encoding of the ADD instruction will be one byte long. Note that the tiny section has to be placed into the tiny memory area at link time.

## Short

The RS08 short addressing mode is used to access only the first 32 bytes of the memory map (addresses from \$0000 to \$001F). The instructions using this addressing mode are

## Assembler Syntax

### Source line

---

encoded using one byte only. This addressing mode is available for CLR, LDA and STA instructions.

Example:

---

```
MyData:    XDEF Entry
           SECTION RS08_SHORT
data:      DS.B 1
MyCode:    SECTION
Entry:
main:      LDA data
           BRA main
```

---

In this example, the value of the variable data is loaded into the accumulator. The data is located in the short memory area, so the encoding of the LDA instruction will be one byte long. Note that the short section has to be placed into the tiny memory area at linktime.

## Direct

The direct addressing mode is used to address operands in the direct page of the memory (location \$0000 to \$00FF).

Example:

---

```
MyData:    XDEF Entry
           SECTION
data:      DS.B 1
MyCode:    SECTION
Entry:
main:      LDA #$55
           STA data
           BRA main
```

---

In this example, the value \$55 is stored in the variable data. The opcode generated for the instruction STA data is two bytes long.

## Extended

The extended addressing mode is used only for JSR and JMP instructions. The 14-bit address is located in the lowest 14 bits of the encoding after the two-bit opcode.

Example:

---

```
data:      XDEF Entry
           XREF target
           DS.B 1
```

---



```
MyCode:   SECTION
Entry:
main:     LDA #$55
          JMP target
```

---

In this example a jump is executed at an address defined by the external symbol target.

## Relative

This addressing mode is used by all branch instructions to determine the destination address. The signed byte following the opcode is added to the contents of the program counter.

As the offset is coded on a signed byte, the branching range is -127 to +128. The destination address of the branch instruction must be in this range.

Example:

---

```
main:
      NOP
      NOP
      BRA main
```

---

## Immediate

The opcode contains the value to use with the instruction rather than the address of this value. The effective address of the instruction is specified using the # character as in the example below.

Example:

---

```
MyData:   XDEF Entry
data:     DS.B 1

MyCode:   SECTION
Entry:
main:     LDA #100
          BRA main
```

---

In this example, the decimal value 100 is loaded in register A.

## Indexed

When using the indexed addressing mode, an index register is used as reference to access the instruction's operand. For the RS08, the index registers are located at \$000F (register X) and \$000E (register D[X]). The D[X] register is called the index data register, and can be designated by either one of the D[X] or ,X notations. As a restriction, when the use of ,X would lead to double commas in the assembly source, the use of ,X is not allowed.

Example:

---

```
MyData:      XDEF Entry
             SECTION
data:        DS.B 1

MyCode:     SECTION
Entry:
main:       CLR D[X] ; equivalent to CLR ,X
             CLR X
```

---

In this example the contents of both X and D[X] registers are replaced by zeros.

## Comment Field

The last field in a source statement is an optional comment field. A semicolon (;) is the first character in the comment field.

Example:

---

```
NOP ; Comment following an instruction
```

---

## Symbols

The following types of symbols are the topics of this section:

- [User-defined symbols on page 280](#)
- [External symbols on page 281](#)
- [Undefined symbols on page 282](#)
- [Reserved symbols on page 282](#)

## User-defined symbols

Symbols identify memory locations in program or data sections in an assembly module. A symbol has two attributes:

- The section, in which the memory location is defined
- The offset from the beginning of that section.

Symbols can be defined with an absolute or relocatable value, depending on the section in which the labeled memory location is found. If the memory location is located within a relocatable section (defined with the [SECTION - Declare Relocatable Section](#) assembler directive), the label has a relocatable value relative to the section start address.

Symbols can be defined relocatable in the label field of an instruction or data definition source line ([Listing 7.18 on page 281](#)).

---

### Listing 7.18 Example of a user-defined relocatable SECTION

---

```
Sec: SECTION
label1: DC.B 2 ; label1 is assigned offset 0 within Sec.
label2: DC.B 5 ; label2 is assigned offset 2 within Sec.
label3: DC.B 1 ; label3 is assigned offset 7 within Sec.
```

---

It is also possible to define a label with either an absolute or a previously defined relocatable value, using the [SET - Set Symbol Value](#) or [EQU - Equate symbol value](#) assembler directives.

Symbols with absolute values must be defined with constant expressions.

---

### Listing 7.19 Example of a user-defined absolute and relocatable SECTION

---

```
Sec: SECTION
label1: DC.B 2 ; label1 is assigned offset 0 within Sec.
label2: EQU 5 ; label2 is assigned value 5.
label3: EQU label1 ; label3 is assigned the address of label1.
```

---

## External symbols

A symbol may be made external using the [XDEF - External Symbol Definition](#) assembler directive. In another source file, an [XREF - External Symbol Reference](#) assembler directive must reference it. Since its address is unknown in the referencing file, it is considered to be relocatable. See [Listing 7.20 on page 281](#) for an example of using XDEF and XREF.

---

### Listing 7.20 Examples of external symbols

---

```
XREF extLabel ; symbol defined in an other module.
; extLabel is imported in the current module
XDEF label ; symbol is made external for other modules
```

---

## Assembler Syntax

### Symbols

---

```
                                ; label is exported from the current module
constSec: SECTION
label:    DC.W 1, extLabel
```

---

## Undefined symbols

If a label is neither defined in the source file nor declared external using XREF, the Assembler considers it to be undefined and generates an error message. [Listing 7.21 on page 282](#) shows an example of an undeclared label.

### Listing 7.21 Example of an undeclared label

---

```
codeSec: SECTION
entry:
    NOP
    BNE entry
    NOP
    JMP end
    JMP label ; <- Undeclared user-defined symbol: label
end:RTS
    END
```

---

## Reserved symbols

Reserved symbols cannot be used for user-defined symbols.

Register names are reserved identifiers.

For the HC08 processor the reserved identifiers are listed in [Listing 7.22 on page 282](#).

### Listing 7.22 Reserved identifiers for an HC(S)08 derivative

---

```
A, CCR, H, X, SP
```

---

The keywords LOW and HIGH are also reserved identifiers. They are used to refer to the low byte and the high byte of a memory location. Also, PAGE is a reserved identifier.

Also, the keywords MAP\_ADDR\_6 and HIGH\_6\_13 are reserved identifiers.

HIGH\_6\_13 returns the higher byte for a given 14 bit address (used to load the PAGE register for the RS08). MAP\_ADDR\_6 will return the lower 6 bits in a 14-bit address (used to determine the offset in the paging window for the RS08).

# Constants

The Assembler supports integer and ASCII string constants:

## Integer constants

The Assembler supports four representations of integer constants:

- A decimal constant is defined by a sequence of decimal digits (0-9).  
Example: 5, 512, 1024
- A hexadecimal constant is defined by a dollar character (\$) followed by a sequence of hexadecimal digits (0-9, a-f, A-F).  
Example: \$5, \$200, \$400
- An octal constant is defined by the commercial at character (@) followed by a sequence of octal digits (0-7).  
Example: @5, @1000, @2000
- A binary constant is defined by a percent character followed by a sequence of binary digits (0-1)

**Example:**

%101, %1000000000, %10000000000

The default base for integer constant is initially decimal, but it can be changed using the [BASE - Set number base](#) assembler directive. When the default base is not decimal, decimal values cannot be represented, because they do not have a prefix character.

## String constants

A string constant is a series of printable characters enclosed in single ( ' ) or double quote ( " ). Double quotes are only allowed within strings delimited by single quotes. Single quotes are only allowed within strings delimited by double quotes. See [Listing 7.23 on page 283](#) for a variety of string constants.

### Listing 7.23 String constants

---

```
'ABCD', "ABCD", 'A', "'B", "A'B", 'A"B'
```

---

## Floating-Point constants

The Macro Assembler does not support floating-point constants.

## Operators

Operators recognized by the Assembler in expressions are:

- [Addition and subtraction operators \(binary\) on page 284](#)
- [Multiplication, division and modulo operators \(binary\) on page 285](#)
- [Sign operators \(unary\) on page 285](#)
- [Shift operators \(binary\) on page 286](#)
- [Bitwise operators \(binary\) on page 287](#)
- [Logical operators \(unary\) on page 288](#)
- [Relational operators \(binary\) on page 289](#)
- [HIGH operator on page 289](#)
- [on page 290HIGH\\_6\\_13 Operator on page 290](#)
- [LOW operator on page 290](#)
- [MAP\\_ADDR\\_6 Operator on page 291](#)
- [PAGE operator on page 292](#)
- [Force operator \(unary\) on page 292](#)

### Addition and subtraction operators (binary)

The addition and subtraction operators are + and -, respectively.

#### Syntax

Addition:     <operand> + <operand>

Subtraction: <operand> - <operand>

#### Description

The + operator adds two operands, whereas the - operator subtracts them. The operands can be any expression evaluating to an absolute or relocatable expression.

Addition between two relocatable operands is not allowed.

#### Example

See [Listing 7.24 on page 285](#) for an example of addition and subtraction operators.

**Listing 7.24 Addition and subtraction operators**

---

```
$A3216 + $42 ; Addition of two absolute operands (= $A3258)  
labelB - $10 ; Subtraction with value of 'labelB'
```

---

## Multiplication, division and modulo operators (binary)

The multiplication, division, and modulo operators are \*, /, and %, respectively.

### Syntax

```
Multiplication: <operand> * <operand>  
Division:      <operand> / <operand>  
Modulo:       <operand> % <operand>
```

### Description

The \* operator multiplies two operands, the / operator performs an integer division of the two operands and returns the quotient of the operation. The % operator performs an integer division of the two operands and returns the remainder of the operation

The operands can be any expression evaluating to an absolute expression. The second operand in a division or modulo operation cannot be zero.

### Example

See [Listing 7.25 on page 285](#) for an example of the multiplication, division, and modulo operators.

**Listing 7.25 Multiplication, division, and modulo operators**

---

```
23 * 4      ; multiplication (= 92)  
23 / 4      ; division (= 5)  
23 % 4      ; remainder(= 3)
```

---

## Sign operators (unary)

The (unary) sign operators are + and - .

---

## Syntax

Plus: +<operand>  
Minus: -<operand>

## Description

The + operator does not change the operand, whereas the – operator changes the operand to its two’s complement. These operators are valid for absolute expression operands.

## Example

See [Listing 7.26 on page 286](#) for an example of the unary sign operators.

### Listing 7.26 Unary sign operators

---

```
+$32      ; ( = $32)
-$32      ; ( = $CE = -$32)
```

---

## Shift operators (binary)

The binary shift operators are << and >>.

## Syntax

Shift left: <operand> << <count>  
Shift right: <operand> >> <count>

## Description

The << operator shifts its left operand left by the number of bits specified in the right operand.

The >> operator shifts its left operand right by the number of bits specified in the right operand.

The operands can be any expression evaluating to an absolute expression.



## Example

See [Listing 7.27 on page 287](#) for an example of the binary shift operators.

### Listing 7.27 Binary shift operators

---

```
$25 << 2      ; shift left (= $94)
$A5 >> 3      ; shift right(= $14)
```

---

## Bitwise operators (binary)

The binary bitwise operators are &, |, and ^.

### Syntax

```
Bitwise AND:      <operand> & <operand>
Bitwise OR:       <operand> | <operand>
Bitwise XOR:      <operand> ^ <operand>
```

### Description

The & operator performs an AND between the two operands on the bit level.

The | operator performs an OR between the two operands on the bit level.

The ^ operator performs an XOR between the two operands on the bit level.

The operands can be any expression evaluating to an absolute expression.

### Example

See [Listing 7.28 on page 287](#) for an example of the binary bitwise operators

### Listing 7.28 Binary bitwise operators

---

```
$E & 3        ; = $2 (%1110 & %0011 = %0010)
$E | 3        ; = $F (%1110 | %0011 = %1111)
$E ^ 3        ; = $D (%1110 ^ %0011 = %1101)
```

---

## Bitwise operators (unary)

The unary bitwise operator is ~.

### Syntax

One's complement: ~<operand>

### Description

The ~ operator evaluates the one's complement of the operand.

The operand can be any expression evaluating to an absolute expression.

### Example

See [Listing 7.29 on page 288](#) for an example of the unary bitwise operator.

#### Listing 7.29 Unary bitwise operator

---

```
~$C ; = $FFFFFFF3 (~%00000000 00000000 00000000 00001100  
                =%11111111 11111111 11111111 11110011)
```

---

## Logical operators (unary)

The unary logical operator is !.

### Syntax

Logical NOT: !<operand>

### Description

The ! operator returns 1 (true) if the operand is 0, otherwise it returns 0 (false).

The operand can be any expression evaluating to an absolute expression.

### Example

See [Listing 7.30 on page 289](#) for an example of the unary logical operator.

**Listing 7.30 Unary logical operator**

---

```
!(8<5) ; = $1 (TRUE)
```

---

## Relational operators (binary)

The binary relational operators are =, ==, !=, <>, <, <=, >, and >=.

### Syntax

---

Equal:	<operand> = <operand>
	<operand> == <operand>
Not equal:	<operand> != <operand>
	<operand> <> <operand>
Less than:	<operand> < <operand>
Less than or equal:	<operand> <= <operand>
Greater than:	<operand> > <operand>
Greater than or equal:	<operand> >= <operand>

---

### Description

These operators compare two operands and return 1 if the condition is 'true' or 0 if the condition is 'false'.

The operands can be any expression evaluating to an absolute expression.

### Example

See [Listing 7.31 on page 289](#) for an example of the binary relational operators

**Listing 7.31 Binary relational operators**

---

```
3 >= 4 ; = 0 (FALSE)
label = 4 ; = 1 (TRUE) if label is 4, 0 or (FALSE) otherwise.
9 < $B ; = 1 (TRUE)
```

---

## HIGH operator

The HIGH operator is HIGH.

## Syntax

High Byte: `HIGH(<operand>)`

## Description

This operator returns the high byte of the address of a memory location.

## Example

Assume `data1` is a word located at address `$1050` in the memory.

```
LDA #HIGH(data1)
```

This instruction will load the immediate value of the high byte of the address of `data1` (`$10`) in register A.

```
LDA HIGH(data1)
```

This instruction will load the direct value at memory location of the higher byte of the address of `data1` (i.e., the value in memory location `$10`) in register A.

## HIGH\_6\_13 Operator

### Syntax

High Byte: `HIGH_6_13(<operand>)`

### Description

This operator returns the high byte of a 14-bit address of a memory location.

### Example

Assume `data1` is a word located at address `$1010` in the memory.

```
LDA #HIGH_6_13(data1)
```

This instruction will load the value `$40` in the accumulator.

## LOW operator

The LOW operator is `LOW`.

## Syntax

LOW Byte: LOW(<operand>)

## Description

This operator returns the low byte of the address of a memory location.

## Example

Assume `data1` is a word located at address `$1050` in the memory.

```
LDA #LOW(data1)
```

This instruction will load the immediate value of the lower byte of the address of `data1` (`$50`) in register A.

```
LDA LOW(data1)
```

This instruction will load the direct value at memory location of the lower byte of the address of `data1` (i.e., the value in memory location `$50`) in register A.

## MAP\_ADDR\_6 Operator

### Syntax

MAP\_ADDR\_6 (<operand>)

### Description

This operator returns the lower 6 bits for a memory location. It should be used to determine the offset in the paging window for a certain memory address. Note that the operator automatically adds the offset of the base of the paging window (`$C0`).

### Example

```
MOV #HIGH_6_13(data), $001F
```

```
STA MAP_ADDR_6(data)
```

In this example, the RS08 PAGE register (mapped at `$001F`) is loaded with the memory page corresponding to `data` and then the value contained in the accumulator is stored at the address pointed by `data`.

## **PAGE operator**

The PAGE operator is PAGE.

### **Syntax**

PAGE Byte: PAGE (<operand>)

### **Description**

This operator returns the page byte of the address of a memory location.

### **Example**

Assume `data1` is a word located at address `$28050` in the memory.

```
LDA #PAGE (data1)
```

This instruction will load the immediate value of the page byte of the address of `data1` (`$2`).

```
LDA PAGE (data1)
```

This instruction will load the direct value at memory location of the page byte of the address of `data1` (i.e., the value in memory location `$2`).

---

**NOTE** The PAGE keyword does not refer to the RS08 PAGE register but to the PAGE operator described above.

---

## **Force operator (unary)**

### **Syntax**

8-bit address: <<operand> or <operand>.B

16-bit address: ><operand> or <operand>.W

## Description

The < or .B operators force the operand to be an 8-bit operand, whereas the > or .W operators force the operand to be a 16-bit operand.

The < operator may be useful to force the 8-bit immediate, 8-bit indexed, or direct addressing mode for an instruction.

> operator may be useful to force the 16-bit immediate, 16-bit indexed, or extended addressing mode for an instruction.

The operand can be any expression evaluating to an absolute or relocatable expression.

## Example

```
<label          ; label is a 8-bit address.
label.B         ; label is a 8-bit address.
>label          ; label is a 16-bit address.
label.W         ; label is a 16-bit address.
```

For the RS08 the < operand forces the operand to short or tiny addressing mode (depending on the instruction where it is used). The same result can be obtained by adding .S or .T to the referred symbol. The > operator may be used to force an address to 8 bits, even if it would fit in 4 or 5 bits (so short or tiny addressing modes could be used).

## Operator precedence

Operator precedence follows the rules for ANSI - C operators ([Table 7.6 on page 293](#))

**Table 7.6 Operator precedence priorities**

Operator	Description	Associativity
()	Parenthesis	Right to Left
~ + -	One's complement Unary Plus Unary minus	Left to Right
* / %	Integer multiplication Integer division Integer modulo	Left to Right
+ -	Integer addition Integer subtraction	Left to Right

**Table 7.6 Operator precedence priorities (*continued*)**

Operator	Description	Associativity
<< >>	Shift Left Shift Right	Left to Right
< <= > >=	Less than Less or equal to Greater than Greater or equal to	Left to Right
=, == !=, <>	Equal to Not Equal to	Left to Right
&	Bitwise AND	Left to Right
^	Bitwise Exclusive OR	Left to Right
	Bitwise OR	Left to Right

## Expression

An expression is composed of one or more symbols or constants, which are combined with unary or binary operators. Valid symbols in expressions are:

- User defined symbols
- External symbols
- The special symbol '\*' represents the value of the location counter at the beginning of the instruction or directive, even when several arguments are specified. In the following example, the asterisk represents the location counter at the beginning of the DC directive:

```
DC.W 1, 2, *-2
```

Once a valid expression has been fully evaluated by the Assembler, it is reduced as one of the following type of expressions:

- [Absolute expression on page 295](#): The expression has been reduced to an absolute value, which is independent of the start address of any relocatable section. Thus it is a constant. [Simple relocatable expression on page 296](#): The expression evaluates to an absolute offset from the start of a single relocatable section.
- Complex relocatable expression: The expression neither evaluates to an absolute expression nor to a simple relocatable expression. The Assembler does not support such expressions.



All valid user defined symbols representing memory locations are simple relocatable expressions. This includes labels specified in XREF directives, which are assumed to be relocatable symbols.

## Absolute expression

An absolute expression is an expression involving constants or known absolute labels or expressions. An expression containing an operation between an absolute expression and a constant value is also an absolute expression.

See [Listing 7.32 on page 295](#) for an example of an absolute expression.

### Listing 7.32 Absolute expression

---

```
Base: SET $100
Label: EQU Base * $5 + 3
```

---

Expressions involving the difference between two relocatable symbols defined in the same file and in the same section evaluate to an absolute expression. An expression as "label2-label1" can be translated as:

### Listing 7.33 Interpretation of label2-label1: difference between two relocatable symbols

---

```
(<offset label2> + <start section address >) -
(<offset label1> + <start section address >)
```

---

This can be simplified to ([Listing 7.34 on page 295](#)):

### Listing 7.34 Simplified result for the difference between two relocatable symbols

---

```
<offset label2> + <start section address > -
<offset label1> - <start section address>
= <offset label2> - <offset label1>
```

---

## Example

In the example in [Listing 7.35 on page 296](#), the expression "tabEnd-tabBegin" evaluates to an absolute expression and is assigned the value of the difference between the offset of tabEnd and tabBegin in the section DataSec.

## Assembler Syntax

### Expression

---

#### Listing 7.35 Absolute expression relating the difference between two relocatable symbols

---

```
DataSec: SECTION
tabBegin: DS.B 5
tabEnd:   DS.B 1

ConstSec: SECTION
label:    EQU tabEnd-tabBegin      ; Absolute expression

CodeSec: SECTION
entry:   NOP
```

---

## Simple relocatable expression

A simple relocatable expression results from an operation such as one of the following:

- <relocatable expression> + <absolute expression>
- <relocatable expression> - <absolute expression>
- <absolute expression> + <relocatable expression>

#### Listing 7.36 Example of relocatable expression

---

```
                XREF XtrnLabel
DataSec: SECTION
tabBegin: DS.B 5
tabEnd:   DS.B 1
CodeSec: SECTION
entry:
    LDA tabBegin+2      ; Simple relocatable expression
    BRA *-3             ; Simple relocatable expression
    LDA XtrnLabel+6    ; Simple relocatable expression
```

---

## Unary operation result

[Table 7.7 on page 297](#) describes the type of an expression according to the operator in an unary operation:

**Table 7.7 Expression type resulting from operator and operand type**

Operator	Operand	Expression
-, !, ~	absolute	absolute
-, !, ~	relocatable	complex
+	absolute	absolute
+	relocatable	relocatable

## Binary operations result

[Table 7.8 on page 297](#) describes the type of an expression according to the left and right operators in a binary operation:

**Table 7.8 Expression type resulting from operator and their operands**

Operator	Left Operand	Right Operand	Expression
-	absolute	absolute	absolute
-	relocatable	absolute	relocatable
-	absolute	relocatable	complex
-	relocatable	relocatable	absolute
+	absolute	absolute	absolute
+	relocatable	absolute	relocatable
+	absolute	relocatable	relocatable
+	relocatable	relocatable	complex
*, /, %, <<, >>,  , &, ^	absolute	absolute	absolute
*, /, %, <<, >>,  , &, ^	relocatable	absolute	complex
*, /, %, <<, >>,  , &, ^	absolute	relocatable	complex
*, /, %, <<, >>,  , &, ^	relocatable	relocatable	complex

# Translation limits

The following limitations apply to the Macro Assembler:

- Floating-point constants are not supported.
- Complex relocatable expressions are not supported.
- Lists of operands or symbols must be separated with a comma.
- Include may be nested up to 50.
- The maximum line length is 1023.

# Assembler Directives

There are different class of assembler directives. The following tables gives you an overview over the different directives and their class:

## Directive overview

### Section-Definition directives

The directives in [Table 8.1 on page 299](#) are used to define new sections.

**Table 8.1 Directives for defining sections**

Directive	Description
<a href="#">ORG - Set Location Counter on page 353</a>	Define an absolute section
<a href="#">SECTION - Declare Relocatable Section on page 361</a>	Define a relocatable section
<a href="#">OFFSET - Create absolute symbols on page 351</a>	Define an offset section

### Constant-Definition directives

The directives in [Table 8.2 on page 299](#) are used to define assembly constants.

**Table 8.2 Directives for defining constants**

Directive	Description
<a href="#">EQU - Equate symbol value on page 322</a>	Assign a name to an expression (cannot be redefined)
<a href="#">SET - Set Symbol Value on page 363</a>	Assign a name to an expression (can be redefined)

### Data-Allocation directives

The directives in [Table 8.3 on page 300](#) are used to allocate variables.

**Table 8.3 Directives for allocating variables**

Directive	Description
<a href="#">DC - Define Constant on page 311</a>	Define a constant variable
<a href="#">DCB - Define Constant Block on page 313</a>	Define a constant block
<a href="#">DS - Define Space on page 314</a>	Define storage for a variable
<a href="#">RAD50 - Rad50-encoded string constants on page 358</a>	RAD50 encoded string constants

### Symbol-Linkage directives

Symbol-linkage directives ([Table 8.4 on page 300](#)) are used to export or import global symbols.

**Table 8.4 Symbol linkage directives**

Directive	Description
<a href="#">ABSENTRY - Application entry point on page 304</a>	Specify the application entry point when an absolute file is generated
<a href="#">XDEF - External Symbol Definition on page 367</a>	Make a symbol public (visible from outside)
<a href="#">XREF - External Symbol Reference on page 368</a>	Import reference to an external symbol.
<a href="#">XREFB - External Reference for Symbols located on the Direct Page on page 369</a>	Import reference to an external symbol located on the direct page.

### Assembly-Control directives

Assembly-control directives ([Table 8.5 on page 300](#)) are general purpose directives used to control the assembly process.

**Table 8.5 Assembly control directives**

Directive	Description
<a href="#">ALIGN - Align Location Counter on page 306</a>	Define Alignment Constraint
<a href="#">BASE - Set number base on page 307</a>	Specify default base for constant definition
<a href="#">END - End assembly on page 318</a>	End of assembly unit
<a href="#">ENDFOR - End of FOR block on page 319</a>	End of FOR block
<a href="#">EVEN - Force word alignment on page 323</a>	Define 2-byte alignment constraint
<a href="#">FAIL - Generate Error message on page 325</a>	Generate user defined error or warning messages
<a href="#">FOR - Repeat assembly block on page 329</a>	Repeat assembly blocks
<a href="#">INCLUDE - Include text from another file on page 335</a>	Include text from another file.
<a href="#">LONGEVEN - Forcing Long-Word alignment on page 340</a>	Define 4 Byte alignment constraint

## Listing-File Control directives

Listing-file control directives ([Table 8.6 on page 301](#)) control the generation of the assembler listing file.

**Table 8.6 Listing-file control directives**

Directive	Description
<a href="#">CLIST - List conditional assembly on page 309</a>	Specify if all instructions in a conditional assembly block must be inserted in the listing file or not.
<a href="#">LIST - Enable Listing on page 336</a>	Specify that all subsequent instructions must be inserted in the listing file.
<a href="#">LLEN - Set Line Length on page 338</a>	Define line length in assembly listing file.

## Assembler Directives

### Directive overview

Table 8.6 Listing-file control directives (*continued*)

Directive	Description
<a href="#">MLIST - List macro expansions on page 345</a>	Specify if the macro expansions must be inserted in the listing file.
<a href="#">NOLIST - Disable Listing on page 348</a>	Specify that all subsequent instruction must not be inserted in the listing file.
<a href="#">NOPAGE - Disable Paging on page 350</a>	Disable paging in the assembly listing file.
<a href="#">PAGE - Insert Page break on page 355</a>	Insert page break.
<a href="#">PLEN - Set Page Length on page 357</a>	Define page length in the assembler listing file.
<a href="#">SPC - Insert Blank Lines on page 364</a>	Insert an empty line in the assembly listing file.
<a href="#">TABS - Set Tab Length on page 365</a>	Define number of character to insert in the assembler listing file for a TAB character.
<a href="#">TITLE - Provide Listing Title on page 366</a>	Define the user defined title for the assembler listing file.

## Macro Control directives

Macro control directives ([Table 8.7 on page 302](#)) are used for the definition and expansion of macros.

Table 8.7 Macro control directives

Directive	Description
<a href="#">ENDM - End macro definition on page 321</a>	End of user defined macro.
<a href="#">MACRO - Begin macro definition on page 341</a>	Start of user defined macro.
<a href="#">MEXIT - Terminate Macro Expansion on page 342</a>	Exit from macro expansion.

## Conditional Assembly directives

Conditional assembly directives ([Table 8.8 on page 302](#)) are used for conditional assembling.



**Table 8.8 Conditional assembly directives**

<b>Directive</b>	<b>Description</b>
<a href="#">ELSE - Conditional assembly on page 316</a>	alternate block
<a href="#">-Compat: Compatibility modes on page 319</a>	End of conditional block
<a href="#">IF - Conditional assembly on page 331</a>	Start of conditional block. A boolean expression follows this directive.
<a href="#">IFcc - Conditional assembly on page 333</a>	Test if two string expressions are equal.
IFDEF	Test if a symbol is defined.
IFEQ	Test if an expression is null.
IFGE	Test if an expression is greater or equal to 0.
IFGT	Test if an expression is greater than 0.
IFLE	Test if an expression is less or equal to 0.
IFLT	Test if an expression is less than 0.
IFNC	Test if two string expressions are different.
IFNDEF	Test if a symbol is undefined
IFNE	Test if an expression is not null.

## Detailed descriptions of all assembler directives

The remainder of the chapter covers the detailed description of all available assembler directives.

## Assembler Directives

Detailed descriptions of all assembler directives

---

# ABSENTRY - Application entry point

## Syntax

```
ABSENTRY <label>
```

## Synonym

None

## Description

This directive is used to specify the application Entry Point when the Assembler directly generates an absolute file. The -FA2 assembly option - ELF/DWARF 2.0 Absolute File - must be enabled.

Using this directive, the entry point of the assembly application is written in the header of the generated absolute file. When this file is loaded in the debugger, the line where the entry point label is defined is highlighted in the source window.

This directive is ignored when the Assembler generates an object file.

---

**NOTE** This instruction only affects the loading on an application by a debugger. It tells the debugger which initial PC should be used. In order to start the application on a target - initialize the Reset vector.

---

If the example in [Listing 8.1 on page 304](#) is assembled using the -FA2 assembler option, an ELF/DWARF 2.0 Absolute file is generated.

### Listing 8.1 Using ABSENTRY to specify an application entry point

---

```
ABSENTRY entry

Reset:  ORG    $fffe
        DC.W  entry
        ORG    $70
entry:  NOP
        NOP
main:   RSP
        NOP
        BRA   main
```

---

## **Assembler Directives**

*Detailed descriptions of all assembler directives*

---

According to the `ABSENTRY` directive, the entry point will be set to the address of entry in the header of the absolute file.

## Assembler Directives

Detailed descriptions of all assembler directives

---

### ALIGN - Align Location Counter

#### Syntax

```
ALIGN <n>
```

#### Synonym

None

#### Description

This directive forces the next instruction to a boundary that is a multiple of <n>, relative to the start of the section. The value of <n> must be a positive number between 1 and 32767. The ALIGN directive can force alignment to any size. The filling bytes inserted for alignment purpose are initialized with '\0'.

ALIGN can be used in code or data sections.

#### Example

The example shown in [Listing 8.2 on page 306](#) aligns the HEX label to a location, which is a multiple of 16 (in this case, location 00010 (Hex))

#### Listing 8.2 Aligning the HEX Label to a Location

---

Assembler

Abs.	Rel.	Loc	Obj. code	Source line
----	----	-----	-----	-----
1	1			
2	2	000000	6869 6768	DC.B "high"
3	3	000004	0000 0000	ALIGN 16
		000008	0000 0000	
		00000C	0000 0000	
4	4			
5	5			
6	6	000010	7F	HEX: DC.B 127 ; HEX is allocated
7	7			; on an address,
8	8			; which is a
9	9			; multiple of 16.

---

## BASE - Set number base

### Syntax

BASE <n>

### Synonym

None

### Description

The directive sets the default number base for constants to <n>. The operand <n> may be prefixed to indicate its number base; otherwise, the operand is considered to be in the current default base. Valid values of <n> are 2, 8, 10, 16. Unless a default base is specified using the BASE directive, the default number base is decimal.

### Example

See [Listing 8.3 on page 307](#) for examples of setting the number base.

#### Listing 8.3 Setting the number base

---

4	4		base	10	; default base: decimal
5	5	000000	dc.b	100	
6	6		base	16	; default base: hex
7	7	000001	dc.b	0a	
8	8		base	2	; default base: binary
9	9	000002	dc.b	100	
10	10	000003	dc.b	%100	
11	11		base	@12	; default base: decimal
12	12	000004	dc.b	100	
13	13		base	\$a	; default base: decimal
14	14	000005	dc.b	100	
15	15				
16	16		base	8	; default base: octal
17	17	000006	dc.b	100	

---

Be careful. Even if the base value is set to 16, hexadecimal constants terminated by a 'D' must be prefixed by the \$ character, otherwise they are supposed to be

## **Assembler Directives**

*Detailed descriptions of all assembler directives*

---

decimal constants in old style format. For example, constant 45D is interpreted as decimal constant 45, not as hexadecimal constant 45D.

## CLIST - List conditional assembly

### Syntax

```
CLIST [ON|OFF]
```

### Synonym

None

### Description

The CLIST directive controls the listing of subsequent conditional assembly blocks. It precedes the first directive of the conditional assembly block to which it applies, and remains effective until the next CLIST directive is read.

When the ON keyword is specified in a CLIST directive, the listing file includes all directives and instructions in the conditional assembly block, even those which do not generate code (which are skipped).

When the OFF keyword is entered, only the directives and instructions that generate code are listed.

As soon as the [-L: Generate a listing file](#) assembler option is activated, the Assembler defaults to CLIST ON.

### Example

[Listing 8.4 on page 309](#) is an example where the CLIST OFF option is used.

#### Listing 8.4 Listing file with CLIST OFF

---

```
CLIST OFF
Try: EQU 0
    IFEQ Try
        LDA #103
    ELSE
        LDA #0
    ENDIF
```

---

## Assembler Directives

Detailed descriptions of all assembler directives

---

[Listing 8.5 on page 310](#) is the corresponding listing file.

### Listing 8.5 Example assembler listing where CLIST ON is used

---

Abs. Rel.	Loc	Obj. code	Source line
2	2	0000 0000	Try: EQU 0
3	3	0000 0000	IFEQ Try
4	4	000000 A667	LDA #103
5	5		ELSE
7	7		ENDIF

---

[Listing 8.6 on page 310](#) is a listing file where CLIST ON is used.

### Listing 8.6 CLIST ON is selected

---

```
CLIST ON
Try: EQU 0
IFEQ Try
LDA #103
ELSE
LDA #0
ENDIF
```

---

[Listing 8.7 on page 310](#) is the corresponding listing file.

### Listing 8.7 Example assembler listing where CLIST ON is used

---

Abs. Rel.	Loc	Obj. code	Source line
2	2	0000 0000	Try: EQU 0
3	3	0000 0000	IFEQ Try
4	4	000000 A667	LDA #103
5	5		ELSE
6	6		LDA #0
7	7		ENDIF
8	8		

---



## DC - Define Constant

### Syntax

```
[<label>:] DC [.<size>] <expression> [,  
<expression>]...
```

where <size> = B (default), W, or L.

### Synonym

```
DCW (= 2 byte DCs),   DCL (= 4 byte DCs),  
FCB (= DC.B),   FDB   (= 2 byte DCs),  
FQB (= 4 byte DCs)
```

### Description

The DC directive defines constants in memory. It can have one or more <expression> operands, which are separated by commas. The <expression> can contain an actual value (binary, octal, decimal, hexadecimal, or ASCII). Alternatively, the <expression> can be a symbol or expression that can be evaluated by the Assembler as an absolute or simple relocatable expression. One memory block is allocated and initialized for each expression.

The following rules apply to size specifications for DC directives:

- DC.B: One byte is allocated for numeric expressions. One byte is allocated per ASCII character for strings ([Listing 8.8 on page 311](#)).
- DC.W: Two bytes are allocated for numeric expressions. ASCII strings are right aligned on a two-byte boundary ([Listing 8.9 on page 312](#)).
- DC.L: Four bytes are allocated for numeric expressions. ASCII strings are right aligned on a four byte boundary ([Listing 8.10 on page 312](#)).

#### Listing 8.8 Example for DC.B

---

```
000000 4142 4344   Label: DC.B "ABCDE"  
000004 45  
000005 0A0A 010A           DC.B %1010, @12, 1,$A
```

---

## Assembler Directives

*Detailed descriptions of all assembler directives*

---

### Listing 8.9 Example for DC.W

---

```
000000 0041 4243   Label: DC.W "ABCDE"  
000004 4445  
000006 000A 000A           DC.W %1010, @12, 1, $A  
00000A 0001 000A  
00000E xxxx           DC.W Label
```

---

### Listing 8.10 Example for DC.L

---

```
000000 0000 0041   Label: DC.L "ABCDE"  
000004 4243 4445  
000008 0000 000A           DC.L %1010, @12, 1, $A  
00000C 0000 000A  
000010 0000 0001  
000014 0000 000A  
000018 xxxx xxxx           DC.L Label
```

---

If the value in an operand expression exceeds the size of the operand, the value is truncated and a warning message is generated.

## See also

Assembler directives:

- [DCB - Define Constant Block on page 313](#)
- [DS - Define Space on page 314](#)
- [ORG - Set Location Counter on page 353](#)
- [SECTION - Declare Relocatable Section on page 361](#)

## DCB - Define Constant Block

### Syntax

```
[<label>:] DCB [.<size>] <count>, <value>  
where <size> = B (default), W, or L.
```

### Description

The DCB directive causes the Assembler to allocate a memory block initialized with the specified <value>. The length of the block is <size> \* <count>. <count> may not contain undefined, forward, or external references. It may range from 1 to 4096.

The value of each storage unit allocated is the sign-extended expression <value>, which may contain forward references. The <count> cannot be relocatable. This directive does not perform any alignment.

The following rules apply to size specifications for DCB directives:

- DCB.B: One byte is allocated for numeric expressions.
- DCB.W: Two bytes are allocated for numeric expressions.
- DCB.L: Four bytes are allocated for numeric expressions.

### Listing 8.11 Examples of DCB directives

---

```
000000 FFFF FF      Label: DCB.B 3, $FF  
000003 FFFE FFFE      DCB.W 3, $FFFE  
000007 FFFE  
000009 0000 FFFE      DCB.L 3, $FFFE  
00000D 0000 FFFE  
000011 0000 FFFE
```

---

### See also

**Assembler directives:**

- [DC - Define Constant on page 311](#)
- [DS - Define Space on page 314](#)
- [ORG - Set Location Counter on page 353](#)
- [SECTION - Declare Relocatable Section on page 361](#)

## Assembler Directives

Detailed descriptions of all assembler directives

---

### DS - Define Space

#### Syntax

```
[<label>:] DS[.<size>] <count>
```

where <size> = B (default), W, or L.

#### Synonym

```
RMB (= DS.B)  
RMD (2 bytes)  
RMQ (4 bytes)
```

#### Description

The DS directive is used to reserve memory for variables ([Listing 8.12 on page 314](#)). The content of the memory reserved is not initialized. The length of the block is

$\text{<size> * <count>}$ .

<count> may not contain undefined, forward, or external references. It may range from 1 to 4096.

#### Listing 8.12 Examples of DS directives

---

```
Counter: DS.B 2 ; 2 continuous bytes in memory  
         DS.B 2 ; 2 continuous bytes in memory  
         ; can only be accessed through the label Counter  
         DS.W 5 ; 5 continuous words in memory
```

---

The label `Counter` references the lowest address of the defined storage area.

---

**NOTE** Storage allocated with a DS directive may end up in constant data section or even in a code section, if the same section contains constants or code as well. The Assembler allocates only a complete section at once.

---

## Example

In [Listing 8.13 on page 315 on page 315](#), a variable, a constant, and code were put in the same section. Because code has to be in ROM, then all three elements must be put into ROM. In order to allocate them separately, put them in different sections ([Listing 8.14 on page 315](#)).

### Listing 8.13 Poor memory allocation

---

```
; How it should NOT be done ...
Counter:      DS 1      ; 1-byte used
InitialCounter: DC.B $f5 ; constant $f5
main:         NOP      ; NOP instruction
```

---

### Listing 8.14 How it should be done...

---

```
DataSect:     SECTION   ; separate section for variables
Counter:      DS 1      ; 1-byte used

ConstSect:    SECTION   ; separate section for constants
InitialCounter: DC.B $f5 ; constant $f5

CodeSect:     SECTION   ; section for code
main:         NOP      ; NOP instruction
```

---

An ORG directive also starts a new section.

## See also

### Assembler directives:

- [DC - Define Constant on page 311](#)
- [ORG - Set Location Counter on page 353](#)
- [SECTION - Declare Relocatable Section on page 361](#)

## Assembler Directives

Detailed descriptions of all assembler directives

---

## ELSE - Conditional assembly

### Syntax

```
IF <condition>
    [<assembly language statements>]
[ELSE]
    [<assembly language statements>]
ENDIF
```

### Synonym

ELSEC

### Description

If <condition> is true, the statements between IF and the corresponding ELSE directive are assembled (generate code).

If <condition> is false, the statements between ELSE and the corresponding ENDIF directive are assembled. Nesting of conditional blocks is allowed. The maximum level of nesting is limited by the available memory at assembly time.

### Example

[Listing 8.15 on page 316](#) is an example of the use of conditional assembly directives:

#### Listing 8.15 Various conditional assembly directives

---

```
Try: EQU      1
     IF Try   != 0
         LDA   #103
     ELSE
         LDA   #0
     ENDIF
```

---

The value of Try determines the instruction to be assembled in the program. As shown, the "lda #103" instruction is assembled. Changing the operand of the "EQU" directive to 0 causes the "lda #0" instruction to be assembled instead.

---

---

**Listing 8.16** Output listing of [Listing 8.15 on page 316](#)

---

Abs.	Rel.	Loc	Obj. code	Source line
1	1		0000 0001	Try: EQU 1
2	2		0000 0001	IF Try != 0
3	3	000000	A667	LDA #103
4	4			ELSE
6	6			ENDIF

---

## Assembler Directives

Detailed descriptions of all assembler directives

---

# END - End assembly

## Syntax

END

## Synonym

None

## Description

The END directive indicates the end of the source code. Subsequent source statements in this file are ignored. The END directive in included files skips only subsequent source statements in this include file. The assembly continues in the including file in a regular way.

## Example

The END statement in [Listing 8.17 on page 318](#) causes any source code after the END statement to be ignored, as in [Listing 8.18 on page 318](#).

### Listing 8.17 Source File

---

```
Label:  DC.W  $1234
        DC.W  $5678
        END
        DC.W  $90AB ; no code generated
        DC.W  $CDEF ; no code generated
```

---

### Listing 8.18 Generated listing file

---

Abs.	Rel.	Loc	Obj. code	Source line
----	----	-----	-----	-----
1	1	000000	1234	Label: DC.W \$1234
2	2	000002	5678	DC.W \$5678

---



## ENDFOR - End of FOR block

### Syntax

ENDFOR

### Synonym

None

### Description

The ENDFOR directive indicates the end of a FOR block.

---

**NOTE** The FOR directive is only available when the `-Compat=b` assembler option is used. Otherwise, the FOR directive is not supported.

---

### Example

See [Listing 8.28 on page 329](#) in the FOR.section.

### See also

**Assembler directives:**

- [FOR - Repeat assembly block on page 329](#)
- [-Compat: Compatibility modes](#)

## Assembler Directives

*Detailed descriptions of all assembler directives*

---

# ENDIF - End conditional assembly

## Syntax

ENDIF

## Synonym

ENDC

## Description

The ENDF directive indicates the end of a conditional block. Nesting of conditional blocks is allowed. The maximum level of nesting is limited by the available memory at assembly time.

## Example

See [Listing 8.30 on page 331](#) in the IF section.

## See also

[IF - Conditional assembly on page 331](#) assembler directive

## ENDM - End macro definition

### Syntax

ENDM

### Synonym

None

### Description

The ENDM directive terminates the macro definition ([Listing 8.19 on page 321](#)).

### Example

The ENDM statement in [Listing 8.19 on page 321](#) terminates the cpChar macro.

#### Listing 8.19 Using ENDM to terminate a macro definition

---

```
cpChar:  MACRO
          LDA   \1
          STA   \2
        ENDM
CodeSec: SECTION
Start:
        cpChar char1, char2
        LDA   char1
        STA   char2
```

---

## Assembler Directives

Detailed descriptions of all assembler directives

---

### EQU - Equate symbol value

#### Syntax

```
<label>: EQU <expression>
```

#### Synonym

None

#### Description

The EQU directive assigns the value of the <expression> in the operand field to <label>. The <label> and <expression> fields are both required, and the <label> cannot be defined anywhere else in the program. The <expression> cannot include a symbol that is undefined or not yet defined.

The EQU directive does not allow forward references.

#### Example

See [Listing 8.20 on page 322](#) for examples of using the EQU directive.

#### Listing 8.20 Using EQU to set variables

---

```
0000 0014  MaxElement: EQU 20
0000 0050  MaxSize:    EQU  MaxElement * 4

                Time:    DS.B 3
0000 0000  Hour:    EQU  Time    ; first byte addr.
0000 0002  Minute:  EQU  Time+1  ; second byte addr
0000 0004  Second:  EQU  Time+2  ; third byte addr
```

---

## **EVEN - Force word alignment**

### **Syntax**

EVEN

### **Synonym**

None

### **Description**

This directive forces the next instruction to the next even address relative to the start of the section. EVEN is an abbreviation for ALIGN 2. Some processors require word and long word operations to begin at even address boundaries. In such cases, the use of the EVEN directive ensures correct alignment. Omission of this directive can result in an error message.

### **Example**

See [Listing 8.21 on page 323](#) for instances where the EVEN directive causes padding bytes to be inserted.

#### **Listing 8.21 Using the Force Word Alignment Directive**

---

Abs.	Rel.	Loc	Obj. code	Source line
----	----	-----	-----	-----
1	1	000000		ds.b 4
2	2			; location count has an even value
3	3			; no padding byte inserted.
4	4			even
5	5	000004		ds.b 1
6	6			; location count has an odd value
7	7			; one padding byte inserted.
8	8	000005		even
9	9	000006		ds.b 3
10	10			; location count has an odd value
11	11			; one padding byte inserted.
12	12	000009		even
13	13		0000 000A	aaa: equ 10

---

## Assembler Directives

*Detailed descriptions of all assembler directives*

---

### See also

[ALIGN - Align Location Counter on page 306](#) assembly directive

## FAIL - Generate Error message

### Syntax

```
FAIL <arg>|<string>
```

### Synonym

None

### Description

There are three modes of the FAIL directive, depending upon the operand that is specified:

- If <arg> is a number in the range [0–499], the Assembler generates an error message, including the line number and argument of the directive. The Assembler does not generate an object file.
- If <arg> is a number in the range [500–\$FFFFFFFF], the Assembler generates a warning message, including the line number and argument of the directive.
- If a string is supplied as an operand, the Assembler generates an error message, including the line number and the <string>. The Assembler does not generate an object file.
- The FAIL directive is primarily intended for use with conditional assembly to detect user-defined errors or warning conditions.

### Examples

The assembly code in [Listing 8.22 on page 325](#) generates the error messages in [Listing 8.23 on page 326](#). The value of the operand associated with the 'FAIL 200' or 'FAIL 600' directives determines (1) the format of any warning or error message and (2) whether the source code segment will be assembled.

#### Listing 8.22 Example source code

---

```
cpChar: MACRO
        IFC "\1", ""
        FAIL 200
        MEXIT
```

## Assembler Directives

Detailed descriptions of all assembler directives

---

```
        ELSE
        LDA    \1
        ENDIF

        IFC  "\2", ""
        FAIL  600
        ELSE
        STA    \2
        ENDIF
    ENDM
codSec: SECTION
Start:
        cpChar char1
```

---

### Listing 8.23 Error messages resulting from assembling the source code in [Listing 8.22 on page 325](#)

---

```
>> in "C:\Freescale\demo\warnfail.asm", line 13, col 19, pos 226
```

```
        IFC  "\2", ""
        FAIL  600
        ^
```

```
WARNING A2332: FAIL found
Macro Call :          FAIL 600
```

---

[Listing 8.24 on page 326](#) is another assembly code example which again incorporates the 'FAIL 200' and the 'FAIL 600' directives. [Listing 8.25 on page 327](#) is the error message that was generated as a result of assembling the source code in [Listing 8.24 on page 326](#).

### Listing 8.24 Example source code

---

```
cpChar: MACRO
        IFC  "\1", ""
        FAIL  200
        MEXIT
    ELSE
        LDA    \1
        ENDIF

        IFC  "\2", ""
        FAIL  600
    ELSE
        STA    \2
```

---



```
        ENDIF
        ENDM
codeSec: SECTION
Start:
        cpChar, char2
```

---

**Listing 8.25 Error messages resulting from assembling the source code in [Listing 8.24 on page 326](#)**

---

```
>> in "C:\Freescale\demo\errfail.asm", line 6, col 19, pos 96

        IFC "\1", ""
            FAIL 200
            ^
ERROR A2329: FAIL found
Macro Call :                FAIL 200
```

---

[Listing 8.26 on page 327](#) has additional uses of the FAIL directive. In this example, the 'FAIL string' and 'FAIL 600' directives are used. Any error messages generated from the assembly code as a result of the FAIL directive are listed in [Listing 8.27 on page 328](#).

**Listing 8.26 Example source code**

---

```
cpChar: MACRO
        IFC "\1", ""
            FAIL "A character must be specified as first parameter"
            MEXIT
        ELSE
            LDA \1
        ENDIF

        IFC "\2", ""
            FAIL 600
        ELSE
            STA \2
        ENDIF
    ENDM
codeSec: SECTION
Start:
        cpChar, char2
```

---

## Assembler Directives

*Detailed descriptions of all assembler directives*

---

### Listing 8.27 Error messages resulting from assembling the source code in [Listing 8.26 on page 327](#)

---

```
>> in "C:\Freescale\demo\failmes.asm", line 7, col 17, pos 110
    IFC "\1", ""
        FAIL "A character must be specified as first parameter"
            ^
ERROR A2338: A character must be specified as first parameter
Macro Call :   FAIL "A character must be specified as first parameter"
```

---

## FOR - Repeat assembly block

### Syntax

```
FOR <label>=<num> TO <num>  
ENDFOR
```

### Synonym

None

### Description

The FOR directive is an inline macro because it can generate multiple lines of assembly code from only one line of input code.

FOR takes an absolute expression and assembles the portion of code following it, the number of times represented by the expression. The FOR expression may be either a constant or a label previously defined using EQU or SET.

---

**NOTE** The FOR directive is only available when the -Compat=b assembly option is used. Otherwise, the FOR directive is not supported.

---

### Example

[Listing 8.28 on page 329](#) is an example of using FOR to create a 5-repetition loop.

#### Listing 8.28 Using the FOR directive in a loop

---

```
FOR label=2 TO 6  
  DC.B  label*7  
ENDFOR
```

---

#### Listing 8.29 Resulting output listing

---

Abs.	Rel.	Loc	Obj. code	Source line
----	----	-----	-----	-----
1	1			FOR label=2 TO 6
2	2			DC.B  label*7
3	3			ENDFOR

---

## Assembler Directives

*Detailed descriptions of all assembler directives*

---

4	2	000000	0E	DC.B	label*7
5	3			ENDFOR	
6	2	000001	15	DC.B	label*7
7	3			ENDFOR	
8	2	000002	1C	DC.B	label*7
9	3			ENDFOR	
10	2	000003	23	DC.B	label*7
11	3			ENDFOR	
12	2	000004	2A	DC.B	label*7
13	3			ENDFOR	

---

### See also

[on page 319](#)[ENDFOR - End of FOR block on page 319](#)

[-Compat: Compatibility modes](#) assembler option

## IF - Conditional assembly

### Syntax

```
IF <condition>
    [<assembly language statements>]
[ELSE]
    [<assembly language statements>]
ENDIF
```

### Synonym

None

### Description

If <condition> is true, the statements immediately following the IF directive are assembled. Assembly continues until the corresponding ELSE or ENDIF directive is reached. Then all the statements until the corresponding ENDIF directive are ignored. Nesting of conditional blocks is allowed. The maximum level of nesting is limited by the available memory at assembly time.

The expected syntax for <condition> is:

```
<condition> := <expression> <relation> <expression>
<relation>  := =|!=|>=|>|<=|<|<>
```

The <expression> must be absolute (It must be known at assembly time).

### Example

[Listing 8.30 on page 331](#) is an example of the use of conditional assembly directives

#### Listing 8.30 IF and ENDIF

---

```
Try: EQU    0
      IF Try != 0
          LDA    #103
      ELSE
          LDA    #0
      ENDIF
```

---

## Assembler Directives

*Detailed descriptions of all assembler directives*

---

The value of Try determines the instruction to be assembled in the program. As shown, the "lda #0" instruction is assembled. Changing the operand of the "EQU" directive to one causes the "lda #103" instruction to be assembled instead. The following shows the listing provided by the Assembler for these lines of code:

### Listing 8.31 Output listing after conditional assembly

---

```
1 1          0000 0000   Try: EQU   0
2 2          0000 0000       IF Try != 0
4 4                          ELSE
5 5 000000 A600          LDA   #0
6 6                          ENDIF
```

---

## IFcc - Conditional assembly

### Syntax

```
IFcc <condition>  
    [<assembly language statements>]  
[ELSE]  
    [<assembly language statements>]  
ENDIF
```

### Synonym

None

### Description

These directives can be replaced by the IF directive `Ifcc <condition>` is true, the statements immediately following the `Ifcc` directive are assembled. Assembly continues until the corresponding `ELSE` or `ENDIF` directive is reached, after which assembly moves to the statements following the `ENDIF` directive. Nesting of conditional blocks is allowed. The maximum level of nesting is limited by the available memory at assembly time.

[Table 8.9 on page 333](#) lists the available conditional types:

**Table 8.9 Conditional assembly types**

<b>ifcc</b>	<b>Condition</b>	<b>Meaning</b>
ifeq	<expression>	if <expression> == 0
ifne	<expression>	if <expression> != 0
iflt	<expression>	if <expression> < 0
ifle	<expression>	if <expression> <= 0
ifgt	<expression>	if <expression> > 0
ifge	<expression>	if <expression> >= 0
ifc	<string1>, <string2>	if <string1> == <string2>
ifnc	<string1>, <string2>	if <string1> != <string2>

## Assembler Directives

Detailed descriptions of all assembler directives

**Table 8.9 Conditional assembly types (continued)**

Ifcc	Condition	Meaning
ifdef	<label>	if <label> was defined
ifndef	<label>	if <label> was not defined

### Example

[Listing 8.32 on page 334](#) is an example of the use of conditional assembler directives:

**Listing 8.32 Using the IFNE conditional assembler directive**

```
Try: EQU 0
      IFNE Try
          LDA #103
      ELSE
          LDA #0
      ENDIF
```

The value of Try determines the instruction to be assembled in the program. As shown, the "lda #0" instruction is assembled. Changing the directive to "IFEQ" causes the "lda #103" instruction to be assembled instead.

[Listing 8.33 on page 334](#) shows the listing provided by the Assembler for these lines of code

**Listing 8.33 output listing for [Listing 8.32 on page 334](#)**

```
1 1          0000 0000  Try: EQU 0
2 2          0000 0000  IFNE Try
4 4          ELSE
5 5 000000 A600      LDA #0
6 6          ENDIF
```



## INCLUDE - Include text from another file

### Syntax

```
INCLUDE <file specification>
```

### Synonym

None

### Description

This directive causes the included file to be inserted in the source input stream. The <file specification> is not case-sensitive and must be enclosed in quotation marks.

The Assembler attempts to open <file specification> relative to the current working directory. If the file is not found there, then it is searched for relative to each path specified in the [GENPATH: Search path for input file](#) environment variable.

### Example

```
INCLUDE "..\LIBRARY\macros.inc"
```

## Assembler Directives

Detailed descriptions of all assembler directives

---

### LIST - Enable Listing

#### Syntax

```
LIST
```

#### Synonym

None

#### Description

Specifies that instructions following this directive must be inserted into the listing and into the debug file. This is a default option. The listing file is only generated if the [-L: Generate a listing file](#) assembler option is specified on the command line.

The source text following the LIST directive is listed until a [NOLIST - Disable Listing on page 348](#) or an [END - End assembly on page 318](#) assembler directive is reached

This directive is not written to the listing and debug files.

#### Example

The assembly source code using the LIST and NOLIST directives in [Listing 8.34 on page 336](#) generates the output listing in [Listing 8.35 on page 337](#).

#### Listing 8.34 Using the LIST and NOLIST assembler directives

---

```
aaa:    NOP

        LIST
bbb:    NOP
        NOP

        NOLIST
ccc:    NOP
        NOP

        LIST
ddd:    NOP          NOP
```

---

**Listing 8.35** Output listing generated from running [Listing 8.34 on page 336](#)

---

Abs.	Rel.	Loc	Obj. code	Source line
----	----	-----	-----	-----
1	1	000000	9D	aaa: NOP
2	2			
4	4	000001	9D	bbb: NOP
5	5	000002	9D	NOP
6	6			
12	12	000005	9D	ddd: NOP
13	13	000006	9D	NOP

---

## Assembler Directives

Detailed descriptions of all assembler directives

---

# LLEN - Set Line Length

## Syntax

LLEN<n>

## Synonym

None

## Description

Sets the number of characters from the source line that are included on the listing line to <n>. The values allowed for <n> are in the range [0 - 132]. If a value smaller than 0 is specified, the line length is set to 0. If a value bigger than 132 is specified, the line length is set to 132.

Lines of the source file that exceed the specified number of characters are truncated in the listing file.

## Example

The following portion of code in [Listing 8.37 on page 338](#) generates the listing file in [Listing 8.37 on page 338](#). Notice that the 'LLEN 24' directive causes the output at the location-counter line 7 to be truncated.

### Listing 8.36 Example assembly source code using LLEN

---

```
DC.B $55
LLEN 32
DC.W $1234, $4567

LLEN 24
DC.W $1234, $4567
EVEN
```

---

### Listing 8.37 Formatted assembly output listing as a result of using LLEN

---

Abs.	Rel.	Loc	Obj.	code	Source line
----	----	-----	-----	-----	-----
1	1	000000	55		DC.B \$55

---

## Assembler Directives

*Detailed descriptions of all assembler directives*

---

2	2				
4	4	000001	1234	4567	DC.W \$1234, \$4567
5	5				
7	7	000005	1234	4567	DC.W \$1234, \$
8	8	000009	00		EVEN

---

## Assembler Directives

Detailed descriptions of all assembler directives

---

### LONGEVEN - Forcing Long-Word alignment

#### Syntax

LONGEVEN

#### Synonym

None

#### Description

This directive forces the next instruction to the next long-word address relative to the start of the section. LONGEVEN is an abbreviation for ALIGN 4.

#### Example

See [Listing 8.38 on page 340](#) for an example where LONGEVEN aligns the next instruction to have its location counter to be a multiple of four (bytes).

#### Listing 8.38 Forcing Long Word Alignment

---

```
 2   2   000000 01                               dcb.b 1,1
      ; location counter is not a multiple of 4; three filling
      ; bytes are required.
 3   3   000001 0000 00                           longeven
 4   4   000004 0002 0002                         dcb.w 2,2
      ; location counter is already a multiple of 4; no filling
      ; bytes are required.
 5   5                               longeven
 6   6   000008 0202                               dcb.b 2,2
 7   7   ; following is for text section
 8   8                               s27          SECTION 27
 9   9   000000 9D                               nop
      ; location counter is not a multiple of 4; three filling
      ; bytes are required.
10  10  000001 0000 00                           longeven
11  11  000004 9D                               nop
```

---

## MACRO - Begin macro definition

### Syntax

```
<label>: MACRO
```

### Synonym

None

### Description

The <label> of the MACRO directive is the name by which the macro is called. This name must not be a processor machine instruction or assembler directive name. For more information on macros, see the [Macros](#) chapter.

### Example

See [Listing 8.39 on page 341](#) for a macro definition.

#### Listing 8.39 Example macro definition

---

```
                XDEF  Start
MyData: SECTION
char1:  DS.B  1
char2:  DS.B  1
cpChar: MACRO
        LDA   \1
        STA   \2
        ENDM
CodeSec: SECTION
Start:
        cpChar char1, char2
        LDA   char1
        STA   char2
```

---

## Assembler Directives

Detailed descriptions of all assembler directives

---

### MEXIT - Terminate Macro Expansion

#### Syntax

MEXIT

#### Synonym

None

#### Description

MEXIT is usually used together with conditional assembly within a macro. In that case it may happen that the macro expansion should terminate prior to termination of the macro definition. The MEXIT directive causes macro expansion to skip any remaining source lines ahead of the [ENDM - End macro definition on page 321](#) directive.

#### Example

See [Listing 8.40 on page 342](#) allows the replication of simple instructions or directives using MACRO with MEXIT.

#### Listing 8.40 Example assembly code using MEXIT

---

```
XDEF  entry

storage: EQU  $00FF

save:  MACRO          ; Start macro definition
      LDX  #storage
      LDA  \1
      STA  0,x        ; Save first argument
      LDA  \2
      STA  2,x        ; Save second argument
      IFC  '\3', ''   ; Is there a third argument?
          MEXIT       ; No, exit from macro
      ENDC
      LDA  \3        ; Save third argument
          STA  4,X
      ENDM          ; End of macro definition

datSec: SECTION
```

---



## Assembler Directives

Detailed descriptions of all assembler directives

```
char1: ds.b 1
char2: ds.b 1

codSec: SECTION
entry:
    save char1, char2
```

[Listing 8.41 on page 343](#) shows the macro expansion of the previous macro.

### Listing 8.41 Macro expansion of [Listing 8.40 on page 342](#)

Abs.	Rel.	Loc	Obj. code	Source line
1	1			XDEF entry
2	2		0000 00FF	storage: EQU \$00FF
3	3			
4	4			save: MACRO ; Start macro definition
5	5			LDX #storage
6	6			LDA \1
7	7			STA 0,x ; Save first arg
8	8			LDA \2
9	9			STA 2,x ; Save second arg
10	10			IFC '\3', '' ; is there a
11	11			MEXIT ; No, exit from macro.
12	12			ENDC
13	13			LDA \3 ; Save third argument
14	14			STA 4,X
15	15			ENDM ; End of macro defin
16	16			
17	17			datSec: SECTION
18	18	000000		char1: ds.b 1
19	19	000001		char2: ds.b 1
20	20			
21	21			
22	22			
23	23			codSec: SECTION
24	24			entry:
25	25			save char1, char2
26	5m	000000	A EFF	+ LDX #storage
27	6m	000002	C6 xxxx	+ LDA char1
28	7m	000005	E700	+ STA 0,x ; Save first arg
29	8m	000007	C6 xxxx	+ LDA char2
30	9m	00000A	E702	+ STA 2,x ; Save second
31	10m		0000 0001	+ IFC '', '' ; Is there a
33	11m			+ MEXIT ; no, exit macro.
34	12m			+ ENDC

## Assembler Directives

*Detailed descriptions of all assembler directives*

---

35	13m	+	LDA		; Save third argu
36	14m	+	STA	4,X	

---

## MLIST - List macro expansions

### Syntax

```
MLIST [ON|OFF]
```

### Description

When the ON keyword is entered with an MLIST directive, the Assembler includes the macro expansions in the listing and in the debug file.

When the OFF keyword is entered, the macro expansions are omitted from the listing and from the debug file.

This directive is not written to the listing and debug file, and the default value is ON.

### Synonym

None

### Example

The assembly code in [Listing 8.42 on page 345](#), with MLIST ON, generates the assembler output listing in [Listing 8.43 on page 346](#)

#### Listing 8.42 Example assembly source code using MLIST

---

```
                XDEF    entry
                MLIST  ON
swap:          MACRO
                LDA    \1
                LDX    \2
                STA    \2
                STX    \1
                ENDM
codSec:       SECTION
entry:
                LDA    #$F0
                LDX    #$0F
main:
                STA    first
                STX    second
                swap  first, second
                NOP
```

## Assembler Directives

Detailed descriptions of all assembler directives

---

```
        BRA    main
datSec: SECTION
first:  DS.B  1
second: DS.B  1
```

---

### Listing 8.43 Assembler output listing of the example in [Listing 8.42 on page 345](#) with MLIST ON

---

```
 1  1                                XDEF  entry
 3  3                                swap: MACRO
 4  4                                LDA   \1
 5  5                                LDX   \2
 6  6                                STA   \2
 7  7                                STX   \1
 8  8                                ENDM
 9  9
10 10                                codSec: SECTION
11 11                                entry:
12 12 000000 A6F0                    LDA   #$F0
13 13 000002 AE0F                    LDX   #$0F
14 14                                main:
15 15 000004 C7 xxxx                    STA   first
16 16 000007 CF xxxx                    STX   second
17 17                                swap first, second
18 4m 00000A C6 xxxx  +                LDA   first
19 5m 00000D CE xxxx  +                LDX   second
20 6m 000010 C7 xxxx  +                STA   second
21 7m 000013 CF xxxx  +                STX   first
22 18 000016 9D                    NOP
23 19 000017 20EB                    BRA   main
24 20
25 21                                datSec: SECTION
26 22 000000                    first: DS.B  1
27 23 000001                    second: DS.B  1
```

---

For the same code, with MLIST OFF, the listing file is as shown in [Listing 8.44 on page 346](#).

### Listing 8.44 Assembler output listing of the example in [Listing 8.42 on page 345](#) with MLIST OFF

---

```
Abs. Rel. Loc   Obj. code Source line
-----
 1     1                                XDEF  entry
```

---

## Assembler Directives

Detailed descriptions of all assembler directives

---

```
3 3 swap: MACRO
4 4 LDA \1
5 5 LDX \2
6 6 STA \2
7 7 STX \1
8 8 ENDM
9 9 codSec: SECTION
10 10 entry:
11 11 000000 A6F0 LDA #$F0
12 12 000002 AE0F LDX #$0F
13 13 main:
14 14 000004 C7 xxxx STA first
15 15 000007 CF xxxx STX second
16 16 swap first, second
21 17 000016 9D NOP
22 18 000017 20EB BRA main
23 19 datSec: SECTION
24 20 000000 first: DS.B 1
25 21 000001 second: DS.B 1
```

---

The MLIST directive does not appear in the listing file. When a macro is called after a MLIST ON, it is expanded in the listing file. If the MLIST OFF is encountered before the macro call, the macro is not expanded in the listing file.

## Assembler Directives

Detailed descriptions of all assembler directives

---

# NOLIST - Disable Listing

## Syntax

```
NOLIST
```

## Synonym

```
NOL
```

## Description

Suppresses the printing of the following instructions in the assembly listing and debug file until a [LIST - Enable Listing on page 336](#) assembler directive is reached.

## Example

See [Listing 8.45 on page 348](#) for an example of using LIST and NOLIST.

### Listing 8.45 Examples of LIST and NOLIST

---

```
aaa:  NOP

      LIST
bbb:  NOP
      NOP

      NOLIST
ccc:  NOP
      NOP

      LIST
ddd:  NOP
      NOP
```

---

The listing above generates the listing file in [Listing 8.46 on page 349](#).

---

**Listing 8.46 Assembler output listing from the assembler source code in [Listing 8.45 on page 348](#)**

---

Assembler					
Abs.	Rel.	Loc	Obj. code	Source	line
-----		-----	-----	-----	-----
1	1	000000	9D	aaa:	NOP
2	2				
4	4	000001	9D	bbb:	NOP
5	5	000002	9D		NOP
6	6				
12	12	000005	9D	ddd:	NOP
13	13	000006	9D		NOP

---

**See Also**

[LIST - Enable Listing on page 336](#) assembler directive

## Assembler Directives

*Detailed descriptions of all assembler directives*

---

### **NOPAGE - Disable Paging**

#### **Syntax**

NOPAGE

#### **Synonym**

None

#### **Description**

Disables pagination in the listing file. Program lines are listed continuously, without headings or top or bottom margins.



## OFFSET - Create absolute symbols

### Syntax

OFFSET <expression>

### Synonym

None

### Description

The `OFFSET` directive declares an offset section and initializes the location counter to the value specified in <expression>. The <expression> must be absolute and may not contain references to external, undefined or forward defined labels.

### Example

[Listing 8.47 on page 351](#) shows how the `OFFSET` directive can be used to access an element of a structure.

#### Listing 8.47 Example assembly source code

---

```
6 6                                OFFSET 0
7 7 000000                        ID:    DS.B  1
8 8 000001                        COUNT: DS.W  1
9 9 000003                        VALUE: DS.L  1
10 10 0000 0007                   SIZE:  EQU  *
11 11
12 12                               DataSec: SECTION
13 13 000000                       Struct: DS.B  SIZE
14 14
15 15                               CodeSec: SECTION
16 16                               entry:
17 17 000003 CE xxxx               LDX   #Struct
18 18 000006 8600                   LDA   #0
19 19 000008 6A00                   STA   ID, X
20 20 00000A 6201                   INC   COUNT, X
21 21 00000C 42                     INCA
22 22 00000D 6A03                   STA   VALUE, X
```

---

## Assembler Directives

Detailed descriptions of all assembler directives

---

When a statement affecting the location counter other than EVEN, LONGEVEN, ALIGN, or DS is encountered after the OFFSET directive, the offset section is ended. The preceding section is activated again, and the location counter is restored to the next available location in this section ([Listing 8.48 on page 352](#)).

### Listing 8.48 Example where the location counter is changed

---

```
7 7                               ConstSec: SECTION
8 8 000000 11                     cst1:  DC.B  $11
9 9 000001 13                     cst2:  DC.B  $13
10 10
11 11                               OFFSET 0
12 12 000000                       ID:    DS.B  1
13 13 000001                       COUNT: DS.W  1
14 14 000003                       VALUE: DS.L  1
15 15           0000 0007           SIZE:  EQU  *
16 16
17 17 000002 22                     cst3:  DC.B  $22
```

---

In the example above, the 'cst3' symbol, defined after the OFFSET directive, defines a constant byte value. This symbol is appended to the section 'ConstSec', which precedes the OFFSET directive.

## ORG - Set Location Counter

### Syntax

ORG <expression>

### Synonym

None

### Description

The ORG directive sets the location counter to the value specified by <expression>. Subsequent statements are assigned memory locations starting with the new location counter value. The <expression> must be absolute and may not contain any forward, undefined, or external references. The ORG directive generates an internal section, which is absolute (see the [Sections](#) chapter).

### Example

See [Listing 8.49 on page 353](#) for an example where ORG sets the location counter.

#### Listing 8.49 Using ORG to set the location counter

---

```
      org    $2000
b1:   nop
b2:   rts
```

---

Viewing [Listing 8.50 on page 353](#), you can see that the b1 label is located at address \$2000 and label b2 is at address \$2001.

#### Listing 8.50 Assembler output listing from the source code in [Listing 8.49 on page 353](#)

---

Abs.	Rel.	Loc	Obj. code	Source line
----	----	-----	-----	-----
1	1			org \$2000
2	2	a002000	9D	b1: nop
3	3	a002001	81	b2: rts

---

## Assembler Directives

*Detailed descriptions of all assembler directives*

---

### See also

**Assembler directives:**

- [DC - Define Constant on page 311](#)
- [DCB - Define Constant Block on page 313](#)
- [DS - Define Space on page 314](#)
- [SECTION - Declare Relocatable Section on page 361](#)

## PAGE - Insert Page break

### Syntax

PAGE

### Synonym

None

### Description

Insert a page break in the assembly listing.

### Example

The portion of code in [Listing 8.51 on page 355](#) demonstrates the use of a page break in the assembler output listing.

#### Listing 8.51 Example assembly source code

---

```
code: SECTION
      DC.B $00,$12
      DC.B $00,$34
      PAGE
      DC.B $00,$56
      DC.B $00,$78
```

---

The effect of the PAGE directive can be seen in [Listing 8.52 on page 355](#).

#### Listing 8.52 Assembler output listing from the source code in [Listing 8.51 on page 355](#)

---

Abs.	Rel.	Loc	Obj. code	Source line
----	----	-----	-----	-----
1	1			code: SECTION
2	2	000000	0012	DC.B \$00,\$12
3	3	000002	0034	DC.B \$00,\$34
5	5	000004	0056	DC.B \$00,\$56

---

## Assembler Directives

*Detailed descriptions of all assembler directives*

---

6	6	000006 0078	DC.B	\$00,\$78
---	---	-------------	------	-----------

---

## **PLEN - Set Page Length**

### **Syntax**

PLEN<n>

### **Synonym**

None

### **Description**

Sets the listings page length to <n> lines. <n> may range from 10 to 10000. If the number of lines already listed on the current page is greater than or equal to <n>, listing will continue on the next page with the new page length setting.

The default page length is 65 lines.

## Assembler Directives

Detailed descriptions of all assembler directives

---

### RAD50 - Rad50-encoded string constants

#### Syntax

```
RAD50 <str>[, cnt]
```

#### Synonym

None

#### Description

This directive places strings encoded with the RAD50 encoding into constants. The RAD50 encoding places 3 string characters out of a reduced character set into 2 bytes. It therefore saves memory when comparing it with a plain ASCII representation. It also has some drawbacks, however. Only 40 different character values are supported, and the strings have to be decoded before they can be used. This decoding does include some computations including divisions (not just shifts) and is therefore rather expensive.

The encoding takes three bytes and looks them up in a string table ([Listing 8.53 on page 358](#)).

#### Listing 8.53 RAD50 encoding

---

```
unsigned short LookUpPos(char x) {
    static const char translate[]=
        " ABCDEFGHIJKLMNOPQRSTUVWXYZ$.?0123456789";

    const char* pos= strchr(translate, x);
    if (pos == NULL) { EncodingError(); return 0; }
    return pos-translate;
}
unsigned short Encode(char a, char b, char c) {
    return LookUpPos(a)*40*40 + LookUpPos(b)*40
        + LookUpPos(c);
}
```

---

If the remaining string is shorter than 3 bytes, it is filled with spaces (which correspond to the RAD50 character 0).

The optional argument `cnt` can be used to explicitly state how many 16-bit values should be written. If the string is shorter than  $3 * cnt$ , then it is filled with spaces.



See the example C code below ([Listing 8.56 on page 359](#)) about how to decode it.

## Example

The string data in [Listing 8.54 on page 359](#) assembles to the following data ([Listing 8.55 on page 359](#)). The 11 characters in the string are represented by 8 bytes.

### Listing 8.54 RAD50 Example

---

```
XDEF rad50, rad50Len
DataSection SECTION
rad50:      RAD50 "Hello World"
rad50Len:  EQU (*-rad50)/2
```

---

### Listing 8.55 Assembler output where 11 characters are contained in eight bytes

---

```
$32D4 $4D58 $922A $4BA0
```

---

This C code shown in [Listing 8.56 on page 359](#) takes the data and prints “Hello World”.

### Listing 8.56 Example—Program that Prints Hello World

---

```
#include "stdio.h"
extern unsigned short rad50[];
extern int rad50Len; /* address is value. Exported asm label */
#define rad50len ((int) &rad50Len)

void printRadChar(char ch) {
    static const char translate[]=
        " ABCDEFGHIJKLMNOPQRSTUVWXYZ$.?0123456789";
    char asciiChar= translate[ch];
    (void) putchar(asciiChar);
}

void PrintHallo(void) {
    unsigned char values= rad50len;
    unsigned char i;
    for (i=0; i < values; i++) {
        unsigned short val= rad50[i];
        printRadChar(val / (40 * 40));
        printRadChar((val / 40) % 40);
        printRadChar(val % 40);
    }
}
```

---

## **Assembler Directives**

*Detailed descriptions of all assembler directives*

---

}

---

## SECTION - Declare Relocatable Section

### Syntax

<name>: SECTION [SHORT] [RS08\_SHORT] [RS08\_TINY] [<number>]

### Synonym

None

### Description

This directive declares a relocatable section and initializes the location counter for the following code. The first SECTION directive for a section sets the location counter to zero. Subsequent SECTION directives for that section restore the location counter to the value that follows the address of the last code in the section.

<name> is the name assigned to the section. Two SECTION directives with the same name specified refer to the same section.

<number> is optional and is only specified for compatibility with the MASM Assembler.

A section is a code section when it contains at least one assembly instruction. It is considered to be a constant section if it contains only DC or DCB directives. A section is considered to be a data section when it contains at least a DS directive or if it is empty.

### Example

The example in [Listing 8.57 on page 361](#) demonstrates the definition of a section aaa, which is split into two blocks, with section bbb in between them.

The location counter associated with the label zz is 1, because a NOP instruction was already defined in this section at label xx.

#### Listing 8.57 Example of the SECTION assembler directive

---

Abs.	Rel.	Loc	Obj. code	Source line
----	----	-----	-----	-----
1	1			aaa: SECTION 4
2	2	000000	9D	xx: NOP
3	3			bbb: SECTION 5
4	4	000000	9D	yy: NOP
5	5	000001	9D	NOP
6	6	000002	9D	NOP

---

## Assembler Directives

Detailed descriptions of all assembler directives

---

```
7 7          aaa: SECTION 4
8 8 000001 9D  zz:  NOP
```

---

The optional qualifier `SHORT` specifies that the section is a short section, That means than the objects defined there can be accessed using the direct addressing mode.

For `RS08`, there are two additional section qualifiers: `RS08_SHORT` and `RS08_TINY`. When a section is declared as `RS08_SHORT` (or `RS08_TINY`) all the objects defined there can be accessed using the short (and respectively tiny) addressing modes.

### Example

The following example demonstrates the definition and usage of a `SHORT` section. In the example shown in [Listing 8.58 on page 362](#), the symbol data is accessed using the direct addressing mode.

#### Listing 8.58 Using the direct addressing mode

---

```
1 1          dataSec: SECTION SHORT
2 2 000000  data:  DS.B 1
3 3
4 4          codeSec: SECTION
5 5
6 6          entry:
7 7 000000 9C          RSP
8 8 000001 A600        LDA #0
9 9 000003 B7xx        STA data
```

---

### See also

#### Assembler directives:

- [ORG - Set Location Counter on page 353](#)
- [DC - Define Constant on page 311](#)
- [DCB - Define Constant Block on page 313](#)
- [DS - Define Space on page 314](#)

## SET - Set Symbol Value

### Syntax

<label>: SET <expression>

### Synonym

None

### Description

Similar to the [EQU - Equate symbol value on page 322](#) directive, the SET directive assigns the value of the <expression> in the operand field to the symbol in the <label> field. The <expression> must resolve as an absolute expression and cannot include a symbol that is undefined or not yet defined. The <label> is an assembly time constant. SET does not generate any machine code.

The value is temporary; a subsequent SET directive can redefine it.

### Example

See [Listing 8.59 on page 363](#) for examples of the SET directive.

#### Listing 8.59 Using the SET assembler directive

---

Abs.	Rel.	Loc	Obj. code	Source line
----	----	-----	-----	-----
1	1		0000 0002	count: SET 2
2	2	000000	02	one: DC.B count
3	3			
4	4		0000 0001	count: SET count-1
5	5	000001	01	DC.B count
6	6			
7	7		0000 0001	IFNE count
8	8		0000 0000	count: SET count-1
9	9			ENDIF
10	10	000002	00	DC.B count

---

The value associated with the label count is decremented after each DC.B instruction.

## Assembler Directives

*Detailed descriptions of all assembler directives*

---

### SPC - Insert Blank Lines

#### Syntax

`SPC<count>`

#### Synonym

None

#### Description

Inserts `<count>` blank lines in the assembly listing. `<count>` may range from 0 to 65. This has the same effect as writing that number of blank lines in the assembly source. A blank line is a line containing only a carriage return.

## TABS - Set Tab Length

### Syntax

TABS <n>

### Synonym

None

### Description

Sets the tab length to <n> spaces. The default tab length is eight. <n> may range from 0 to 128.

## Assembler Directives

*Detailed descriptions of all assembler directives*

---

### TITLE - Provide Listing Title

#### Syntax

```
TITLE "title"
```

#### Synonym

```
TTL
```

#### Description

Print the <title> on the head of every page of the listing file. This directive must be the first source code line. A title consists of a string of characters enclosed in quotes (").

The title specified will be written on the top of each page in the assembly listing file.



## XDEF - External Symbol Definition

### Syntax

```
XDEF [.<size>] <label>[,<label>]...  
where <size> = B(direct), W (default), or L or S or T
```

### Synonym

```
GLOBAL, PUBLIC
```

### Description

This directive specifies labels defined in the current module that are to be passed to the linker as labels that can be referenced by other modules linked to the current module.

The number of symbols enumerated in an XDEF directive is only limited by the memory available at assembly time.

The S and T size designators are only available for RS08, and result in marking the symbol as short or tiny.

### Example

See [Listing 8.60 on page 367](#) for the case where the XDEF assembler directive can specify symbols that can be used by other modules.

#### Listing 8.60 Using XDEF to create a variable to be used in another file

---

```
XDEF Count, main  
;; variable Count can be referenced in other modules,  
;; same for label main. Note that Linker & Assembler  
;; are case-sensitive, i.e., Count != count.  
  
Count: DS.W 2  
  
code: SECTION  
main: DC.B 1
```

---

## Assembler Directives

*Detailed descriptions of all assembler directives*

---

### XREF - External Symbol Reference

#### Syntax

```
XREF [.<size>] <symbol>[,<symbol>]...
```

where <size> = B (direct), W (default), or L.

#### Synonym

```
EXTERNAL
```

#### Description

This directive specifies symbols referenced in the current module but defined in another module. The list of symbols and corresponding 32-bit values is passed to the linker.

The number of symbols enumerated in an XREF directive is only limited by the memory available at assembly time.

The S and T size designators are only available for RS08, and result in marking the symbol as short or tiny.

#### Example

```
XREF OtherGlobal ; Reference "OtherGlobal" defined in  
                ; another module. (See the XDEF  
                ; directive example.)
```

## **XREFB - External Reference for Symbols located on the Direct Page**

### **Syntax**

```
XREFB <symbol> [, <symbol>] ...
```

### **Synonym**

None

### **Description**

This directive specifies symbols referenced in the current module but defined in another module. Symbols enumerated in a XREFB directive, can be accessed using the direct address mode. The list of symbols and corresponding 8-bit values is passed to the linker.

The number of symbols enumerated in a XREFB directive is only limited by the memory available at assembly time.

### **Example**

---

```
XREFB OtherDirect ; Reference "OtherDirect" def in another  
                ; module (See XDEF directive example.)
```

---

## **Assembler Directives**

*Detailed descriptions of all assembler directives*

---

# Macros

---

A macro is a template for a code sequence. Once a macro is defined, subsequent reference to the macro name are replaced by its code sequence.

## Macro overview

A macro must be defined before it is called. When a macro is defined, it is given a name. This name becomes the mnemonic by which the macro is subsequently called.

The Assembler expands the macro definition each time the macro is called. The macro call causes source statements to be generated, which may include macro arguments. A macro definition may contain any code or directive except nested macro definitions. Calling previously defined macros is also allowed. Source statements generated by a macro call are inserted in the source file at the position where the macro is invoked.

To call a macro, write the macro name in the operation field of a source statement. Place the arguments in the operand field. The macro may contain conditional assembly directives that cause the Assembler to produce in-line-coding variations of the macro definition.

Macros call produces in-line code to perform a predefined function. Each time the macro is called, code is inserted in the normal flow of the program so that the generated instructions are executed in line with the rest of the program.

## Defining a macro

The definition of a macro consists of four parts:

- The header statement, a `MACRO` directive with a label that names the macro.
- The body of the macro, a sequential list of assembler statements, some possibly including argument placeholders.
- The `ENDM` directive, terminating the macro definition.
- eventually an instruction `MEXIT`, which stops macro expansion.

See the [Assembler Directives](#) chapter for information about the `MACRO`, `ENDM`, `MEXIT`, and `MLIST` directives.

The body of a macro is a sequence of assembler source statements. Macro parameters are defined by the appearance of parameter designators within these source statements. Valid

## Macros

### Calling macros

---

macro definition statements includes the set of processor assembly language instructions, assembler directives, and calls to previously defined macros. However, macro definitions may not be nested.

## Calling macros

The form of a macro call is:

```
[<label>:] <name>[.<sizearg>] [<argument> [, <argument>] . . .]
```

Although a macro may be referenced by another macro prior to its definition in the source module, a macro must be defined before its first call. The name of the called macro must appear in the operation field of the source statement. Arguments are supplied in the operand field of the source statement, separated by commas.

The macro call produces in-line code at the location of the call, according to the macro definition and the arguments specified in the macro call. The source statements of the expanded macro are then assembled subject to the same conditions and restrictions affecting any source statement. Nested macros calls are also expanded at this time.

## Macro parameters

As many as 36 different substitutable parameters can be used in the source statements that constitute the body of a macro. These parameters are replaced by the corresponding arguments in a subsequent call to that macro.

A parameter designator consists of a backslashes character (\), followed by a digit (0 - 9) or an uppercase letter (A - Z). Parameter designator \0 corresponds to a size argument that follows the macro name, separated by a period (.).

Consider the macro definition in [Listing 9.1 on page 372](#):

### Listing 9.1 Example macro definition

---

```
MyMacro: MACRO  
        DC.\0    \1, \2  
        ENDM
```

---

When this macro is used in a program, e.g.:

```
MyMacro.B $10, $56
```

the Assembler expands it to:

DC.B \$10, \$56

Arguments in the operand field of the macro call refer to parameter designator \1 through \9 and \A through \Z, in that order. The argument list (operand field) of a macro call cannot be extended onto additional lines.

At the time of a macro call, arguments from the macro call are substituted for parameter designators in the body of the macro as literal (string) substitutions. The string corresponding to a given argument is substituted literally wherever that parameter designator occurs in a source statement as the macro is expanded. Each statement generated in the execution is assembled in line.

It is possible to specify a null argument in a macro call by a comma with no character (not even a space) between the comma and the preceding macro name or comma that follows an argument. When a null argument itself is passed as an argument in a nested macro call, a null value is passed. All arguments have a default value of null at the time of a macro call.

## Macro argument grouping

To pass text including commas as a single macro argument, the Assembler supports a special syntax. This grouping starts with the [? prefix and ends with the ?] suffix. If the [? or ?] patterns occur inside of the argument text, they have to be in pairs. Alternatively, brackets, question marks and backward slashes can also be escaped with a backward slash as prefix.

---

**NOTE** This escaping only takes place inside of [? ?] arguments. A backslash is only removed in this process if it is just before a bracket ( [ ] ), a question mark ( ? ) , or a second backslash ( \ ).

---

### Listing 9.2 Example macro definition

---

```
MyMacro:  MACRO
           DC      \1
           ENDM
MyMacro1: MACRO
           \1
           ENDM
```

---

[Listing 9.3 on page 374](#) has some macro calls with rather complicated arguments:

## Macros

### Macro parameters

---

#### Listing 9.3 Macro calls for [Listing 9.2 on page 373](#)

---

```
MyMacro [? $10, $56?]  
MyMacro ["\ [?"?]  
MyMacro1 [?MyMacro [? $10, $56?]?]  
MyMacro1 [?MyMacro \ [? $10, $56\?]?]
```

---

These macro calls expand to the following lines ([Listing 9.4 on page 374](#)):

#### Listing 9.4 Macro expansion of [Listing 9.3 on page 374](#)

---

```
DC    $10, $56  
DC    " [?"  
DC    $10, $56  
DC    $10, $56
```

---

The Macro Assembler does also supports for compatibility with previous version's macro grouping with an angle bracket syntax ([Listing 9.5 on page 374](#)):

#### Listing 9.5 Angle bracket syntax

---

```
MyMacro <$10, $56>
```

---

However, this old syntax is ambiguous as < and > are also used as compare operators. For example, the following code ([Listing 9.6 on page 374](#)) does not produce the expected result:

#### Listing 9.6 Potential problem using the angle-bracket syntax

---

```
MyMacro <1 > 2, 2 > 3 > ; Wrong!
```

---

Because of this the old angle brace syntax should be avoided in new code. There is also an option to disable it explicitly.

See also the [-CMacBrackets: Square brackets for macro arguments grouping](#) and the [-CMacAngBrack: Angle brackets for grouping Macro Arguments](#) assembler options.



## Labels inside macros

To avoid the problem of multiple-defined labels resulting from multiple calls to a macro that has labels in its source statements, the programmer can direct the Assembler to generate unique labels on each call to a macro.

Assembler-generated labels include a string of the form `_nnnnn` where `nnnnn` is a 5-digit value. The programmer requests an assembler-generated label by specifying `\@` in a label field within a macro body. Each successive label definition that specifies a `\@` directive generates a successive value of `_nnnnn`, thereby creating a unique label on each macro call. Note that `\@` may be preceded or followed by additional characters for clarity and to prevent ambiguity.

This is the definition of the `clear` macro ([Listing 9.7 on page 375](#)):

### Listing 9.7 Clear macro definition

---

```
clear:   MACRO
          LDX   #\1
          LDA   #16
\@LOOP:  CLR    0,X
          INCX
          DECA
          BNE   \@LOOP
        ENDM
```

---

This macro is called in the application ([Listing 9.8 on page 375](#)):

### Listing 9.8 Calling the clear macro

---

```
clear    temporary
clear    data
```

---

The two macro calls of `clear` are expanded in the following manner ([Listing 9.9 on page 375](#)):

### Listing 9.9 Macro call expansion

---

```
          clear temporary
          LDX   #temporary
          LDA   #16
_00001LOOP: CLR    0,X
          INCX
          DECA
```

---

## Macros

### Macro expansion

---

```
                BNE    _00001LOOP
clear data
                LDX    #data
                LDA    #16
_00002LOOP:    CLR    0,X
                INCX
                DECA
                BNE    _00002LOOP
```

---

## Macro expansion

When the Assembler reads a statement in a source program calling a previously defined macro, it processes the call as described in the following paragraphs.

The symbol table is searched for the macro name. If it is not in the symbol table, an undefined symbol error message is issued.

The rest of the line is scanned for arguments. Any argument in the macro call is saved as a literal or null value in one of the 35 possible parameter fields. When the number of arguments in the call is less than the number of parameters used in the macro the argument, which have not been defined at invocation time are initialize with "" (empty string).

Starting with the line following the `MACRO` directive, each line of the macro body is saved and is associated with the named macro. Each line is retrieved in turn, with parameter designators replaced by argument strings or assembler-generated label strings.

Once the macro is expanded, the source lines are evaluated and object code is produced.

## Nested macros

Macro expansion is performed at invocation time, which is also the case for nested macros. If the macro definition contains nested macro call, the nested macro expansion takes place in line. Recursive macro call are also supported.

A macro call is limited to the length of one line, i.e., 1024 characters.

# Assembler Listing File

---

The assembly listing file is the output file of the Assembler that contains information about the generated code. The listing file is generated when the `-L` assembler option is activated. When an error is detected during assembling from the file, no listing file is generated.

The amount of information available depends upon the following assembler options:

- [-L: Generate a listing file](#)
- [-Lc: No Macro call in listing file](#)
- [-Ld: No macro definition in listing file](#)
- [-Le: No Macro expansion in listing file](#)
- [-Li: No included file in listing file](#)

The information in the listing file also depends on following assembler directives:

- [LIST - Enable Listing](#)
- [NOLIST - Disable Listing](#)
- [CLIST - List conditional assembly](#)
- [MLIST - List macro expansions](#)

The format from the listing file is influenced by the following assembler directives:

- [PLEN - Set Page Length](#)
- [LLEN - Set Line Length](#)
- [TABS - Set Tab Length](#)
- [SPC - Insert Blank Lines](#)
- [PAGE - Insert Page break](#)
- [NOPAGE - Disable Paging](#)
- [TITLE - Provide Listing Title.](#)

The name of the generated listing file is `<base name>.lst`.

## Page header

The page header consists of three lines:

## Assembler Listing File

### Source listing

---

- The first line contains an optional user string defined in the `TITLE` directive.  
The second line contains the name of the Assembler vendor (Freescale) as well as the target processor name - HC(S)08.
- The third line contains a copyright notice.

### Listing 10.1 Example page header output

---

```
Demo Application
Freescale HC08-Assembler
(c) COPYRIGHT Freescale 1991-2005
```

---

## Source listing

The printed columns can be configured in various formats with the [-Lasmc: Configure listing file](#) assembler option. The default format of the source listing has the five columns as in [on page 378](#):

### Abs.

This column contains the absolute line number for each instruction. The absolute line number is the line number in the debug listing file, which contains all included files and where any macro calls have been expanded.

### Listing 10.2 Example output listing - Abs. column

---

Abs.	Rel.	Loc	Obj. code	Source line
----	----	-----	-----	-----
1	1			;-----
2	2			; File: test.o
3	3			;-----
4	4			
5	5			XDEF Start
6	6			MyData: SECTION
7	7	000000		char1: DS.B 1
8	8	000001		char2: DS.B 1
9	9			INCLUDE "macro.inc"
10	1i			cpChar: MACRO
11	2i			LDA \1
12	3i			STA \2
13	4i			ENDM
14	10			CodeSec: SECTION

---

```

15  11                               Start:
16  12                               cpChar char1, char2
17  2m  000000 C6 xxxx  +          LDA char1
18  3m  000003 C7 xxxx  +          STA char2
19  13  000006 9D              NOP
20  14  000007 9D              NOP

```

## Rel.

This column contains the relative line number for each instruction. The relative line number is the line number in the source file. For included files, the relative line number is the line number in the included file. For macro call expansion, the relative line number is the line number of the instruction in the macro definition. See [Listing 10.3 on page 379](#).

An 'i' suffix is appended to the relative line number when the line comes from an included file. An 'm' suffix is appended to the relative line number when the line is generated by a macro call.

### Listing 10.3 Example listing file - Rel. column

Abs.	Rel.	Loc	Obj. code	Source line
-----				
1	1			-----
2	2			; File: test.o
3	3			-----
4	4			
5	5			XDEF Start
6	6			MyData: SECTION
7	7	000000		char1: DS.B 1
8	8	000001		char2: DS.B 1
9	9			INCLUDE "macro.inc"
10	1i			cpChar: MACRO
11	2i			LDA \1
12	3i			STA \2
13	4i			ENDM
14	10			CodeSec: SECTION
15	11			Start:
16	12			cpChar char1, char2
17	2m	000000 C6 xxxx	+	LDA char1
18	3m	000003 C7 xxxx	+	STA char2
19	13	000006 9D		NOP
20	14	000007 9D		NOP

## Assembler Listing File

### Source listing

---

In the previous example, the line number displayed in the 'Rel.' column. represent the line number of the corresponding instruction in the source file.

'1i' on absolute line number 10 denotes that the instruction 'cpChar: MACRO' is located in an included file.

'2m' on absolute line number 17 denotes that the instruction 'LDA char1' is generated by a macro expansion.

## Loc

This column contains the address of the instruction. For absolute sections, the address is preceded by an 'a' and contains the absolute address of the instruction. For relocatable sections, this address is the offset of the instruction from the beginning of the relocatable section.. This offset is a hexadecimal number coded on 6 digits.

A value is written in this column in front of each instruction generating code or allocating storage. This column is empty in front of each instruction that does not generate code (for example SECTION, XDEF, ...). See [Listing 10.4 on page 380](#).

### Listing 10.4 Example Listing File - Loc column

---

Abs.	Rel.	Loc	Obj. code	Source line
----	----	-----	-----	-----
1	1			;-----
2	2			; File: test.o
3	3			;-----
4	4			
5	5			XDEF Start
6	6			MyData: SECTION
7	7	000000		char1: DS.B 1
8	8	000001		char2: DS.B 1
9	9			INCLUDE "macro.inc"
10	1i			cpChar: MACRO
11	2i			LDA \1
12	3i			STA \2
13	4i			ENDM
14	10			CodeSec: SECTION
15	11			Start:
16	12			cpChar char1, char2
17	2m	000000	C6 xxxx	+ LDA char1
18	3m	000003	C7 xxxx	+ STA char2
19	13	000006	9D	NOP
20	14	000007	9D	NOP

---

In the previous example, the hexadecimal number displayed in the column 'Loc.' is the offset of each instruction in the section 'codeSec'.

There is no location counter specified in front of the instruction 'INCLUDE "macro.inc"' because this instruction does not generate code.

The instruction 'LDA char1' is located at offset 0 from the section 'codeSec' start address.

The instruction 'STA char2' is located at offset 3 from the section 'codeSec' start address.

## Obj. code

This column contains the hexadecimal code of each instruction in hexadecimal format. This code is not identical to the code stored in the object file. The letter 'x' is displayed at the position where the address of an external or relocatable label is expected. Code at any position when 'x' is written will be determined at link time. See [Listing 10.5 on page 381](#).

**Listing 10.5 Example listing file - Obj. code column**

Abs.	Rel.	Loc	Obj. code	Source line
----	----	-----	-----	-----
1	1			;-----
2	2			; File: test.o
3	3			;-----
4	4			
5	5			XDEF Start
6	6			MyData: SECTION
7	7	000000		char1: DS.B 1
8	8	000001		char2: DS.B 1
9	9			INCLUDE "macro.inc"
10	1i			cpChar: MACRO
11	2i			LDA \1
12	3i			STA \2
13	4i			ENDM
14	10			CodeSec: SECTION
15	11			Start:
16	12			cpChar char1, char2
17	2m	000000	C6 xxxx	+ LDA char1
18	3m	000003	C7 xxxx	+ STA char2
19	13	000006	9D	NOP
20	14	000007	9D	NOP

## Assembler Listing File

Source listing

---

### Source line

This column contains the source statement. This is a copy of the source line from the source module. For lines resulting from a macro expansion, the source line is the expanded line, where parameter substitution has been done. See [Listing 10.6 on page 382](#).

#### Listing 10.6 Example listing file - Source line column

---

Abs.	Rel.	Loc	Obj. code	Source line
----	----	-----	-----	-----
1	1			;-----
2	2			; File: test.o
3	3			;-----
4	4			
5	5			XDEF Start
6	6			MyData: SECTION
7	7	000000		char1: DS.B 1
8	8	000001		char2: DS.B 1
9	9			INCLUDE "macro.inc"
10	1i			cpChar: MACRO
11	2i			LDA \1
12	3i			STA \2
13	4i			ENDM
14	10			CodeSec: SECTION
15	11			Start:
16	12			cpChar char1, char2
17	2m	000000	C6 xxxx	+ LDA char1
18	3m	000003	C7 xxxx	+ STA char2
19	13	000006	9D	NOP
20	14	000007	9D	NOP

---



# Mixed C and Assembler Applications

---

When you intend to mix Assembly source file and ANSI-C source files in a single application, the following issues are important:

- [“Memory models” on page 383](#)
- [“Parameter passing scheme” on page 384](#)
- [“Return Value” on page 384](#)
- [“Accessing assembly variables in an ANSI-C source file” on page 384](#)
- [“Accessing ANSI-C variables in an assembly source file” on page 385](#)
- [“Invoking an assembly function in an ANSI-C source file” on page 386](#)
- [“Support for structured types” on page 389](#)

To build mixed C and Assembler applications, you have to know how the C Compiler uses registers and calls procedures. The following sections will describe this for compatibility with the compiler. If you are working with another vendor’s ANSI-C compiler, refer to your Compiler Manual to get the information about parameter passing rules.

## Memory models

The memory models are only important if you mix C and assembly code. In this case all sources must be compiled or assembled with the same memory model.

The Assembler supports all memory models of the compiler. Depending on your hardware, use the smallest memory model suitable for your programming needs.

[Table 11.1 on page 384](#) summarizes the different memory models. It shows when to use a particular memory model and which assembler switch to use.

**Table 11.1** HC08 memory models

Option	Memory Model	Local Data	Global Data	Suggested Use
-Ms	SMALL	SP rel	extended	The SMALL memory model is the default. All pointers and functions are assumed to have 16-bit addresses if not explicitly specified. In the SMALL memory model, code and data must be in the 64k address space.
-Mt	TINY	SP rel	direct	In the TINY memory model, all data including stack must fit into the zero page. Data pointers are assumed to have 8-bit addresses if not explicitly specified with the keyword <code>__far</code> . The code address space is still 64k and function pointers are still 16 bits in length.

---

**NOTE** The default pointer size for the compiler is also affected by the memory model chosen.

---

## Parameter passing scheme

Please check the compiler manual, back-end chapter about the details of parameter passing.

## Return Value

Please check the compiler manual's backend chapter about the details of parameter passing.

## Accessing assembly variables in an ANSI-C source file

A variable or constant defined in an assembly source file is accessible in an ANSI-C source file.

The variable or constant is defined in the assembly source file using the standard assembly syntax.

Variables and constants must be exported using the XDEF directive to make them visible from other modules ([Listing 11.1 on page 385](#)).

#### **Listing 11.1 Example of data and constant definition**

---

```
XDEF  ASMData, ASMConst
DataSec: SECTION
ASMData: DS.W 1          ; Definition of a variable
ConstSec: SECTION
ASMConst: DC.W $44A6    ; Definition of a constant
```

---

We recommend that you generate a header file for each assembler source file. This header file should contain the interface to the assembly module.

An external declaration for the variable or constant must be inserted in the header file ([Listing 11.2 on page 385](#)).

#### **Listing 11.2 Example of data and constant declarations**

---

```
/* External declaration of a variable */
extern int      ASMData;
/* External declaration of a constant */
extern const int ASMConst;
```

---

The variables or constants can then be accessed in the usual way, using their names ([Listing 11.3 on page 385](#)).

#### **Listing 11.3 Example of data and constant reference**

---

```
ASMData = ASMConst + 3;
```

---

## **Accessing ANSI-C variables in an assembly source file**

A variable or constant defined in an ANSI-C source file is accessible in an assembly source file.

## Mixed C and Assembler Applications

Invoking an assembly function in an ANSI-C source file

---

The variable or constant is defined in the ANSI-C source file using the standard ANSI-C syntax ([Listing 11.4 on page 386](#)).

### Listing 11.4 Example definition of data and constants

---

```
unsigned int CData;          /* Definition of a variable */
unsigned const int CConst; /* Definition of a constant */
```

---

An external declaration for the variable or constant must be inserted into the assembly source file ([Listing 11.5 on page 386](#)).

This can also be done in a separate file, included in the assembly source file.

### Listing 11.5 Example declaration of data and constants

---

```
XREF CData; External declaration of a variable
XREF CConst; External declaration of a constant
```

---

The variables or constants can then be accessed in the usual way, using their names ([Listing 11.6 on page 386](#)).

---

**NOTE** The compiler supports also the automatic generation of assembler include files. See the description of the `-La` compiler option in the compiler manual.

---

### Listing 11.6 Example of data and constant reference

---

```
LDA CConst
...
LDA CData
...
```

---

## Invoking an assembly function in an ANSI-C source file

An function implemented in an assembly source file (`mixasm.asm` in [Listing 11.7 on page 387](#)) can be invoked in a C source file ([Listing 11.9 on page 388](#)). During the implementation of the function in the assembly source file, you should pay attention to the parameter passing scheme of the ANSI-C compiler you are using in order to retrieve the parameter from the right place.

---

**Listing 11.7 Example of an assembly file: mixasm.asm**

---

```
XREF CData
XDEF AddVar
XDEF ASMData

DataSec: SECTION
ASMData: DS.B 1
CodeSec: SECTION
AddVar:
    ADD CData    ; add CData to the parameter in register A
    STA ASMData ; result of the addition in ASMData
    RTS
```

---

We recommend that you generate a header file for each assembly source file ([Listing 11.7 on page 387](#)). This header file (mixasm.h in [Listing 11.8 on page 387](#)) should contain the interface to the assembly module.

**Listing 11.8 Header file for the assembly mixasm.asm file: mixasm.h**

---

```
/* mixasm.h */
#ifndef _MIXASM_H_
#define _MIXASM_H_

void AddVar(unsigned char value);
/* function that adds the parameter value to global CData */
/* and then stores the result in ASMData */

/* variable which receives the result of AddVar */
extern char ASMData;

#endif /* _MIXASM_H_ */
```

---

The function can then be invoked in the usual way, using its name.

## Example of a C file

A C source code file (mixc.c) has the main() function which calls the AddVar() function. See [Listing 11.9 on page 388](#). (Compile it with the -Cc compiler option when using the HIWARE Object File Format).

## Mixed C and Assembler Applications

Invoking an assembly function in an ANSI-C source file

---

### Listing 11.9 Example C source code file: mixc.c

---

```
static int Error          = 0;
const unsigned char CData = 12;
#include "mixasm.h"

void main(void) {
    AddVar(10);
    if (ASMDData != CData + 10){
        Error = 1;
    } else {
        Error = 0;
    }
    for(;;); // wait forever
}
```

---

**CAUTION** Be careful, as the Assembler will not make any checks on the number and type of the function parameters.

---

The application must be correctly linked.

For these C and \*.asm files, a possible linker parameter file is shown in [Listing 11.10 on page 388](#).

### Listing 11.10 Example of linker parameter file: mixasm.prm

---

```
LINK mixasm.abs
NAMES
    mixc.o mixasm.o
END
SECTIONS
    MY_ROM    = READ_ONLY    0x4000 TO 0x4FFF;
    MY_RAM    = READ_WRITE   0x2400 TO 0x2FFF;
    MY_STACK  = READ_WRITE   0x2000 TO 0x23FF;
END
PLACEMENT
    DEFAULT_RAM    INTO MY_RAM;
    DEFAULT_ROM    INTO MY_ROM;
    SSTACK         INTO MY_STACK;
END
INIT main
```

---

**NOTE** We recommend that you use the same memory model and object file format for all the generated object files.

---

## Support for structured types

When the [-Struct: Support for structured types](#) assembler option is activated, the Macro Assembler also supports the definition and usage of structured types. This allows an easier way to access ANSI-C structured variable in the Macro Assembler.

In order to provide an efficient support for structured type the macro assembler should provide notation to:

- Define a structured type. See [“Structured type definition” on page 389](#).
- Define a structured variable. See [“Variable definition” on page 391](#).
- Declare a structured variable. See [“Variable declaration” on page 391](#).
- Access the address of a field inside of a structured variable. See [“Accessing a field address” on page 392](#)
- Access the offset of a field inside of a structured variable. See [“Accessing a field offset” on page 393](#).

**NOTE** Some limitations apply in the usage of the structured types in the Macro Assembler. See [Structured type: Limitations on page 393](#).

---

## Structured type definition

The Macro Assembler is extended with the following new keywords in order to support ANSI-C type definitions.

- STRUCT
- UNION

The structured type definition for STRUCT can be encoded as in [Listing 11.11 on page 389](#):

### Listing 11.11 Definition for STRUCT

---

```
typeName: STRUCT
  lab1: DS.W 1   lab2: DS.W 1   ...
ENDSTRUCT
```

---

where:

---

## Mixed C and Assembler Applications

### Support for structured types

---

'typeName' is the name associated with the defined type. The type name is considered to be a user-defined keyword. The Macro Assembler will be case-insensitive on typeName.

'STRUCT' specifies that the type is a structured type.

'lab1' and 'lab2' are the fields defined inside of the 'typeName' type. The fields will be considered as user-defined labels, and the Macro Assembler will be case-sensitive on label names.

As with all other directives in the Assembler, the STRUCT and UNION directives are case-insensitive.

The STRUCT and UNION directives cannot start on column 1 and must be preceded by a label.

## Types allowed for structured type fields

The field inside of a structured type may be:

- another structured type or
- a base type, which can be mapped on 1, 2, or 4 bytes.

[Table 11.2 on page 390](#) shows how the ANSI-C standard types are converted in the assembler notation:

**Table 11.2 Converting ANSI-C standard types to assembler notation**

ANSI-C type	Assembler Notation
char	<a href="#">DS - Define Space</a>
short	DS.W
int	DS.W
long	DS.L
enum	DS.W
bitfield	-- not supported --
float	-- not supported --
double	-- not supported --
data pointer	DS.W
function pointer	-- not supported --



## Variable definition

The Macro Assembler can provide a way to define a variable with a specific type. This is done using the following syntax ([Listing 11.12 on page 391](#)):

```
var: typeName
```

where:

- 'var' is the name of the variable.
- 'typeName' is the type associated with the variable.

### Listing 11.12 Assembly code analog of a C struct of type: myType

---

```
myType:    STRUCT
field1:    DS.W 1
field2:    DS.W 1
field3:    DS.B 1
field4:    DS.B 3
field5:    DS.W 1
           ENDSTRUCT
```

```
DataSection: SECTION
```

```
structVar: TYPE myType ; var 'structVar' is of type 'myType'
```

---

## Variable declaration

The Macro Assembler can provide a way to associated a type with a symbol which is defined externally. This is done by extending the XREF syntax:

```
XREF var: typeName, var2
```

where:

- 'var' is the name of an externally defined symbol.
- 'typeName' is the type associated with the variable 'var'.

'var2' is the name of another externally defined symbol. This symbol is not associated with any type. See [Listing 11.13 on page 391](#) for an example.

### Listing 11.13 Example of extending XREF

---

```
myType: STRUCT
field1:  DS.W 1
field2:  DS.W 1
field3:  DS.B 1
field4:  DS.B 3
field5:  DS.W 1
```

---

```
ENDSTRUCT  
  
XREF extData: myType ; var 'extData' is type 'myType'
```

---

## Accessing a structured variable

The Macro Assembler can provide a means to access each structured type field absolute address and offset.

## Accessing a field address

To access a structured-type field address ([Listing 11.14 on page 392](#)), the Assembler uses the colon character ':'.

```
var:field
```

where

- 'var' is the name of a variable, which was associated with a structured type.
- 'field' is the name of a field in the structured type associated with the variable.

### Listing 11.14 Example of accessing a field address

---

```
myType:  STRUCT  
field1:  DS.W  1  
field2:  DS.W  1  
field3:  DS.B  1  
field4:  DS.B  3  
field5:  DS.W  1  
ENDSTRUCT  
  
XREF  myData:myType  
XDEF  entry  
  
CodeSec: SECTION  
entry:  
LDA   myData:field3 ; Loads register A with the content of  
                        ; field field3 from variable myData.
```

---

---

**NOTE** The period cannot be used as separator because in assembly language it is a valid character inside of a symbol name.

---

## Accessing a field offset

To access a structured type field offset, the Assembler will use following notation:

```
<typeName>-><field>
```

where:

- 'typeName' is the name of a structured type.
- 'field' is the name of a field in the structured type associated with the variable. See [Listing 11.15 on page 393](#) for an example of using this notation for accessing an offset.

### Listing 11.15 Accessing a field offset with the -><field> notation

---

```
myType:  STRUCT
field1:  DS.W  1
field2:  DS.W  1
field3:  DS.B  1
field4:  DS.B  3
field5:  DS.W  1
        ENDSTRUCT
        XREF.B myData
        XDEF  entry

CodeSec: SECTION
entry:
        LDX #myData
        LDA myType->field3,X ; Adds the offset of field 'field3'
                               ; (4) to X and loads A with the
                               ; content of the pointed address
```

---

## Structured type: Limitations

A field inside of a structured type may be:

- another structured type
- a base type, which can be mapped on 1, 2, or 4 bytes.

The Macro Assembler is not able to process bitfields or pointer types.

The type referenced in a variable definition or declaration must be defined previously. A variable cannot be associated with a type defined afterwards.

## Mixed C and Assembler Applications

*Structured type: Limitations*

---

# Make Applications

---

This chapters has the following sections:

- [“Assembly applications” on page 395](#)
- [“Memory maps and segmentation” on page 396](#)

## Assembly applications

This section covers:

- [Directly generating an absolute file on page 395](#)
- [Mixed C and assembly applications on page 395](#)

### Directly generating an absolute file

When an absolute file is directly generated by the Assembler:

- the application entry point must be specified in the assembly source file using the directive `ABSENTRY`.
- The whole application must be encoded in a single assembly unit.
- The application should only contain absolute sections.

### Generating object files

The entry point of the application must be mentioned in the Linker parameter file using the `"INIT funcname"` command. The application is build of the different object files with the Linker. The Linker is document in a separate document.

Your assembly source files must be separately assembled. Then the list of all the object files building the application must be enumerated in the application PRM file.

### Mixed C and assembly applications

Normally the application starts with the main procedure of a C file. All necessary object files - assembly or C - are linked with the Linker in the same fashion like pure C applications. The Linker is documented in a separate document.

## Make Applications

### Memory maps and segmentation

---

# Memory maps and segmentation

Relocatable Code Sections are placed in the `DEFAULT_ROM` or `.text` Segment.

Relocatable Data Sections are placed in the `DEFAULT_RAM` or `.data` Segment.

---

**NOTE** The `.text` and `.data` names are only supported when the ELF object file format is used.

---

There are no checks at all that variables are in RAM. If you mix code and data in a section you cannot place the section into ROM. That is why we suggest that you separate code and data into different sections.

If you want to place a section in a specific address range, you have to put the section name in the placement portion of the linker parameter file ([Listing 12.1 on page 396](#)).

#### Listing 12.1 Example assembly source code

---

```
SECTIONS
  ROM1      = READ_ONLY  0x0200 TO 0x0FFF;
  SpecialROM = READ_ONLY  0x8000 TO 0x8FFF;
  RAM       = READ_WRITE 0x4000 TO 0x4FFF;
PLACEMENT
  DEFAULT_ROM INTO ROM1;
  mySection  INTO SpecialROM;
  DEFAULT_RAM INTO RAM;
END
```

---

# How to ...

---

This chapter covers the following topics:

- [How to work with absolute sections on page 397](#)
- [How to work with relocatable sections on page 400](#)
- [How to initialize the Vector table on page 402](#)
- [Splitting an application into different modules on page 410](#)
- [Using the direct addressing mode to access symbols on page 412](#)

## How to work with absolute sections

An absolute section is a section whose start address is known at assembly time.

(See modules `fiborg.asm` and `fiborg.prm` in the demo directory)

### Defining absolute sections in an assembly source file

An absolute section is defined using the `ORG` directive. In that case, the Macro Assembler generates a pseudo section, whose name is "ORG\_<index>", where `index` is an integer which is incremented each time an absolute section is encountered ([Listing 13.1 on page 397](#)).

#### Listing 13.1 Defining an absolute section containing data

---

```

var:   ORG   $800      ; Absolute data section.
       DS.   1
       ORG   $A00      ; Absolute constant data section.
cst1:  DC.B  $A6
cst2:  DC.B  $BC

```

---

In the previous portion of code, the label `cst1` is located at address `$A00`, and label `cst2` is located at address `$A01`.

## How to ...

*How to work with absolute sections*

---

### Listing 13.2 Assembler output listing for [Listing 13.1 on page 397](#)

---

```
1      1                                ORG   $800
2      2  a000800          var:  DS.B  1
3      3                                ORG   $A00
4      4  a000A00  A6      cst1:  DC.B  $A6
5      5  a000A01  BC      cst2:  DC.B  $BC
```

---

Program assembly source code should be located in a separate absolute section ([Listing 13.3 on page 398](#)).

### Listing 13.3 Defining an absolute section containing code

---

```
      XDEF  entry
      ORG   $C00 ; Absolute code section.
entry:
      LDA  cst1 ; Load value in cst1
      ADD  cst2 ; Add value in cst2
      STA  var  ; Store in var
      BRA  entry
```

---

In the portion of assembly code above, the LDA instruction is located at address \$C00, and the ADD instruction is at address \$C03. See [Listing 13.4 on page 398](#).

### Listing 13.4 Assembler output listing for [Listing 13.3 on page 398](#)

---

```
      8      8                                ORG   $C00 ; Absolute code
      9      9                                entry:
     10     10  a000C00  C6  0A00          LDA  cst1 ; Load value
     11     11  a000C03  CB  0A01          ADD  cst2 ; Add value
     12     12  a000C06  C7  0800          STA  var  ; Store in var
     13     13  a000C09  20F5          BRA  entry
     14     14
```

---

In order to avoid problems during linking or execution from an application, an assembly file should at least:

- Initialize the stack pointer if the stack is used.
  - The RSP instruction can be used to initialize the stack pointer to \$FF.
  - Publish the application's entry point using XDEF.
  - The programmer should ensure that the addresses specified in the source files are valid addresses for the MCU being used.
-



## Linking an application containing absolute sections

When the Assembler is generating an object file, applications containing only absolute sections must be linked. The linker parameter file must contain at least:

- the name of the absolute file
- the name of the object file which should be linked
- the specification of a memory area where the sections containing variables must be allocated. For applications containing only absolute sections, nothing will be allocated there.
- the specification of a memory area where the sections containing code or constants must be allocated. For applications containing only absolute sections, nothing will be allocated there.
- the specification of the application entry point, and
- the definition of the reset vector.

The minimal linker parameter file will look as shown in [Listing 13.5 on page 399](#).

### Listing 13.5 Minimal linker parameter file

---

```
LINK test.abs /* Name of the executable file generated. */
NAMES
    test.o /* Name of the object file in the application. */
END
SECTIONS
/* READ_ONLY memory area. There should be no overlap between this
   memory area and the absolute sections defined in the assembly
   source file.
*/
    MY_ROM = READ_ONLY 0x4000 TO 0x4FFF;
/* READ_WRITE memory area. There should be no overlap between this
   memory area and the absolute sections defined in the assembly
   source file.
*/
    MY_RAM = READ_WRITE 0x2000 TO 0x2FFF;
END
PLACEMENT
/* Relocatable variable sections are allocated in MY_RAM. */
    DEFAULT_RAM INTO MY_RAM;
/* Relocatable code and constant sections are allocated in MY_ROM. */
    DEFAULT_ROM INTO MY_ROM;
END
INIT entry /* Application entry point. */
VECTOR ADDRESS 0xFFFFE entry /* Initialization of the reset vector. */
```

---

## How to ...

### How to work with relocatable sections

---

**NOTE** There should be no overlap between the absolute sections defined in the assembly source file and the memory areas defined in the PRM file.

---

**NOTE** As the memory areas (segments) specified in the PRM file are only used to allocate relocatable sections, nothing will be allocated there when the application contains only absolute sections. In that case you can even specify invalid address ranges in the PRM file.

---

## How to work with relocatable sections

A relocatable section is a section which start address is determined at linking time.

### Defining relocatable sections in a source file

A relocatable section is defined using the `SECTION` directive. See [Listing 13.6 on page 400](#) for an example of defining relocatable sections.

#### Listing 13.6 Defining relocatable sections containing data

---

```
constSec: SECTION    ; Relocatable constant data section.
cst1:    DC.B    $A6
cst2:    DC.B    $BC

dataSec:  SECTION    ; Relocatable data section.
var:     DS.B    1
```

---

In the previous portion of code, the label `cst1` will be located at an offset 0 from the section `constSec` start address, and label `cst2` will be located at an offset 1 from the section `constSec` start address. See [Listing 13.7 on page 400](#).

#### Listing 13.7 Assembler output listing for [Listing 13.6 on page 400](#)

---

```
2      2      constSec: SECTION ; Relocatable
3      3      000000 A6    cst1:    DC.B    $A6
4      4      000001 BC    cst2:    DC.B    $BC
5      5
6      6      dataSec:  SECTION ; Relocatable
```

---

```
7      7      000000          var:      DS.B      1
```

---

Program assembly source code should be located in a separate relocatable section ([Listing 13.8 on page 401](#)[Listing 13.8 on page 401](#)).

### **Listing 13.8 Defining a relocatable section for code**

---

```
      XDEF  entry
codeSec: SECTION      ; Relocatable code section.
entry:
      LDA  cst1  ; Load value in cst1
      ADD  cst2  ; Add value in cst2
      STA  var   ; Store in var
      BRA  entry
```

---

In the previous portion of code, the LDA instruction is located at an offset 0 from the codeSec section start address, and ADD instruction at an offset 3 from the codeSec section start address.

In order to avoid problems during linking or execution from an application, an assembly file should at least:

- Initialize the stack pointer if the stack is used
- The RSP instruction can be used to initialize the stack pointer to \$FF.
- Publish the application's entry point using the XDEF directive.

## **Linking an application containing relocatable sections**

Applications containing relocatable sections must be linked. The linker parameter file must contain at least:

- the name of the absolute file,
- the name of the object file which should be linked,
- the specification of a memory area where the sections containing variables must be allocated,
- the specification of a memory area where the sections containing code or constants must be allocated,
- the specification of the application's entry point, and
- the definition of the reset vector.

A minimal linker parameter file will look as shown in [Listing 13.9 on page 402](#).

## How to ...

### How to initialize the Vector table

---

#### Listing 13.9 Minimal linker parameter file

---

```
/* Name of the executable file generated.      */
LINK test.abs
/* Name of the object file in the application. */
NAMES
    test.o
END
SECTIONS
/* READ_ONLY memory area. */
    MY_ROM = READ_ONLY 0x2B00 TO 0x2BFF;
/* READ_WRITE memory area. */
    MY_RAM = READ_WRITE 0x2800 TO 0x28FF;
END
PLACEMENT
/* Relocatable variable sections are allocated in MY_RAM.      */
    DEFAULT_RAM          INTO MY_RAM;
/* Relocatable code and constant sections are allocated in MY_ROM. */
    DEFAULT_ROM, constSec INTO MY_ROM;
END
INIT entry                /* Application entry point.      */
VECTOR ADDRESS 0xFFFE entry /* Initialization of the reset vector. */
```

---

**NOTE** The programmer should ensure that the memory ranges he specifies in the SECTIONS block are valid addresses for the controller he is using. In addition, when using the SDI debugger the addresses specified for code or constant sections must be located in the target board ROM area. Otherwise, the debugger will not be able to load the application

---

## How to initialize the Vector table

The vector table can be initialized in the assembly source file or in the linker parameter file. We recommend that you initialize it in the linker parameter file.

- [on page 403](#) [Initializing the Vector table in the linker PRM file on page 403](#) (recommended),
- [Initializing the Vector Table in a source file using a relocatable section on page 405](#), or
- [Initializing the Vector Table in a source file using an absolute section on page 408](#).

The HC(S)08 allows 128 entries in the vector table starting at memory location \$FF00 extending to memory location \$FFFF.

The Reset vector is located in \$FFFE, and the SWI interrupt vector is located in \$FFFC. From \$FFFA down to \$FF00 are located the IRQ[0] interrupt (\$FFFA), IRQ[1] (\$FFFA), ..., IRQ[125] (\$FF00).

In the following examples, the Reset vector, the SWI interrupt and the IRQ[1] interrupt are initialized. The IRQ[0] interrupt is not used.

## Initializing the Vector table in the linker PRM file

Initializing the vector table from the PRM file allows you to initialize single entries in the table. The user can decide to initialize all the entries in the vector table or not.

The labels or functions, which should be inserted in the vector table, must be implemented in the assembly source file ([Listing 13.10 on page 403](#)). All these labels must be published, otherwise they cannot be addressed in the linker PRM file.

### Listing 13.10 Initializing the Vector table from a PRM File

---

```
XDEF  IRQ1Func, SWIFunc, ResetFunc
DataSec: SECTION
Data:  DS.W 5          ; Each interrupt increments an element
                          ; of the table.
CodeSec: SECTION
```

---

```
; Implementation of the interrupt functions.
IRQ1Func:
        LDA    #0
        BRA    int
SWIFunc:
        LDA    #4
        BRA    int
ResetFunc:
        LDA    #8
        BRA    entry
int:
        PSHH
        LDHX  #Data ; Load address of symbol Data in X
; X <- address of the appropriate element in the tab
Offset:  TSTA
        BEQ   Offset3
Offset2:
        AIX   #1
        DECA
```

---

## How to ...

### How to initialize the Vector table

---

```
Offset3:      BNE      Offset2
              INC      0, X      ; The table element is incremented
              PULH
              RTI
entry:        LDHX     #$0E00 ; Init Stack Pointer to $E00-$1=$DFF
              TXS
              CLRX
              CLRH
              CLI                ; Enables interrupts
loop:        BRA      loop
```

---

---

**NOTE** The 'IRQ1Func', 'SWIFunc', and 'ResetFunc' functions are published. This is required, because they are referenced in the linker PRM file.

---

---

**NOTE** The HC08 processor automatically pushes the PC, X, A, and CCR registers on the stack on occurrence of an interrupt. The interrupt functions do not need to save and restore those registers. To maintain compatibility with the M6805 Family, the H register is not stacked, it is the user's responsibility to save and restore it prior to returning.

---

---

**NOTE** All Interrupt functions must be terminated with an RTI instruction

---

The vector table is initialized using the linker VECTOR ADDRESS command ([Listing 13.11 on page 404](#)).

### Listing 13.11 Using the VECTOR ADDRESS Linker Command

---

```
LINK test.abs
NAMES
    test.o
END
SECTIONS
    MY_ROM = READ_ONLY 0x0800 TO 0x08FF;
    MY_RAM = READ_WRITE 0x0B00 TO 0x0CFF;
    MY_STACK = READ_WRITE 0x0D00 TO 0x0DFF;
END
PLACEMENT
    DEFAULT_RAM INTO MY_RAM;
    DEFAULT_ROM INTO MY_ROM;
```

---

```
SSTACK          INTO MY_STACK;
END
INIT ResetFunc
VECTOR ADDRESS 0xFFFF8 IRQ1Func
VECTOR ADDRESS 0xFFFFC SWIFunc
VECTOR ADDRESS 0xFFFFE ResetFunc
```

---

---

**NOTE** The statement `'INIT ResetFunc'` defines the application entry point. Usually, this entry point is initialized with the same address as the reset vector.

---

**NOTE** The statement `'VECTOR ADDRESS 0xFFFF8 IRQ1Func'` specifies that the address of the `'IRQ1Func'` function should be written at address `0xFFFF8`.

---

## Initializing the Vector Table in a source file using a relocatable section

Initializing the vector table in the assembly source file requires that all the entries in the table are initialized. Interrupts, which are not used, must be associated with a standard handler.

The labels or functions that should be inserted in the vector table must be implemented in the assembly source file or an external reference must be available for them. The vector table can be defined in an assembly source file in an additional section containing constant variables. See [Listing 13.12 on page 405](#).

### Listing 13.12 Initializing the Vector Table in source code with a relocatable section

---

```
        XDEF  ResetFunc
        XDEF  IRQ0Int
DataSec: SECTION
Data:   DS.W 5 ; Each interrupt increments an element of the table.
CodeSec: SECTION
; Implementation of the interrupt functions.
IRQ1Func:
        LDA  #0
        BRA  int
SWIFunc:
        LDA  #4
        BRA  int
```

## How to ...

### How to initialize the Vector table

---

```
ResetFunc:
    LDA    #8
    BRA    entry
DummyFunc:
    RTI
int:
    PSHH
    LDHX  #Data ; Load address of symbol Data in X
           ; X <- address of the appropriate element in the tab
Offset:  TSTA
-----
Offset2: BEQ    Offset3
          AIX    # $1
          DECA
          BNE    Offset2
Offset3:  INC    0, X ; The table element is incremented
          PULH
          RTI
entry:   LDHX  # $0E00 ; Init Stack Pointer to $E00-$1=$DFE
          TXS
          CLRX
          CLRH

          CLI           ; Enables interrupts
loop:   BRA    loop
VectorTable: SECTION
; Definition of the vector table.
IRQ1Int: DC.W  IRQ1Func
IRQ0Int: DC.W  DummyFunc
SWIInt:  DC.W  SWIFunc
ResetInt: DC.W  ResetFunc
```

---

**NOTE** Each constant in the 'VectorTable' section is defined as a word (a 2-byte constant), because the entries in the vector table are 16 bits wide.

---

**NOTE** In the previous example, the constant 'IRQ1Int' is initialized with the address of the label 'IRQ1Func'. The constant 'IRQ0Int' is initialized

---



with the address of the label 'Dummy Func' because this interrupt is not in use.

---

**NOTE** All the labels specified as initialization value must be defined, published (using XDEF) or imported (using XREF) before the vector table section. No forward reference is allowed in the DC directive.

---

**NOTE** The constant 'IRQ0Int' is exported so that the section containing the vector table is linked with the application.

---

The section should now be placed at the expected address. This is performed in the linker parameter file ([Listing 13.13 on page 407](#)).

### Listing 13.13 Example linker parameter file

---

```
LINK test.abs
NAMES
    test.o+
END
ENTRIES
    IRQ0Int
END
SECTIONS
    MY_ROM    = READ_ONLY    0x0800 TO 0x08FF;
    MY_RAM    = READ_WRITE  0x0B00 TO 0x0CFF;
    MY_STACK  = READ_WRITE  0x0D00 TO 0x0DFF;
    /* Define the memory range for the vector table */
    Vector    = READ_ONLY    0xFFF8 TO 0xFFFF;
END
PLACEMENT
    DEFAULT_RAM      INTO MY_RAM;
    DEFAULT_ROM      INTO MY_ROM;
    SSTACK           INTO MY_STACK;
    /* Place the section 'VectorTable' at the appropriated address. */
    VectorTable      INTO Vector;
END
INIT ResetFunc
```

---

**NOTE** The statement 'Vector = READ\_ONLY 0xFFF8 TO 0xFFFF' defines the memory range for the vector table.

---

## How to ...

### How to initialize the Vector table

---

**NOTE** The statement `'VectorTable INTO Vector'` specifies that the vector table should be loaded in the read only memory area `Vector`. This means, the constant `'IRQ1Int'` will be allocated at address `0xFFFF8`, the constant `'IRQ0Int'` will be allocated at address `0xFFFFA`, the constant `'SWIInt'` will be allocated at address `0xFFFFC`, and the constant `'ResetInt'` will be allocated at address `0xFFFFE`.

---

**NOTE** The '+' after the object file name switches smart linking off. If this statement is missing in the PRM file, the vector table will not be linked with the application, because it is never referenced. The smart linker only links the referenced objects in the absolute file.

---

## Initializing the Vector Table in a source file using an absolute section

Initializing the vector table in the assembly source file requires that all the entries in the table are initialized. Interrupts, which are not used, must be associated with a standard handler.

The labels or functions, which should be inserted in the vector table must be implemented in the assembly source file or an external reference must be available for them. The vector table can be defined in an assembly source file in an additional section containing constant variables. See [Listing 13.14 on page 408](#) for an example.

### Listing 13.14 Initializing the Vector Table using an absolute section

---

```
XDEF ResetFunc
DataSec: SECTION
Data: DS.W 5 ; Each interrupt increments an element of the table.
CodeSec: SECTION
; Implementation of the interrupt functions.
IRQ1Func:
    LDA #0
    BRA int
SWIFunc:
    LDA #4
    BRA int
ResetFunc:
    LDA #8
    BRA entry
DummyFunc:
    RTI
```

```
int:
    PSHH
    LDHX #Data ; Load address of symbol Data in X
    ; X <- address of the appropriate element in the tab
Offset: TSTA
        BEQ  Offset3
Offset2:
    AIX  #$1
    DECA
        BNE  Offset2
Offset3:
    INC  0, X ; The table element is incremented
    PULH
    RTI
entry:
    LDHX #$0E00 ; Init Stack Pointer to $E00-$1=$DFF
    TXS
    CLRX
    CLRH
    CLI ; Enables interrupts
loop:  BRA  loop

    ORG  $FFF8
; Definition of the vector table in an absolute section
; starting at address $FFF8.
IRQ1Int: DC.W  IRQ1Func
IRQ0Int: DC.W  DummyFunc
SWIInt:  DC.W  SWIFunc
ResetInt: DC.W  ResetFunc
```

---

The section should now be placed at the expected address. This is performed in the linker parameter file ([Listing 13.15 on page 409](#)).

**Listing 13.15 Example linker parameter file for [Listing 13.14 on page 408](#):**

---

```
LINK test.abs
NAMES
    test.o+
END
SECTIONS
    MY_ROM = READ_ONLY 0x0800 TO 0x08FF;
    MY_RAM = READ_WRITE 0x0B00 TO 0x0CFF;
    MY_STACK = READ_WRITE 0x0D00 TO 0x0DFF;
END
PLACEMENT
```

## How to ...

### Splitting an application into different modules

---

```
DEFAULT_RAM      INTO MY_RAM;
DEFAULT_ROM      INTO MY_ROM;
SSTACK          INTO MY_STACK;
END
INIT ResetFunc
```

---

**NOTE** The '+' after the object file name switches smart linking off. If this statement is missing in the PRM file, the vector table will not be linked with the application, because it is never referenced. The smart linker only links the referenced objects in the absolute file.

---

## Splitting an application into different modules

Complex application or application involving several programmers can be split into several simple modules. In order to avoid any problem when merging the different modules, the following rules must be followed.

For each assembly source file, one include file must be created containing the definition of the symbols exported from this module. For the symbols referring to code label, a small description of the interface is required.

### Example of an Assembly File (Test1.asm)

See [Listing 13.16 on page 410](#) for an example Test1.asm include file.

#### Listing 13.16 Separating Code into Modules — Test1.asm

---

```
XDEF AddSource
XDEF Source

DataSec: SECTION
Source: DS.W 1
CodeSec: SECTION
AddSource:
    RSP
    ADD Source
    STA Source
    RTS
```

---

## Corresponding include file (Test1.inc)

See [Listing 13.17 on page 411](#) for an example Test1.inc include file.

### Listing 13.17 Separating Code into Modules — Test1.inc

---

```
XREF AddSource
; The AddSource function adds the value stored in the variable
; Source to the contents of the A register. The result of the
; computation is stored in the Source variable.
;
; Input Parameter: The A register contains the value that should be
;                  added to the Source variable.
; Output Parameter: Source contains the result of the addition.

XREF Source
; The Source variable is a 1-byte variable.
```

---

## Example of an assembly File (Test2.asm)

[Listing 13.18 on page 411](#) is another assembly code file module for this project.

### Listing 13.18 Separating Code into Modules—Test2.asm

---

```
XDEF  entry
INCLUDE "Test1.inc"

CodeSec: SECTION
entry:  RSP
        LDA  #$7
        JSR  AddSource
        BRA  entry
```

---

The application's \*.prm file should list both object files building the application. When a section is present in the different object files, the object file sections are concatenated into a single absolute file section. The different object file sections are concatenated in the order the object files are specified in the \*.prm file.

## How to ...

Using the direct addressing mode to access symbols

---

# Example of a PRM file (Test2.prm)

## Listing 13.19 Separating assembly code into modules—Test2.prm

---

```
LINK test2.abs /* Name of the executable file generated. */
NAMES
    test1.o
    test2.o /* Name of the object files building the application. */
END

SECTIONS
    MY_ROM = READ_ONLY 0x2B00 TO 0x2BFF; /* READ_ONLY mem. */
    MY_RAM = READ_WRITE 0x2800 TO 0x28FF; /* READ_WRITE mem. */
END

PLACEMENT
    /* variables are allocated in MY_RAM */
    DataSec, DEFAULT_RAM INTO MY_RAM;

    /* code and constants are allocated in MY_ROM */
    CodeSec, ConstSec, DEFAULT_ROM INTO MY_ROM;
END
INIT entry /* Definition of the application entry point. */
VECTOR ADDRESS 0xFFFFE entry /* Definition of the reset vector. */
```

---

**NOTE** The 'CodeSec' section is defined in both object files. In 'test1.o', the 'CodeSec' section contains the symbol 'AddSource'. In 'test2.o', the 'CodeSec' section contains the 'entry' symbol. According to the order in which the object files are listed in the NAMES block, the function 'AddSource' is allocated first and the 'entry' symbol is allocated next to it.

---

## Using the direct addressing mode to access symbols

There are different ways for the Assembler to use the direct addressing mode on a symbol:

- [“Using the direct addressing mode to access external symbols” on page 413,](#)
- [“Using the direct addressing mode to access exported symbols” on page 413,](#)
- [“Defining symbols in the direct page” on page 413,](#)
- [“Using the force operator” on page 414,](#) or

- [“Using SHORT sections” on page 414.](#)

## Using the direct addressing mode to access external symbols

External symbols, which should be accessed using the direct addressing mode, must be declared using the `XREF .B` directive. Symbols which are imported using `XREF` are accessed using the extended addressing mode.

### Listing 13.20 Using direct addressing to access external symbols

---

```
XREF.B ExternalDirLabel
XREF   ExternalExtLabel
...
LDA    ExternalDirLabel ; Direct addressing mode is used.
...
LDA    ExternalExtLabel ; Extended addressing mode is used.
```

---

## Using the direct addressing mode to access exported symbols

Symbols, which are exported using the `XDEF .B` directive, will be accessed using the direct addressing mode. Symbols which are exported using `XDEF` are accessed using the extended addressing mode.

### Listing 13.21 Using direct addressing to access exported symbols

---

```
XDEF.B DirLabel
XDEF   ExtLabel
...
LDA    DirLabel ; Direct addressing mode is used.
...
LDA    ExtLabel ; Extended addressing mode is used.
```

---

## Defining symbols in the direct page

Symbols that are defined in the predefined `BSCT` section are always accessed using the direct-addressing mode ([Listing 13.22 on page 414](#)).

## How to ...

Using the direct addressing mode to access symbols

---

### Listing 13.22 Defining symbols in the direct page

---

```
...
        BSCT
DirLabel: DS.B 3
dataSec: SECTION
ExtLabel: DS.B 5
...
codeSec: SECTION
...
        LDA    DirLabel ; Direct addressing mode is used.
...
        LDA    ExtLabel ; Extended addressing mode is used.
```

---

## Using the force operator

A force operator can be specified in an assembly instruction to force direct or extended addressing mode ([Listing 13.23 on page 414](#)).

The supported force operators are:

- < or .B to force direct addressing mode
- > or .W to force extended addressing mode.

### Listing 13.23 Using a force operator

---

```
...
dataSec: SECTION
label:   DS.B 5
...
codeSec: SECTION
...
        LDA    <label ; Direct addressing mode is used.
        LDA    label.B ; Direct addressing mode is used.
...
        LDA    >label ; Extended addressing mode is used.
        LDA    label.W ; Extended addressing mode is used.
```

---

## Using SHORT sections

Symbols that are defined in a section defined with the SHORT qualifier are always accessed using the direct addressing mode ([Listing 13.24 on page 415](#)).



**Listing 13.24 Using SHORT sections**

---

```
...
shortSec: SECTION SHORT
DirLabel: DS.B 3
dataSec: SECTION
ExtLabel: DS.B 5
...
codeSec: SECTION
...
        LDA    DirLabel ; Direct addressing mode is used.
...
        LDA    ExtLabel ; Extended addressing mode is used.
```

---

## **How to ...**

*Using the direct addressing mode to access symbols*

---



# Appendices

---

This document has the following appendices:

- [“Global Configuration File Entries” on page 419](#)
- [“Local Configuration File Entries” on page 429](#)
- [“MASM Compatibility” on page 441](#)
- [“MCUasm Compatibility” on page 445](#)



# Global Configuration File Entries

---

This appendix documents the sections and entries that can appear in the global configuration file. This file is named `mcutools.ini`.

`mcutools.ini` can contain these sections:

- [\[Installation\] Section on page 420](#)
- [\[Options\] Section on page 421](#)
- [\[XXX Assembler\] Section on page 422](#)
- [\[Editor\] Section on page 425](#)

# [Installation] Section

---

## Path

### Arguments

Last installation path.

### Description

Whenever a tool is installed, the installation script stores the installation destination directory into this variable.

### Example

```
Path=C:\install
```

---

## Group

### Arguments

Last installation program group.

### Description

Whenever a tool is installed, the installation script stores the installation program group created into this variable.

### Example

```
Group=Assembler
```

# [Options] Section

---

## DefaultDir

### Arguments

Default directory to be used.

### Description

Specifies the current directory for all tools on a global level. See also [DEFAULTDIR: Default current directory](#) environment variable.

### Example

```
DefaultDir=C:\install\project
```

## Global Configuration File Entries

[XXX\_Assembler] Section

---

# [XXX\_Assembler] Section

This section documents the entries that can appear in an [XXX\_Assembler] section of the `mcutools.ini` file.

---

**NOTE** XXX is a placeholder for the name of the name of the particular Assembler you are using. For example, if you are using the HC08 Assembler, the name of this section would be [HC08\_Assembler].

---

---

## SaveOnExit

### Arguments

1/0

### Description

1 if the configuration should be stored when the Assembler is closed, 0 if it should not be stored. The Assembler does not ask to store a configuration in either cases.

---

## SaveAppearance

### Arguments

1/0

### Description

1 if the visible topics should be stored when writing a project file, 0 if not. The command line, its history, the windows position and other topics belong to this entry.

This entry corresponds to the state of the *Appearance* check box in the [Save Configuration](#) dialog box.



## SaveEditor

### Arguments

1/0

### Description

If the editor settings should be stored when writing a project file, 0 if not. The editor setting contain all information of the *Editor Configuration* dialog box. This entry corresponds to the state of the check box *Editor Configuration* in the [Save Configuration dialog box](#).

---

## SaveOptions

### Arguments

1/0

### Description

1 if the options should be contained when writing a project file, 0 if not. This entry corresponds to the state of the *Options* check box in the [Save Configuration dialog box](#).

---

## RecentProject0, RecentProject1, ...

### Arguments

Names of the last and prior project files

---

## Global Configuration File Entries

[XXX\_Assembler] Section

---

### Description

This list is updated when a project is loaded or saved. Its current content is shown in the file menu.

### Example

```
SaveOnExit=1
SaveAppearance=1
SaveEditor=1
SaveOptions=1
RecentProject0=C:\myprj\project.ini
RecentProject1=C:\otherprj\project.ini
```

## [Editor] Section

---

### Editor\_Name

#### Arguments

The name of the global editor

#### Description

Specifies the name of the editor used as global editor. This entry has only a descriptive effect. Its content is not used to start the editor.

#### Saved

Only with *Editor Configuration* set in the *File > Configuration Save Configuration* dialog box.

---

### Editor\_Exe

#### Arguments

The name of the executable file of the global editor (including path).

#### Description

Specifies the filename which is started to edit a text file, when the global editor setting is active.

#### Saved

Only with *Editor Configuration* set in the *File > Configuration Save Configuration* dialog box.

## Global Configuration File Entries

[Editor] Section

---

### Editor\_Opts

#### Arguments

The options to use with the global editor

#### Description

Specifies options (arguments), which should be used when starting the global editor. If this entry is not present or empty, "%f" is used. The command line to launch the editor is built by taking the `Editor_Exe` content, then appending a space followed by the content of this entry.

#### Saved

Only with *Editor Configuration* set in the *File > Configuration Save Configuration* dialog box.

#### Example

```
[Editor]
editor_name=IDF
editor_exe=C:\Freescale\prog\idf.exe
editor_opts=%f -g%1,%c
```

# Example

[Listing A.1 on page 427](#) shows a typical `mcutools.ini` file.

## Listing A.1 Typical `mcutools.ini` file layout

---

```
[Installation]
Path=c:\Freescale
Group=Assembler

[Editor]
editor_name=IDF
editor_exe=C:\Freescale\prog\idf.exe
editor_opts=%f -g%1,%c

[Options]
DefaultDir=c:\myprj

[HC08_Assembler]
SaveOnExit=1
SaveAppearance=1
SaveEditor=1
SaveOptions=1
RecentProject0=c:\myprj\project.ini
RecentProject1=c:\otherprj\project.ini
```

---

## Global Configuration File Entries

*Example*

---

# Local Configuration File Entries

---

This appendix documents the sections and entries that can appear in the local configuration file. Usually, you name this file `project.ini`, where `project` is a placeholder for the name of your project.

A `project.ini` file can contains these sections:

- [\[Editor\] Section on page 430](#)
- [\[XXX Assembler\] Section on page 432](#)
- [Example on page 439](#)

# [Editor] Section

---

## Editor\_Name

### Arguments

The name of the local editor

### Description

Specifies the name of the editor used as local editor. This entry has only a description effect. Its content is not used to start the editor.

This entry has the same format as for the global editor configuration in the `mcutools.ini` file.

### Saved

Only with 'Editor Configuration' set in the *File > Configuration > Save Configuration* dialog box.

---

## Editor\_Exe

### Arguments

The name of the executable file of the local editor (including path).

### Description

Specifies the filename with is started to edit a text file, when the local editor setting is active. In the editor configuration dialog box, the local editor selection is only active when this entry is present and not empty.

This entry has the same format as for the global editor configuration in the `mcutools.ini` file.

### Saved

Only with *Editor Configuration* set in the *File > Configuration > Save Configuration* dialog box.

---



## Editor\_Opts

### Arguments

The options to use with the local editor

### Description

Specifies options (arguments), which should be used when starting the local editor. If this entry is not present or empty, "%f" is used. The command line to launch the editor is build by taking the Editor\_Exe content, then appending a space followed by the content of this entry.

This entry has the same format as for the global editor configuration in the `mcutools.ini` file.

### Saved

Only with *Editor Configuration* set in the *File > Configuration > Save Configuration* dialog box.

### Example

```
[Editor]
editor_name=IDF
editor_exe=C:\Freescale\prog\idf.exe
editor_opts=%f -g%l,%c
```

## Local Configuration File Entries

[XXX\_Assembler] Section

---

# [XXX\_Assembler] Section

This section documents the entries that can appear in an [XXX\_Assembler] section of a `project.ini` file.

---

**NOTE** XXX is a placeholder for the name of the name of the particular Assembler you are using. For example, if you are using the HC08 Assembler, the name of this section would be [HC08\_Assembler].

---

---

## RecentCommandLineX, X= integer

### Arguments

String with a command line history entry, e.g., `fibonacci.asm`

### Description

This list of entries contains the content of the command line history.

### Saved

Only with *Appearance* set in the *File > Configuration > Save Configuration* dialog box.

---

## CurrentCommandLine

### Arguments

String with the command line, e.g., `"fibonacci.asm -w1"`

### Description

The currently visible command line content.

### Saved

Only with *Appearance* set in the *File > Configuration > Save Configuration* dialog box.

## StatusbarEnabled

### Arguments

1/0

### Special

This entry is only considered at startup. Later load operations do not use it any more.

### Description

Current statusbar state.

- 1: Statusbar is visible
- 0: Statusbar is hidden

### Saved

Only with *Appearance* set in the *File > Configuration > Save Configuration* dialog box.

---

## ToolbarEnabled

### Arguments

1/0

### Special

This entry is only considered at startup. Afterwards, any load operations do not use it any longer.

### Description

Current toolbar state:

- 1: Toolbar is visible
- 0: Toolbar is hidden

## Local Configuration File Entries

[XXX\_Assembler] Section

---

### Saved

Only with *Appearance* set in the *File > Configuration > Save Configuration* dialog box.

---

## WindowPos

### Arguments

10 integers, e.g., "0, 1, -1, -1, -1, -1, 390, 107, 1103, 643"

### Special

This entry is only considered at startup. Afterwards, any load operations do not use it any longer.

Changes of this entry do not show the "\*" in the title.

### Description

This numbers contain the position and the state of the window (maximized,..) and other flags.

### Saved

Only with *Appearance* set in the *File > Configuration > Save Configuration* dialog box.

---

## WindowFont

### Arguments

size: = 0 -> generic size, < 0 -> font character height, > 0 -> font cell height

weight: 400 = normal, 700 = bold (valid values are 0..1000)

italic: 0 = no, 1 = yes

font name: max. 32 characters.

### Description

Font attributes.

---

**Saved**

Only with *Appearance* set in the *File > Configuration > Save Configuration* dialog box.

**Example**

```
WindowFont=-16,500,0,Courier
```

---

## TipFilePos

**Arguments**

any integer, e.g., 236

**Description**

Actual position in tip of the day file. Used that different tips are shown at different calls.

**Saved**

Always when saving a configuration file.

---

## ShowTipOfDay

**Arguments**

0/1

**Description**

Should the *Tip of the Day* dialog box be shown at startup?

- 1: It should be shown
- 0: No, only when opened in the help menu

**Saved**

Always when saving a configuration file.

---

## Local Configuration File Entries

[XXX\_Assembler] Section

---

### Options

#### Arguments

current option string, e.g.: -W2

#### Description

The currently active option string. This entry can be very long.

#### Saved

Only with *Options* set in the *File > Configuration > Save Configuration* dialog box.

---

### EditorType

#### Arguments

0/1/2/3/4

#### Description

This entry specifies which editor configuration is active:

- 0: global editor configuration (in the file `mcutools.ini`)
- 1: local editor configuration (the one in this file)
- 2: command line editor configuration, entry `EditorCommandLine`
- 3: DDE editor configuration, entries beginning with `EditorDDE`
- 4: CodeWarrior with COM. There are no additional entries.

For details, see also [Editor Setting dialog box](#).

#### Saved

Only with *Editor Configuration* set in the *File > Configuration > Save Configuration* dialog box.

---

---

## EditorCommandLine

### Arguments

Command line, for UltraEdit-32: "c:\Programs Files\IDM Software Solutions\UltraEdit-32\uedit32.exe %f -g%l,%c"

### Description

Command line content to open a file. For details, see also [Editor Setting dialog box](#).

### Saved

Only with *Editor Configuration* set in the *File > Configuration > Save Configuration* dialog box.

---

## EditorDDEClientName

### Arguments

client command, e.g., "[open (%f)]"

### Description

Name of the client for DDE editor configuration. For details, see also [Editor Setting dialog box](#).

### Saved

Only with *Editor Configuration* set in the *File > Configuration > Save Configuration* dialog box.

---

## EditorDDETopicName

### Arguments

topic name, e.g., "system"

---

## Local Configuration File Entries

[XXX\_Assembler] Section

---

### Description

Name of the topic for DDE editor configuration. For details, see also [Editor Setting dialog box](#).

### Saved

Only with *Editor Configuration* set in the *File > Configuration > Save Configuration* dialog box.

---

## EditorDDEServiceName

### Arguments

service name, e.g., "system"

### Description

Name of the service for DDE editor configuration. For details, see also [Editor Setting dialog box](#).

### Saved

Only with *Editor Configuration* set in the *File > Configuration > Save Configuration* dialog box.



## Example

The example in [Listing B.1 on page 439](#) shows a typical layout of the configuration file (usually `project.ini`).

### Listing B.1 Example of a project.ini file

---

```
[Editor]
Editor_Name=IDF
Editor_Exec=c:\Freescale\prog\idf.exe
Editor_Opts=%f -g%l,%c

[HC08_Assembler]
StatusBarEnabled=1
ToolBarEnabled=1
WindowPos=0,1,-1,-1,-1,-1,390,107,1103,643
WindowFont=-16,500,0,Courier
TipFilePos=0
ShowTipOfDay=1
Options=-w1
EditorType=3
RecentCommandLine0=fibo.asm -w2
RecentCommandLine1=fibo.asm
CurrentCommandLine=fibo.asm -w2
EditorDDEClientName=[open(%f)]
EditorDDETopicName=system
EditorDDEServiceName=msdev
EditorCommandLine=c:\Freescale\prog\idf.exe %f -g%l,%c
```

---

## Local Configuration File Entries

*Example*

---

# MASM Compatibility

---

The Macro Assembler has been extended to ensure compatibility with the MASM Assembler.

## Comment Line

A line starting with a (\*) character is considered to be a comment line by the Assembler.

## Constants (Integers)

For compatibility with the MASM Assembler, the following notations are also supported for integer constants:

- A decimal constant is defined by a sequence of decimal digits (0-9) followed by a 'd' or 'D' character.
- A hexadecimal constant is defined by a sequence of hexadecimal digits (0-9, a-f, A-F) followed by a 'h' or 'H' character.
- An octal constant is defined by a sequence of octal digits (0-7) followed by an 'o', 'O', 'q', or 'Q' character.
- A binary constant is defined by a sequence of binary digits (0-1) followed by a 'b' or 'B' character.

### Listing C.1 Example

---

```
512d      ; decimal representation
512D      ; decimal representation
200h      ; hexadecimal representation
200H      ; hexadecimal representation
1000o     ; octal representation
1000O     ; octal representation
1000q     ; octal representation
1000Q     ; octal representation
1000000000b ; binary representation
1000000000B ; binary representation
```

---

## Operators

For compatibility with the MASM Assembler, the following notations in [Table C.1 on page 442](#) are also supported for operators:

**Table C.1 Operator notation for MASM compatibility**

Operator	Notation
Shift left	!<
Shift right	!>
Arithmetic AND	!.
Arithmetic OR	!+
Arithmetic XOR	!x, !X

## Directives

[Table C.2 on page 442](#) enumerates the directives that are supported by the Macro Assembler for compatibility with MASM:

**Table C.2 Supported MASM directives**

Operator	Notation	Description
RMB	DS	Define storage for a variable. Argument specifies the byte size
RMD	DS 2*	Define storage for a variable. Argument specifies the number of 2-byte blocks
RMQ	DS 4*	Define storage for a variable. Argument specifies the number of 4-byte blocks
ELSEC	ELSE	Alternate of conditional block
ENDC	ENDIF	End of conditional block
NOL	NOLIST	Specify that all subsequent instructions must not be inserted in the listing file.
TTL	TITLE	Define the user defined title for the assembler listing file.

**Table C.2 Supported MASM directives**

<b>Operator</b>	<b>Notation</b>	<b>Description</b>
GLOBAL	XDEF	Make a symbol public (Visible from outside)
PUBLIC	XDEF	Make a symbol public (Visible from outside)
EXTERNAL	XREF	Import reference to an external symbol.
XREFB	XREF.B	Import reference to an external symbol located on the direct page.
SWITCH		Allows the switching to a section which has been defined previously.
ASCT		Creates a predefined section which name id ASCT.
BSCT		Creates a predefined section which name id BSCT. Variable defined in this section are accessed using the direct addressing mode.
CSCT		Creates a predefined section which name id CSCT.
DSCT		Creates a predefined section which name id DSCT.
ID SCT		Creates a predefined section which name id ID SCT.
IP SCT		Creates a predefined section which name id IP SCT.
PSCT		Creates a predefined section which name id PSCT.



# MCUasm Compatibility

---

The Macro Assembler has been extended to ensure compatibility with the MCUasm Assembler.

MCUasm compatibility mode can be activated, specifying the `-MCUasm` option.

This chapter covers the following topics:

- [“Labels” on page 445](#)
- [“SET directive” on page 445](#)
- [“Obsolete directives” on page 446](#)

## Labels

When MCUasm compatibility mode is activated, labels must be followed by a colon, even when they start on column 1.

When MCUasm compatibility mode is activated, following portion of code generate an error message, because the label ‘label’ is not followed by a colon.

### Listing D.1 Example

---

```
label      DC.B  1
```

---

When MCUasm compatibility mode is not activated, the previous portion of code does not generate any error message.

## SET directive

When MCUasm compatibility mode is activated, relocatable expressions are also allowed in a SET directive.

When MCUasm compatibility mode is activated, the following portion of code does not generate any error messages:

## MCUasm Compatibility

### Obsolete directives

---

#### Listing D.2 Example

---

```
label: SET *
```

---

When MCUasm compatibility mode is not activated, the previous portion of code generates an error message because the SET label can only refer to absolute expressions.

## Obsolete directives

[Table D.1 on page 446](#) enumerates the directives, which are not recognized any longer when the MCUasm compatibility mode is switched ON.:

**Table D.1 Obsolete directives**

Operator	Notation	Description
RMB	DS	Define storage for a variable
NOL	NOLIST	Specify that all subsequent instructions must not be inserted in the listing file.
TTL	TITLE	Define the user-defined title for the assembler listing file.
GLOBAL	XDEF	Make a symbol public (Visible from the outside)
PUBLIC	XDEF	Make a symbol public (Visible from the outside)
EXTERNAL	XREF	Import reference to an external symbol.



---

# Index

---

## Symbols

\$() 117  
\${} 117  
%(ENV) 146  
%" 146  
' 146  
%E 146  
%e 146  
%f 146  
%N 145  
%n 146  
%p 145  
\* 294  
.abs 138  
.asm 137  
.dbg 139  
.hidefaults 115, 116  
.inc 137  
.ini 94  
.lst 139  
.o 138  
.s1 138  
.s2 138  
.s3 138  
.sx 138  
{Compiler} 117  
{Project} 117  
{System} 117

## A

A2309  
    File not found 61  
About... dialog box 110  
ABSENTRY 84, 300  
absolute assembly 86, 88  
Absolute Expression 294, 295  
Absolute Section 242, 247  
ABSPATH 104, 122, 138

Add Additional Files dialog box 22  
Add Files dialog box 34, 42  
Addressing Mod 265  
Addressing Mode  
    Direct 276  
    Extended 276  
    Immediate 276  
    Indexed, 8-bit offset 266  
    Indexed, 8-bit offset with post-increment 266  
    Indexed, no offset 266, 276  
    Inherent 276  
    Memory to memory direct to direct 266  
    Memory to memory indexed to direct with post-increment 266  
    Relative 276  
    Stack pointer, 16-bit offset 266  
    Stack pointer, 8-bit offset 266

Addressing Modes 265, 276

ALIGN 306, 323, 340

ASMOPTIONS 123

Assembler

    Configuration 94  
    Input File 110, 137  
    Menu 95  
    Messages 106  
    Option 105  
    Options Setting Dialog 105  
    Output Files 137  
    Status Bar 93

Assembler for HC08 preference panel 38, 84

Assembler Main Window 90

Assembler menu 95

## B

-B 151  
BASE 300, 307  
-BL 151

---

## C

- C 159
- Ci 152
- CLIST 301
- CMacAngBrack 154
- CMacBrackets 155
- CODE 145, 193
- Code Section 241
- CodeWarrior 100
- CodeWarrior project window 25
- CodeWarrior with COM 100
- color 212, 213, 214, 215, 216
- COM 100
- COM Editor Configuration 101
- Command-Line Editor configuration 99
- Compat 156
- Complex Relocatable Expression 294
- Constant
  - Binary 283, 441
  - Decimal 283, 441
  - Floating point 283
  - Hexadecimal 283, 441
  - Integer 283
  - Octal 283, 441
  - String 283
- Constant Section 241
- COPYRIGHT 124
- Create Group dialog box 41
- CTRL-S 105
- Current Directory 116, 125
- CurrentCommandLine 432

## D

- D 161
- Data Section 242
- DC 311
- DCB 313
- DDE Editor configuration 100
- Debug File 139, 336
- Default Directory 421
- DEFAULTDIR 125, 137
- DefaultDir 421
- Device and Connection dialog box 21

## Directive 265

- ABSENTRY 300
- ALIGN 306, 323, 340
- BASE 300, 307
- CLIST 301
- DC 311
- DCB 313
- DS 300, 314
- ELSE 316
- ELSEC 442
- END 318
- ENDC 442
- ENDFOR 301, 319
- ENDIF 302, 319, 320, 330
- ENDM 302, 342
- EQU 299, 322
- EVEN 323
- EXTERNAL 443, 446
- FAIL 301, 325
- FOR 329
- GLOBAL 443, 446
- IF 331, 333
- IFC 302, 333
- IFDEF 303, 334
- IFEQ 303, 333
- IFGE 303, 333
- IFGT 303, 333
- IFLE 303, 333
- IFLT 303, 333
- IFNC 303, 333
- IFNDEF 303, 334
- IFNE 303, 333
- INCLUDE 335
- LIST 301, 336
- LLEN 338
- LONGEVEN 301, 340
- Macro 341
- MEXIT 342
- MLIST 345
- NOL 442, 446
- NOLIST 301, 348
- NOPAGE 301, 350
- OFFSET 351
- ORG 353

---

PAGE 301, 355  
PLEN 357  
PUBLIC 443, 446  
RAD50 300, 358  
RMB 442, 446  
Section 299, 361  
SET 363  
SPC 364  
TABS 365  
TITLE 366  
TTL 442, 446  
XDEF 367  
XREF 282, 300, 368  
XREFB 300, 369, 443  
Drag and Drop 111  
DS 300, 314

## **E**

Editor 430  
Editor Setting dialog bo 96  
Editor\_Exec 425, 430  
Editor\_Name 425, 430  
Editor\_Opts 426, 431  
EditorCommandLine 437  
EditorDDEClientName 437  
EditorDDEServiceName 438  
EditorDDETopicName 437  
EditorType 436  
EDOUT 139  
ELSE 316  
ELSEC 442  
END 318  
ENDC 442  
ENDFOR 301, 319  
ENDIF 302, 319, 320, 330  
ENDM 302, 342  
-ENV 163  
ENVIRONMENT 126  
Environment  
    ABSPATH 122, 138  
    ASMOPTIONS 123  
    COPYRIGHT 124  
    DEFAULTDIR 125, 137  
    ENVIRONMENT 126

ENVIRONMENT 115, 116  
ERRORFILE 127  
File 115  
GENPATH 130, 137, 335  
HIENVIRONMENT 126  
INCLUDETIME 131  
OBJPATH 132, 138  
TEXTPATH 134  
TMP 135  
Variable 115  
Environment Configuration dialog bo 104  
Environment Variable 121  
    ABSPATH 138  
    SRECORD 138  
Environment Variables 104, 115  
EQU 299, 322  
Error File 139  
Error Listing 139  
ERRORFILE 127  
EVEN 323  
Explorer 116  
Expression 293  
    Absolute 294, 295  
    Complex Relocatable 294  
    Simple Relocatable 294, 296  
EXTERNAL 443, 446  
External Symbol 281

## **F**

-F2 164  
-F2o 164  
-FA2 164  
-FA2o 164  
FAIL 301, 325  
-Fh 164  
File  
    Debug 139, 336  
    Environment 115  
    Error 139  
    Include 137  
    Listing 138, 139, 301, 336  
    Object 138  
    PRM 243, 245, 246  
    Source 137

---

File Manager 116  
File menu 93  
File menu options 94  
Floating-Point Constant 283  
FOR 329

## G

GENPATH 63, 65, 104, 130, 137, 335  
GENPATH environmental variable 66  
GLOBAL 443, 446  
Global Edito 96  
Global Editor Configuration dialog box 97  
Group 420  
groups, CodeWarrior 29  
GUI Graphic User Interface 89

## H

-H 166  
HC(S)08 New Project dialog box 20  
HC08 Assembler main window 91  
HC08 Assembler Message Settings dialog  
box 109  
HC08 Assembler Option Settings dialog bo 55  
HC08 Assembler Option Settings dialog box 39,  
85  
HIENVIRONMENT 126  
HIGH 282  
hiwave.ex 71  
HOST 145

## I

-I 167  
IDF 116  
IF 331, 333  
IFC 302, 333  
IFDEF 303, 334  
IFEQ 303, 333  
IFGE 303, 333  
IFGT 303, 333  
IFLE 303, 333  
IFLT 303, 333  
IFNC 303, 333  
IFNDEF 303, 334

IFNE 303, 333  
INCLUDE 335  
Include Files 137  
INCLUDETIME 131  
Instruction 250  
Integer Constant 283

## L

-L 168  
Label 250  
LANGUAGE 145  
-Lasmc 171  
-Lasms 173  
-Lc 175  
-Ld 178  
-Le 181  
-Li 184  
LIBPATH 104  
-Lic 186, 188  
-LicA 187  
-LicWait 190  
Line Continuation 120  
Linker for HC08 preference panel 69, 86  
Linker main window 75  
LIST 301, 336  
Listing File 138, 139, 301, 336  
-Ll 191  
LLEN 338  
Load Executable File dialog box 79  
Local Editor 97  
Local editor configuration dialog box 98  
LONGEVEN 301, 340  
LOW 282

## M

Macro 265, 341  
-MacroNest 195  
-MCUasm 196  
MCUTOOLS.INI 125  
Menu bar options 93  
MESSAGE 145  
Message classes 108  
Message Settings 106  
Message Settings dialog box 106, 107

---

Message Settings options 107  
MEXIT 342  
Microsoft Developer Studio configuration  
  settings 100  
MLIST 345  
Modifiers 101  
-Ms 193, 384  
-Mt 193  
-Mx 384

## N

-N 197  
New Target dialog box 31  
-NoBeep 198  
-NoDebugInfo 199  
-NoEnv 200  
NOL 442, 446  
NOLIST 301, 348  
NOPAGE 301, 350

## O

Object File 138  
-ObjN 201  
OBJPATH 104, 132, 138  
OFFSET 351  
Operand 265, 276  
Operator 283, 442  
  Addition 284, 293, 297  
  Arithmetic AND 442  
  Arithmetic Bit 297  
  Arithmetic OR 442  
  Arithmetic XOR 442  
  Bitwise 287  
  Bitwise (unary) 288  
  Bitwise AND 294  
  Bitwise Exclusive OR 294  
  Bitwise OR 294  
  Division 285, 293, 297  
  Force 292  
  HIGH 282, 289, 290, 291  
  Logical 288  
  LOW 282, 290  
  Modulo 285, 293, 297  
  Multiplication 285, 293, 297

PAGE 292  
Precedence 293  
Relational 289, 294  
Shift 286, 294, 297  
  Shift left 442  
  Shift right 442  
Sign 285, 293, 297  
Subtraction 284, 293, 297

## Option

  CODE 145, 193  
  HOST 145  
  LANGUAGE 145  
  MESSAGE 145  
  OUTPUT 145  
  VARIOUS 145  
Option Settings dialog box 105  
Option Settings options 106  
Options 421, 436  
ORG 353  
OUTPUT 145

## P

PAGE 301, 355  
-PAlign 201  
PATH 132  
Path 420  
Path environment variables 104  
Path List 119  
PLEN 357  
-PR8R15 201  
PRM File 243, 245, 246  
PRM file 72  
Processor Expert dialog box 23  
-Prod 203  
project.ini 119  
PUBLIC 443, 446

## R

RAD50 300, 358  
RecentCommandLine 432  
Relocatable Section 244  
Rename Group dialog bo 43  
Reserved Symbol 282  
Reset vector 83

---

RGB 212, 213, 214, 215, 216  
RMB 442, 446

## S

Save As dialog box 40  
Save Configuration dialog box 102  
SaveAppearance 422  
SaveEditor 423  
SaveOnExit 422  
SaveOptions 423  
Section 299, 361  
    Absolute 242, 247  
    Code 241  
    Constant 241  
    Data 242  
    Relocatable 244  
Sections 241  
Select File to Assemble dialog box 87  
Select File to Link dialog box 74  
Select files to add... dialog box 33, 42  
Select Files to Assemble dialog box 59  
SET 363  
Set Connection dialog box 77, 78  
SHORT 362  
ShowTipOfDay 435  
Simple Relocatable Expression 294, 296  
Simulator 80  
Simulator/Debugger 71  
Source File 137  
SPC 364  
Special Modifiers 145  
-ST 204  
Starting 89  
startup 119  
Startup dialog box 19  
Status Bar 93  
StatusbarEnabled 433  
String Constant 283  
-Struct 204  
Symbol 280  
    External 281  
    Reserved 282  
    Undefined 282  
    User Defined 280

## T

TABS 365  
TEXTPATH 104, 134  
Tip of the Day 51, 89  
Tip of the Day dialog box 90  
TipFilePos 435  
TITLE 366  
TMP 135  
Toolbar 92  
ToolbarEnabled 433  
True-Time Simulator & Real-Time Debugger 77  
TTL 442, 446

## U

Undefined Symbol 282  
UNIX 116  
User Defined Symbol 280

## V

-V 205  
Variable  
    Environment 115  
VARIOUS 145  
-View 206  
View menu 95  
View menu options 95

## W

-W1 208  
-W2 209  
-WErrFile 210  
WindowFont 434  
WindowPos 434  
Windows 116  
WinEdit 116, 128  
-Wmsg8x3 211  
-WmsgCE 212  
-WmsgCF 213  
-WmsgCI 214  
-WmsgCU 215  
-WmsgCW 216  
-WmsgFb 112  
-WmsgFbiv 219

---

- WmsgFbm 217
- WmsgFbv 217
- WmsgFi 112, 211
- WmsgFim 219
- WmsgFob 221
- WmsgFoi 223
- WmsgFonp 218, 220, 222, 224, 226, 227, 228
- WmsgNe 229, 233
- WmsgNi 229, 230
- WmsgNu 231
- WmsgNw 229, 230, 233
- WmsgSd 234
- WmsgSe 235
- WmsgSi 236
- WmsgSw 237
- WOutFile 238
- WStdout 239

## **X**

- XDEF 367
- XREF 282, 300, 368
- XREFB 300, 369, 443











